



**Power Supply System
Guardian Hybrid Cabinet
GDN.S.48.MS32
Instruction Manual**



Document Number: MS0032HC-MAN rev. 2

**© 2019 UNIPOWER LLC
All Rights Reserved**

UNIPOWER, LLC
65 Industrial Park Rd
Dunlap, TN 37327
Phone: +1-954-346-2442
Toll Free: 1-800-440-3504
Web site: www.unipowerco.com

Copyright © 1999-2019 UNIPOWER LLC

All Rights Reserved

Restricted Rights Legend:

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph © (1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 or subparagraphs © (1) and (2) of Commercial Computer Software - Restricted Rights at 48 CFR 52.227-19, as applicable.

For Contact Information, please go to <https://www.unipowerco.com/contact/>

Refer to the UNIPOWER License Agreement in this package before installing or using this product.

Unless specifically noted, all addresses, data characters and persons referenced herein, and all examples involving names of companies and products, are fictitious examples and are designed solely to illustrate the use of UNIPOWER products.

Product names, logos, brands, and other trademarks featured or referred to within this product manual are the property of their respective trademark holders. These trademark holders are not affiliated with UNIPOWER LLC or our products. They do not sponsor or endorse our products.

LIMITATIONS AND AUTHORIZATIONS FOR USE AND PERMITTED APPLICATIONS

UNIPOWER's products are not designed, intended for use in, or authorized for use as critical components in, human life support systems/equipment, equipment used in hazardous environments, or equipment used in nuclear control equipment or systems. Any such use requires the prior express written consent of an authorized executive officer of UNIPOWER LLC, which consent may be withheld by UNIPOWER LLC in its sole discretion. Users assume all risk and liability for, and agree to indemnify and defend UNIPOWER from and against any claims for personal injury (including death) or property damage resulting from any such use or application which is made in the absence of such prior express written consent.

If you find errors or problems with this documentation, please notify UNIPOWER. UNIPOWER does not guarantee that this document is error-free. The information in this document is subject to change without notice.

REV	DESCRIPTION	CHK'd & APPR'd / DATE
2	PCO# 45398	MM / 07-31-19

Contents

Chapter 1 About This Manual	6
1.1 Objectives	6
1.2 Audience	6
1.3 Document Key	6
1.4 Feedback & Support	7
Chapter 2 System Description	8
2.1 Overview	8
2.2 System Components	10
2.2.1 Rectifier Module	11
2.2.2 Solar Converter Module	12
2.2.3 System Controller	13
2.2.4 Distribution Unit	14
2.2.5 Extended 3U PDU (Optional)	15
2.2.6 DC Input Distribution Unit	15
2.2.7 PV String Combiner	17
2.2.8 Genset Kit (Optional)	18
Chapter 3 System Safety	19
3.1 Safety Warnings and Guidelines	19
3.1.1 System Markings	19
3.1.2 Safety Recommendations	19
3.1.3 Installation Warning	20
3.1.4 Restricted Access Area Warnings	20
3.1.5 System Enclosure	20
3.1.6 Operating Temperature Warnings	20
3.1.7 Recommended Power Ratings	20
3.1.8 Electrical Safety Warnings	21
3.1.9 Grounding	22
3.1.10 Batteries	22
3.1.10.1 Lead Acid Batteries	22
3.1.11 PV Modules and Arrays	23
3.1.12 Generator	23
3.1.13 In Case of an Accident	23
3.2 Caution	24
3.2.1 Storage and Transportation	24
3.2.2 Disposal	24
3.2.3 Handling Electrostatic Sensitive Devices	24
3.2.4 Traceability	24
3.2.5 Breakers	24
3.2.6 Hot Surfaces	25
Chapter 4 Installation Guide	26
4.1 Site Requirements	26
4.2 Unpacking	26
4.3 Tools	26
4.4 Cable Size	27
4.5 Mounting Power Cabinet	28
4.6 Mounting the 3U PDU (if not already installed)	30
4.7 Connecting the System Unit to the 3U PDU (if not already installed)	31
4.8 Connecting PV Cables to the PV String Combiner	32
4.9 Connecting PV String Combiner Grounding Cable	33
4.10 Connecting PV String Combiner Alarm Cable	34
4.10.1 Alarm Cable Connection for Single PV Combiner	35
4.10.2 Alarm Cable Connection for Multiple PV Combiners	35
4.11 Connecting the DC Input Distribution Unit	37

4.12	AC Input Connection.....	39
4.13	DC Load Connection.....	40
4.14	Battery Cable and Connection.....	41
4.15	DC Load Connection to 3U PDU (optional).....	42
4.16	Battery Installation.....	43
4.17	Alarm and Signal Connections.....	44
4.18	Symmetry Connection.....	46
4.19	Temperature Sensor Connection.....	47
4.20	Genset Signal and Control Cable Connection.....	48
4.21	Rectifier/Solar Converter Installation.....	49
Chapter 5 Commissioning.....		51
5.1	Commissioning Overview.....	51
5.3	Preparation.....	51
5.4	Commissioning procedure.....	52
Chapter 6 Maintenance & Troubleshooting.....		58
6.1	Maintenance.....	58
6.1.1	Checking Terminal Connection.....	58
6.1.2	Other Requirements.....	58
6.2	Troubleshooting.....	59
Chapter 7 Replacing Modules.....		61
7.1	Controller Replacement.....	61
7.2	Rectifier/Solar Converter Replacement.....	61
7.3	Battery and Load Breaker Replacement.....	61
7.4	Surge Protection Device Replacement.....	62
Appendix A.1 - System Unit Layout.....		63
Appendix A.2 - System Diagram - ACX External Board (4-relays).....		64
Appendix A.3 - System Diagram - ACX Alarm Relay Board (10-relays).....		65
Appendix B - Genset Kit.....		66

TABLES

Table 4-1	Recommended Electrical Cable Sizes.....	27
Table 5-1	Commissioning Record.....	57
Table 6-1	Connection Torque Setting Check.....	58
Table B-1	Fuel Sensor Input Connections.....	67
Table B-2	Fuel Sensor Input Connections.....	67
Table B-3	Jumper Settings.....	67
Table B-4	Alarm Input Connections.....	67
Table B-4	Alarm Output Connections.....	68
Table B-5	Genset Control and Battery Monitor Output Connections.....	68
Table B-5	Genset Control and Battery Monitor Input Connections.....	68

FIGURES

Figure 2-1	Main System Module Overview (6U configuration shown)	8
Figure 2-2	Cabinet Overview (5U system unit shown)	9
Figure 2-3	Principal of Operation	10
Figure 2-4	Guardian Rectifier	11
Figure 2-5	Solar Converter.....	12
Figure 2-6	Extended 3U PDU.....	15
Figure 2-7	DC Input Distribution Unit	16
Figure 2-8	PV String Combiner	17
Figure 2-9	PV String Combiner - Internal View	17
Figure 4-1	Cabinet Drilling Pattern.....	28
Figure 4-2	Cabinet Levelling	29
Figure 4-3	Cabinet Grounding Connection.....	29
Figure 4-4	Cable Entry (Top View).....	30
Figure 4-5	Removing the Top Cover.....	30
Figure 4-6	3U PDU Bus Bar Connections	31
Figure 4-7	3U PDU Alarm Connections	31
Figure 4-8	Connecting PV Cables.....	32
Figure 4-9	Removing PV Connectors	33
Figure 4-10	PV String Combiner Earth Grounding Connection.....	34
Figure 4-11	PV String Combiner Alarm Connections	34
Figure 4-12	Alarm Cable Connection for Single PV String Combiner	35
Figure 4-13	Alarm Cable Routing Between Multiple PV String Combiners	35
Figure 4-14	Connecting the Alarm Cable to PV String Combiner #1	36
Figure 4-15	Connecting the Alarm Cable to PV String Combiner #2	36
Figure 4-16	Extended Alarm Cable Connection between PV String Combiners	37
Figure 4-13	Direct Connection from the PV Array.....	38
Figure 4-14	Connection from the PV String Combiner	38
Figure 4-15	AC Input Terminal Block (1-phase)	39
Figure 4-16	AC Input Terminal Block (2-phase)	40
Figure 4-17	AC Input Terminal Block (3-phase)	40
Figure 4-18	DC Load Connection.....	41
Figure 4-19	Battery Cable Connection	42
Figure 4-20	DC Load Connection to 3U PDU.....	42
Figure 4-21	Battery Installation (Example only)	43
Figure 4-22	Alarm Interface.....	44
Figure 4-23	ACX External Connection Board.....	45
Figure 4-24	ACX Alarm Relay Board	46
Figure 4-25	2-block Symmetry Measurement (for illustration only).....	47
Figure 4-26	4-Block Symmetry Measurement (for illustration only).....	47
Figure 4-27	Temperature Sensor Connection	48
Figure 4-28	Genset Kit Overview	49
Figure 4-29	Genset Kit Connections.....	49
Figure 4-23	Rectifier/solar converter Installation	50
Figure 5-1	General Settings	53
Figure 5-1	Battery Settings	54
Figure 5-3	Genset Setup.....	55
Figure 5-3	Load Settings.....	56
Figure B-1	Genset Module	66
Figure B-2	Genset Connections.....	66
Figure B-6	Genset Bypass	69

1. About This Manual

This chapter contains an overview of the information that is presented in this Power System Manual. This includes information on objectives, the intended audience, and the organization of this manual. In addition, this chapter also defines the conventions used to indicate warnings, cautions and noteworthy information.

1.1 Objectives

This manual describes the Power System, explains how to unpack and install the system, how to perform the initial power-up and operational system check.

The information presented in this document is current as of the publication date.

1.2 Audience

This manual is to be used by installers and technicians who are preparing the site for a new installation and installing the power system. This manual assumes that the technician has an understanding of power systems in general and understands safety procedures for working around AC and DC voltage.

The user of this document should be familiar with electronic circuitry and wiring practices and have some expertise as an electronic, power, or electromechanical technician.

1.3 Document Key

This manual uses the following conventions:



WARNING This symbol indicates a situation that could cause bodily injury. Always be aware of hazardous conditions when working in or around the power system.



CAUTION This symbol indicates a situation that might result in equipment damage. The reader should be aware that their actions could result in equipment or data loss.



NEED MORE INFORMATION? This symbol is used to reference information either in this manual or in another document.



NOTE This symbol means the reader should take note. Notes are helpful suggestions or reminders.

Table 1-1 Abbreviations

Abbr.	Description	Abbr.	Description
ACX	Advance Controller Card	MC	Main Cabinet
ACDU	AC Distribution	MCCB	Molded Case Circuit Breaker
DC	Distribution Cabinet	MCB	Miniature circuit breaker
EC	Extension cabinet	PBC	P1 Battery Cabinet
FMD	Fan-cooled Modular Power Converter	PBDU	P1 Battery Distribution Unit
FMP	Fan-cooled Modular Power Rectifier	PCC	Prime Controller Card
GDN	Guardian system	PDU	P1 Distribution Unit
Genset	Diesel Generator	PLD	Partial load disconnection
LVD	Low voltage disconnection	SLI	SLI Inverter

1.4 Feedback & Support

Product support can be obtained using the following addresses and telephone numbers.

Corporate office:
UNIPOWER, LLC
210 N University Dr
Coral Springs, FL 33071
United States

Manufacturing facility:
UNIPOWER, LLC
65 Industrial Park Rd
Dunlap, TN 37327
United States

Manufacturing facility:
UNIPOWER Slovakia SRO
ZLATOVSKA 1279
Business Center 22
91105 Trencin, Slovakia

Phone: +1-954-346-2442

Toll Free: 1-800-440-3504

Web site – www.unipowerco.com

When contacting UNIPOWER, please be prepared to provide:

1. The product model number, spec number, S build number, and serial number
- see the equipment nameplate on the front panel
2. Your company's name and address
3. Your name and title
4. The reason for the contact
5. If there is a problem with product operation:
 - Is the problem intermittent or continuous?
 - What revision is the firmware?
 - What actions were being performed prior to the appearance of the problem?
 - What actions have been taken since the problem occurred?

1.5 Disclaimer

UNIPOWER is not responsible for system problems that are the result of installation or modification of the instructions provided in this manual.



NOTE This manual is intended to give a general guide on how to install, commission and maintain Guardian MS32 Hybrid Cabinetized DC Power System. Individual systems will vary according to exact customer requirements and any resultant additional documentation will be supplied with the system. If you are in any doubt please [contact us](#) before attempting any of the above tasks.

2.1 Overview

This chapter contains an overview of a system and a brief introduction of the modules and accessories that comprise a typical solution.

The Guardian Hybrid cabinet power system has been designed to meet the requirements of modern telecommunication with high reliability, strong flexibility and convenient maintenance. There are three different sizes of cabinet available, 1400mm x 600mm x 600mm, 1800mm x 600mm x 600mm and 2000mm X600mm x600mm.

For pure solar applications, the power system is based on the fan-cooled, hot-swappable pure solar converter module FPV30.48 with an output power up to 2.9kW. It can also be configured as a hybrid solution with AC-DC rectifier modules FMPe20.48G, FMP25.48G or FMPe30.48G which are interoperable with the solar converter module in the power system with an output power up to 2000W, 2500W or 2900W respectively. It is recommended to mount at most 5 solar converter modules in each power system. To meet different applications, the power system can be configured with one or two rectifier/solar converter shelves (each with 4 positions). The system controller used is the [HCX Advanced Hybrid Controller](#). The distribution unit is reconfigurable to meet future use. Optional accessories include a rear/top cover kit, genset kit and PV combiner module.

The power system can also includes optional units such as a 3U power distribution unit (PDU), which may be configured according to customer requirements. This PDU extends DC distribution by up to 24 circuits with 18mm MCBs. It has a maximum DC capacity of 300A.

The power system can be managed locally through messages and alarms displayed on the LCD screen of system controller, or remotely using the PC-based [PowCom™ Hybrid](#) software package.




Figure 2-1 Main System Module Overview (6U configuration shown)




Figure 2-2 Cabinet Overview (5U system unit shown)

The Guardian Hybrid MS32 is capable of delivering up to 28kW steady state power. The system is based on a combination of hot-swappable 48V solar converters and optional rectifier modules which operate in parallel with automatic load sharing.

The power system is normally configured with N+1 redundancy, with N as the number of modules necessary for feeding the load and charging the battery and 1 as the redundant module. In normal operation the modules are used to feed the load and simultaneously maintain the batteries in a fully charged state.

Upon mains input power failure and/or insufficient solar energy to run the solar converters, the modules are shut down and the batteries feed the load immediately. If the battery voltage drops below the preset level, the Low Voltage Battery Disconnection (LVBD) circuit disconnects the batteries automatically to prevent over-discharge of the battery to prolong it's life. When the mains input power is restored and/or there is sufficient solar energy, the modules will start up automatically to feed the load, close the LVBD circuit and recharge the batteries.

System performance is supervised and controlled by the HCX Advanced Hybrid controller. The DC output voltage, alarm thresholds, LVBD circuit operation, temperature compensated battery charging can be set by the controller. Any malfunction will be indicated by LED, text in the display and via operation of dry contacts. In the event of controller malfunction, basic tasks like feeding the load and charging batteries will be maintained by the modules directly at preset default values. Alarm and threshold setting of the power system can be set either through the buttons and operation menu on the local controller, or remotely through the PowCom™ Hybrid supervision software.




Figure 2-3 Principal of Operation

2.2 System Components

With the exception of the solar converter and rectifier modules the Guardian Hybrid system is delivered with all components mounted according to the ordered configuration. The main components are described below and in later chapters of this manual.

2.2.1 Rectifier Module

The fan-cooled rectifier converts the AC input to -48VDC output for loads and batteries. It is designed for parallel operation and plug-in installation in the power shelf and supplies extremely stable DC power.

Each rectifier incorporates an internal microprocessor that sends frequent updates to the system controller and adjacent rectifiers. This ensures accurately controlled load sharing among rectifiers and supplies status and identification information to the controller.

The rectifier module features two LEDs for status indication, thermal protection with power derating, and input over voltage disconnection with automatic reset. The rectifier module is hot-swappable and can be quickly removed and replaced without disrupting the system or load.




Figure 2-4 Guardian Rectifier

RECTIFIER MODEL	FMPe20.48G	FMP25.48G	FMPe30.48G
Efficiency	96%	92.5%	95%
Input Current (max)	<11.6A	<16.8A	<17.0A
Output Current (53.5V float)	37.4A	46.7A	54.2A
Output Power	2000W @ >180VAC 1100W @ <180VAC	2500W @ >180VAC 1400W @ <180VAC	2900W @ >180VAC 1700W @ <180VAC
Operating Temperature (without derating)	55°C Max.	55°C Max.	55°C Max.
Input Voltage (Nominal 100-240VAC)	90-300VAC	85-300VAC	
Output Voltage	44-57.6VDC		
Load sharing	< 5% of nominal current		
Dimensions (HxWxD)	1.6 (41) x 4.2 (107) x 14 (355) ”(mm)		
Weight	4.6lbs / 2.1kg		
Cooling	Fan-cooled, speed controlled		
Protection	Short circuit, automatic current/power limiting, input/output overvoltage, thermal		

Alarms	Fan failure, Short circuit/arcing protection, High temperature/output voltage Low output voltage, Input voltage out of range Low fan speed (warning) Internal communication failure
LED Indication	Green: AC normal operation Yellow: Steady - Low fan speed, High temperature Flashing - Communications failure Red: Module alarm / shutdown
Audible noise	<45dBA @ ≤25°C (50% load) <60dBA (100% load)

2.2.2 Solar Converter Module

Based on the global developing trend of environmental protection and energy conservation, the compact FPV30.48G 2.9kW 48VDC solar converter module is designed to provide steady DC power for loads and batteries. Maximum energy harvest from the valuable photovoltaic (PV) array is accomplished through a patented >99% Maximum Power Point Tracking (MPPT) algorithm.

The solar converter module features international standards compliance and high thermal protection; is 100% compatible with the AC-DC rectifier modules in the power system.

The solar converter provides a modular building block for Renewable Energy and Hybrid sites, accompanied by the Guardian Power System, indoor and

outdoor enclosures and PV string combiners. UNIPOWER provides a total site solution across a wide range of challenging environments.

The appearance and operating principle of solar converter modules are the same as rectifier modules.




Figure 2-5 Solar Converter

CONVERTER MODEL	FPV30.48G
Efficiency	95% peak
Input Current (max)	<17.6A
Output Current (53.5V float)	54.2A
Output Power	2900W
Operating Temperature (without derating)	65°C Max.
Input Voltage	Nominal MPPT: 160-300 V DC Minimum: 130 V DC Maximum: 360 V DC
Output Voltage	46-57.6VDC
Load sharing	< 5% of nominal current
Dimensions (HxWxD)	1.6 (41) x 4.2 (107) x 14 (355) "(mm)
Weight	4.6lbs / 2.1kg
Cooling	Fan-cooled, speed controlled
Protection	Short circuit, automatic current/power limiting, input/output overvoltage, thermal
Alarms	Fan failure, Short circuit/arcing protection, High temperature/output voltage Low output voltage, Input voltage out of range Low fan speed (warning) Internal communication failure
LED Indication	Green: AC normal operation Yellow: Steady - Low fan speed, High temperature Flashing - Communications failure Red: Module alarm / shutdown
Audible noise	<45dBA @ ≤25°C (50% load) <60dBA (100% load)

2.2.3 System Controller

The Guardian Hybrid system can be controlled by the HCX Advanced hybrid controller.

The system controller is a supervisory system with onboard software for monitoring and operation of power supply systems based on UNIPOWER modules. The design is based on the philosophy of having one main controller supervising the entire power supply system, and the use of distributed intelligence by local microcontrollers. An RS485 data bus takes care of internal communication between the various units.

USB and Web interfaces are used for remote control from a PC with PowCom™ Hybrid software, either through a direct connection of the Local Area Network (LAN) or a dial-up modem.

The description and operation of this controller is covered in a separate manual which is available at <https://www.unipowerco.com/pdf/hcx-man.pdf>.

2.2.4 Distribution Unit

The distribution unit includes configurable load breakers, battery breakers, a shunt for battery current measurement and fuse alarms for load and battery breakers.

The distribution unit has no special operation other than switching the load and battery breakers on and off. All trip states of breakers are supervised by measuring the voltage drop across each breaker.

Breakers that are not connected to any load will not cause a breaker alarm even if they are left open.

A battery fuse alarm may not be triggered instantly when a battery breaker is off. The alarm is triggered only when the voltage drop between the system voltage and the battery voltage is more than 1.5V. The interval that the voltage drop increases to 1.5V depends on the battery status.

Due to a small leakage current (2.5-3mA) through the alarm circuit, the voltage measured with a Digital Volt Meter (DVM) on an open breaker output will be nearly equal to the rectifier output voltage.

The distribution module has common “+Ve” with load breakers in “-Ve” leg. For more information see schematic drawing in Appendix A - Drawings.

2.2.4.1 Low Voltage Battery Disconnect (LVBD)

Generally, the system is equipped with low voltage battery disconnection, which prevents the batteries from deep discharging, thus prolonging the battery life. A disconnection requires a detected mains failure at the supervision unit.

If disconnection occurs, the batteries will not supply power to the load until they have been recharged to set voltage level, which can be adjusted by the user.

If disconnection occurs, the batteries will be reconnected when mains supply returns.

2.2.4.2 Partial Load Disconnection / Load Shedding (PLD)

Partial load disconnection can be configured to be voltage or time dependent, this is selected when ordering the power system.

At a mains outage the controller will open the PLD contactor when the batteries have discharged to a certain voltage or if the battery voltage has been under a certain voltage for a predetermined time. The disconnection has to be set according to the present load and battery manufacturer's discharge tables or requirements.

2.2.5 Extended 3U PDU (Optional)

The 3U PDU provides up to 24 additional MCB protected circuits for DC loads. The maximum DC capacity is 300A.




Figure 2-6 Extended 3U PDU



NOTE The 3U PDU does not increase the overall system capacity.

The 3U PDU is optionally installed in the power cabinet. For installation details, please see Chapter 4.

2.2.6 DC Input Distribution Unit

The DC Input Distribution Unit is an essential part of the Hybrid Power System for solar input. It is used as an optional kit which can generally fit in the Guardian model cabinet. It can extend the MCBs to connect at most five PV panels strings.

The DC Input Distribution Unit consists of the input MCBs for connecting five PV String Combiners at most, the Surge Protection Devices, the Ground Fault Detection device for detecting grounding failure, the output terminals and a fuse for GFD. Through the output terminals, the DC Input Distribution Unit will be connected to the FPV module of the system.

The DC Input Distribution Unit does not need special operation except for switching the breakers on and off. The auxiliary contact besides the breakers can trigger the breakers to switch off when GFD fuse fail.




Figure 2-7 DC Input Distribution Unit

INPUT

Strings	5 maximum
Voltage	100-350VDC
Current	25ADC maximum for each string

OUTPUT

Voltage	100-350VDC
Current	25ADC maximum for each string
Temperature	-40 to +55°C
Dimensions, inches (mm)	19.0 (482) H x 5.2 (132) W x 10.6 (269) D

2.2.7 PV String Combiner

The PV String combiner, as a component of the Hybrid Power System, provides multiple functions including solar energy collection, switching control and power distribution; which helps to optimize the working efficiency of the Hybrid Power System.

The PV String Combiner can connect three way PV Solar panels and multiple combiners can be connected together with the Hybrid Power System.

Two types of combiners with connector MC4/Amphenol are available to satisfy various installation requirements.




Figure 2-8 PV String Combiner




Figure 2-9 PV String Combiner - Internal View

ELETRICAL DATA

Input Voltage	100 to 300VDC
Input Current	10A
Input Strings	3 max.
MCB Current	10A
Output Current	25A max.
Surge Protection Module	VAL-MS 230 ST
Operation Temperature	-25°C ~ 75°C

MECHANICAL DATA

Dimensions, inches (mm)	11.8 (300) H x 11.8 (300) W x 5.3 (135) D
Material	Aluminum
Enclosure	IP55

2.2.8 Genset Kit (Optional)

The Genset interface board is used between the genset and controller. It provides 5KV surge protection for each input from the genset or the oil sensor. It also provides power to the oil sensor and amplifies the sense output voltage to suitable level for the controller.

Please refer to Appendix B for more details.

3.1 Safety Warnings and Guidelines

The following warnings and guidelines should be followed by properly trained and authorized personnel when installing, operating, commissioning or maintaining this equipment. Neglecting the instructions may be dangerous to personnel and equipment.

3.1.1 System Markings

The following markings are found on the Power System:

Ground Symbol



DC Ground Symbol



Product Label - The product label contains the system part number, model number, system ratings and safety approvals. The label is located inside the system.

Safety Label - The safety label is located inside the system.

3.1.2 Safety Recommendations

Any device that uses electricity requires proper guidelines to ensure safety.

- The Power System should only be installed or serviced by a qualified personnel.
- Always keep tools away from walkways and aisles. Tools present a tripping hazard in confined areas.
- Keep the system area clear and dust-free during and after the installation.
- Always know the location of emergency shut-off switches in case of an accident.
- Always wear appropriate eye protection and use appropriate tools for working with high voltage equipment.
- Do not perform any action that creates a potential hazard to other people in the system area.
- Never work alone in potentially hazardous conditions.
- Always check for possible hazards before beginning work.
- Remove watches, rings and jewelry that may present a hazard while working on the power system.

3.1.3 Installation Warning

The following safety guidelines should be observed when transporting or moving the system:

- Before moving the Power System, read the system specifications sheet to determine whether the install site meets all the size, environmental, and power requirements.
- The system should only be moved by qualified personnel and equipment.
- The Power System should be properly mounted to the building structure at the install location to prevent bodily injury.

3.1.4 Restricted Access Area Warnings

The Power System is designed for installation in locations with restricted access often secured by a locking mechanism. It can therefore be accessed only by a trained service person, who is fully aware of the restrictions applied to the location, or by an authority responsible for the location.



NOTE This may be disregarded for systems delivered in a UNIPOWER Outdoor enclosure.

3.1.5 System Enclosure

Appropriate measures need to be taken to avoid intrusion of any unwanted objects or insects into conductive areas of the power system as there is a potential risk of system damage.

Disclaimer: UNIPOWER LLC assumes no liability or responsibility for system failures resulting from inappropriate enclosure around the system.

3.1.6 Operating Temperature Warnings

To prevent the Power System from overheating, an automatic shutdown mechanism has been installed. It is not recommended to continually operate the Power System in an area that exceeds the maximum recommended operating temperature.

3.1.7 Recommended Power Ratings

Exceeding the following recommended power ratings may result in the system overheating.

- 46-57VDC, 500A at 45°C ambient
- 46-57VDC, 435A at 55°C ambient
- 46-57VDC, 350A at 65°C ambient

3.1.8 Electrical Safety Warnings

The following are electrical safety recommendations for working near the Power System:



WARNING Observe low voltage safety precautions before attempting to work on the system when power is connected. Potentially lethal voltages are present within the system.



WARNING Caution must be exercised when handling system power cables. Damage to the insulation or contact points of cables can cause contact with lethal voltages. For safety reasons, cables should be connected to the power system before power is applied.

- Remove all metallic jewelry like watches or rings that may present a hazard while working on the power system.
- Before connecting the AC input source to the power system, always verify voltage.
- Verify the AC source capacity. See system specifications for AC information.
- All AC connections must conform to local codes and regulations, e.g. ANSI, CEC, NEC, etc.
- When making AC connections, all AC power and DC load distribution breakers should be in the OFF position.
- All circuit breakers should meet the original design specifications of the system. In addition, equipment connected to the system should not overload the circuit breakers as this may have a negative effect on overcurrent protection and supply wiring, causing system or user harm.
- Verify the DC capacity before making connections. See system specifications for DC information.
- Potentially lethal voltages are present within the system. Ensure that all power supplies are completely isolated by turning all power switches OFF, disconnecting all relevant connectors and removing all relevant breakers before attempting any maintenance work. Do not rely on switches alone to isolate the power supply. Batteries should also be disconnected.
- Potentially lethal voltages are present within this system. Ensure that low voltage safety requirements are implemented before attempting to work on the system with power connected.
- Potentially lethal voltages can be induced if the equipment is not grounded (earthed) correctly. Ensure that all ground connections are secure.

3.1.9 Grounding



WARNING Grounding connection must be performed **before** operating the system. Refer to local codes, e.g. ANSI, CEC, NEC, T1-333, ETSI 300-386-TC specifying the connection of power system to building ground. In case of any doubt regarding the grounding connection, please contact a person responsible for the system.



WARNING The system should be hard-wired to the incoming earth ground. A solid high current ground connection capable of sinking the maximum system current is required.



CAUTION A conductor is connected between the ground point and the 0 VDC bus bar on the PBDU distribution. This conductor is connected to its own earth bar and not shared with other safety conductors.

3.1.10 Batteries



WARNING When installing or replacing batteries, there is risk of explosion if an incorrect battery type is used.

3.1.10.1 Lead Acid Batteries



WARNING This equipment may use Lead Acid Batteries. When handling batteries, follow the instructions included with the battery set, as the fluids contained within these batteries are known to be a health hazard. The disposal of lead acid batteries is subject to legal requirements for hazardous waste disposal. Local guidelines should be followed for disposal.

Ensure the following guidelines are observed when dealing with equipment that may contain lead acid batteries:

- Any attempt to burn these batteries may result in an explosion and the generation of toxic fumes.
- Should a lead acid battery suffer damage, it must be moved into a well-ventilated area. Contact with the corrosive fluid must be avoided.
- Neutralize any acid corrosion with copious amounts of a solution of baking soda and water, and then wipe off all traces of soda.
- If the lead acid battery is removed from the equipment, any exposed contact must be insulated prior to disposal.
- Ensure that protective full-face shields, rubber gloves and aprons are worn and insulated tools are used when working with the batteries. It is advised also to have water available in case acid gets in contact with the eyes.

3.1.11 PV Modules and Arrays

The following safety precautions should be taken into consideration when installing PV modules:

- All electrical installations must be done in accordance with the local and national electrical codes.
- Solar modules produce electrical energy when exposed to sunlight.



WARNING There is a risk of electric shock since the voltage generated by PV modules is higher than the system nominal voltage. Module installation should be performed only by a qualified person.

- It is required that PV arrays installed on the roof must incorporate a ground-fault protection device to detect an electrical short circuit which could result in fire.



WARNING The GFD does not ensure personal safety, it is a device for system protection only.

- It is essential that PV installer is familiar with fall protection regulations. Any work done at more than six feet above the ground must be done with fall protection considerations.

3.1.12 Generator

Generator connections must be carried out by a trained electrician in accordance with applicable codes.

- To eliminate unexpected startup and possible electric shock, ensure that Automatic Genset Starting is disabled before servicing the Genset.
- Keep hands away from moving parts.
- Do not operate a diesel operated generator where there can be flammable vapours created by fuel spills or gas leaks.
- Do not smoke or turn electrical switches ON/OFF when fuel fumes are present - diesel fuel is combustible.
- Do not store fuel containers in the same enclosure as other spark-producing equipment (e.g. Batteries).

3.1.13 In Case of an Accident


In the event of an accident resulting in injury:

1. Use caution and check for hazards in the area.
2. Disconnect power to the system.


3. If possible, send someone to get medical aid. If not, check the condition of the victim and call for help.

3.2 Caution


3.2.1 Storage and Transportation

 **CAUTION** During storage and transportation, the units must remain in their original packages in order to avoid mechanical damage, maintain tracability, and protect the units against electrostatic discharge.


3.2.2 Disposal

 **CAUTION** The product should not be disposed with other wastes at the end of its working life so as to prevent possible harm to the environment or human health from uncontrolled waste disposal.

3.2.3 Handling Electrostatic Sensitive Devices

 **CAUTION** An electrostatic sensitive device is an electronic component that may be permanently damaged by the discharge of electrostatic charges encountered in routine handling, testing and transportation.

3.2.4 Traceability

 **CAUTION** Units are labeled with permanently attached product identification labels. The labels are designed to be indelible throughout the life span of the equipment, unless mistreated. Make sure that the product identification labels are present on the equipment and are not subjected to unusual wear or mistreatment.

3.2.5 Breakers

Maximum 45°C operating ambient:

1. Up to 32A CB maximum load must not exceed 80% of it's rating.
2. 40A CB maximum load shall not exceed 30A.
3. 50-63A CB maximum load shall not exceed 35A.

Maximum 55°C operating ambient:

1. Up to 20A CB maximum load must not exceed 80% of it's rating
2. 25A to 63A CB maximum load must not exceed 60% of it's rating.

Maximum 65°C operating ambient:

1. Up to 20A CB maximum load must not exceed 80% of it's rating
2. 25A to 63A CB maximum load must not exceed 50% of it's rating.



CAUTION Breakers should always be replaced with the same type and rating in order to avoid damage to system components.

3.2.6 Hot Surfaces



CAUTION Areas of the Power System may become hot. Take precautions and handle with care to avoid bodily harm.



WARNING There are potential hazards related to installing this power system. It is important to carefully read and understand the contents of the Safety chapter before performing system installation.



CAUTION Make sure sufficient room is left around the system to enable optimal air circulation and thus prevent the system from overheating. Keep vent openings from blocking.

The following information should be read before attempting to install the Power System.

4.1 Site Requirements

The site should be suitable and ready for the Power supply. If it is not or you are unsure about this, contact your supervisor before continuing. Check, using a spirit level, that the site is level. Adjustment is provided in the cabinet to cater for floors that are not flat or smooth.

4.2 Unpacking

Check that the received equipment is in accordance with the packing list. Ensure that the cabinet and the equipment have not been damaged during transportation.

Report any parts that are damaged, missing or incorrect. If possible, correct the problem before continuing.

4.3 Tools

The following tools are required for a safe installation of the system:

- Anti-static hand strap.
- Socket wrench, insulated.
- Screwdriver set, flat, insulated.
- Screwdriver set, torx, insulated.
- Screwdrivers, pozidrive (cross head), sizes 1, 2, and 3, insulated.
- Torque spanner (for battery connection), insulated.



WARNING Use only single-ended, fully insulated tools. Shafts of screwdrivers etc. should be insulated.



CAUTION Installation in USA / Canada must conform with the requirements in NEC/CEC.



CAUTION Care must be taken when installing this system. The units can be damaged and can cause damage if not handled with care. Pay particular attention to the order in which units are installed.

4.4 Cable Size

Please use the recommended cable size given below for the system installation.

Port	Current Max.	Cable Size Min.(mm ²)	Cable Size Min.(AWG)	Temperature Rating
AC Input -L1	72A	16mm ²	4 AWG	105°C
AC Input -L2	54A	10mm ²	6 AWG	105°C
AC Input -L3	54A	10mm ²	6 AWG	105°C
AC Input -N	72A	10mm ²	4 AWG	105°C
AC Input -PE	-	10mm ²	7 AWG	105°C
Battery MCB	80A	25mm ²	2 AWG	105°C
Battery MCB	100A	35mm ²	1 AWG	105°C
Battery MCB	125A	50mm ²	0 AWG	105°C
DC Load -MCB	63A	16mm ²	5 AWG	105°C
DC Load -MCB	50A	14mm ²	6 AWG	105°C
DC Load -MCB	40A	10mm ²	7AWG	105°C
DC Load -MCB	32A	8mm ²	8 AWG	105°C
DC Load -MCB	25A	8mm ²	8 AWG	105°C
DC Load -MCB	20A	6mm ²	9 AWG	105°C
DC Load -MCB	16A	4mm ²	10 AWG	105°C
DC Load -MCB	10A	2.5mm ²	14 AWG	105°C
DC Load -MCB	6A	2.5mm ²	14 AWG	105°C
DC Load -MCB	4A	1.5mm ²	15 AWG	105°C
DC Load -MCB	2A	1.5mm ²	15 AWG	105°C

Table 4-1 Recommended Electrical Cable Sizes

4.5 Mounting Power Cabinet

1. The site should be suitable and ready for the Power system.
2. Move the cabinet to the right place and lift into an upright position.
3. If necessary the cabinet can be mounted to the concrete slab and existing structures to properly support the floor loading. In addition, the mounting site needs to be designed and installed in accordance with local building codes and regulations.
4. Mark the position of the four fastening bolts on the floor according to the Figure 4-1.




Figure 4-1 Cabinet Drilling Pattern

5. To mount the cabinet in a level position use a screwdriver to adjust the four feet and a spirit level to verify.




Figure 4-2 Cabinet Levelling



CAUTION The Earth Grounding connection must be before connecting supply.



NOTE The internal earth cable is connected between the positive DC busbar and the cabinet.

6. Connect the grounding cable with a minimum cross sectional area of 16mm² between the earth grounding point at the top-rear of the cabinet and the Main Earth Terminal (MET). See Figure 4-3.
7. Tighten the cable connection to a torque of 10Nm.




Figure 4-3 Cabinet Grounding Connection

8. Cable entry is provided through a series of holes at the top/rear of the cabinet.




Figure 4-4 Cable Entry (Top View)

4.6 Mounting the 3U PDU (if not already installed)

The mounting position of the 3U PDU is determined by the size and mechanical configuration of the cabinet. It should be fastened to the cabinet with four M6x12mm screws.




Figure 4-5 Removing the Top Cover



NOTE The 19"/23" adaptor bracket actually used may differ from the one shown.

4.7 Connecting the System Unit to the 3U PDU (if not already installed)

1. Turn off the AC input before installation.
2. Connect the DC parallel cable lugs to the positive and negative bus bars with two M8 x 20mm screws (Figure 4-6).




Figure 4-6 3U PDU Bus Bar Connections

3. Connect the external PDU load breaker alarm cable to the J1-pin2 or J3-pin2 terminal on the fuse alarm board in the system unit (Figure 4-7).




Figure 4-7 3U PDU Alarm Connections

4.8 Connecting PV Cables to the PV String Combiner



NOTE This section is only applicable when using the PV String Combiner.

The PV String Combiner with MC4/Amphenol includes the following cable entry terminals:

- Input connectors terminal including three male PV connector terminals (PV+) and three female PV connector terminals (PV-).
- Output connector terminal including a male PV Connector terminal and a female PV Connector (PV-).
- Grounding cable entry and Alarm cable entry.

The internal cable connections of the combiner are carried out at the factory. Installers only need to make the external cable connection as described below:

1. Ensure that all the load MCBs are in the OFF position.
2. Connect the connectors with red cables to the male PV (+) connector terminals.
3. Connect the connectors with black cables to the female PV (-) connector terminals.
4. Ensure that the connectors are tightly clamped to the terminals.




Figure 4-8 Connecting PV Cables



NOTE The PV Combiner may be supplied with the mating part of the MC/Amphenol connectors already installed. In such case it may be necessary to use an open ended spanner or similar tool to remove them as described below. Such tools are not provided with the unit.

1. Insert the spanner into the holes in the body of the connector, fig. 4-9 step 1.
2. Pull the connector out to remove the connector, fig. 4-9 step 2.




Figure 4-9 Removing PV Connectors

4.9 Connecting PV String Combiner Grounding Cable



NOTE This section is only applicable when using the PV String Combiner.

To connect the grounding cable, follow the steps as below:

1. Ensure that all the load MCBs are in the OFF position.
2. Route the grounding cable to the Earth Grounding Terminal through the grounding cable gland.
3. Insert the grounding cable into the opening of the Earth Grounding Terminal.
4. Tighten the cable to the Earth Grounding Terminal.




Figure 4-10 PV String Combiner Earth Grounding Connection

4.10 Connecting PV String Combiner Alarm Cable



NOTE This section is only applicable when using the PV String Combiner.

The PV String Combiner supports two optional alarm cable connecting methods:

- Independent cable connection for single combiner.
- Extended cable connection between multiple combiners.

The terminal block provides six terminals for connecting the alarm cable, the following figure displays the labelled terminals:




Figure 4-11 PV String Combiner Alarm Connections

4.10.1 Alarm Cable Connection for Single PV Combiner

The alarm cable consists of three wires respectively labeled as PVSF, +Vsys, PVDA which need to be connected to the corresponding labelled terminals of Alarm Terminal Block.

Follow the steps as below to connect the alarm cable for a single combiner (Figure 4-12):

1. Route the alarm cable to the alarm terminal block through the alarm cable gland.
2. Connect the labelled wires orderly to the corresponding terminals respectively labelled as PVSF, +Vsys, PVDA according to Figure 8.
The labelled wires must match the labelled terminals.
3. Tighten the wires to the terminals by turning the screwdriver clockwise.
4. Connect the alarm cable to the system.




Figure 4-12 Alarm Cable Connection for Single PV String Combiner

4.10.2 Alarm Cable Connection for Multiple PV Combiners

When multiple combiners need to be connected, the alarm cables should be connected between combiners. The following figure shows the alarm cable routing between multiple combiners. N is the number of the combiners required for the system.




Figure 4-13 Alarm Cable Routing Between Multiple PV String Combiners

The following assumes that two combiners (Combiner 1 and Combiner 2) need to be connected, follow the steps as below to connect alarm cables between the two combiners:

1. Route the alarm cable to the alarm terminal blocks through the alarm cable gland.
2. Connect the labelled wires to the corresponding terminals respectively labelled as PVSF, +Vsys, PVDA of the Combiner 1 (Figure 4-14).




Figure 4-14 Connecting the Alarm Cable to PV String Combiner #1

3. Connect the other end of wires orderly to the terminals respectively labelled as PVSF, +Vsys, PVDA of the Combiner 2 (Figure 4-15).




Figure 4-15 Connecting the Alarm Cable to PV String Combiner #2

4. Tighten the wires to the alarm terminal blocks by turning the screw driver clockwise.

5. Complete the extended alarm cable connection between the alarm terminal blocks of the two combiners (Figure 4-16).




Figure 4-16 Extended Alarm Cable Connection between PV String Combiners

Repeat steps 1 to 6 if alarm cables for additional combiners.

4.11 Connecting the DC Input Distribution Unit

Depending on the installation configuration, connection to the DC Input Distribution Unit can be made either from up to 5 PV strings or PV String Combiners.

Remove the front door of the DC Input Distribution Unit to connect the input PV cables. Follow the steps below to connect the input to the input MCBs of the DC Input Distribution Unit.

1. Check that all the MCBs are in the OFF position.
2. Connect the negative (PV-) output cable from the panel or string combiner to the corresponding negative (-) terminal of the breaker. Insert the stripped cable into the opening on top of the breaker and tighten the screw.
3. Connect the positive (PV+) output cables from the panel or string combiner to the corresponding positive (+) terminal of the breaker. Insert the stripped cable into the opening on top of the breaker and tighten the screw.




Figure 4-13 Direct Connection from the PV Array




Figure 4-14 Connection from the PV String Combiner

4. Using minimum 9AWG cable, connect each positive (PV+) output terminal on the DC Input Distribution Panel to the corresponding positive (+) input terminal on the rectifier/ Solar Converter shelf.
5. Using minimum 9AWG cable, connect each negative (PV-) output terminal on the DC Input Distribution Panel to the corresponding negative (-) input terminal on the rectifier/ Solar Converter shelf.



WARNING For personnel safety, the DC Input Distribution Unit must be electronically disconnected while connecting cables. Use suitable tools to tighten the cables.



WARNING While connecting the PV cables to the DC Input Distribution Unit, the MCBs of the PV String Combiner must be in the OFF position.

4.12 AC Input Connection



NOTE This section is only applicable when using a Genset or utility supply and connecting AC power.



WARNING Ensure that mains input is turned off before connecting. The grounding must be connected to PE terminal as first.



WARNING High leakage current. Ensure earth is connected before connecting mains supply.



WARNING Only a qualified electrician may carry out the mains installation.



CAUTION Depending on deployment region with regards to lightning strikes and heavy inductive energy, it is highly recommended to install AC Surge Protection Class C, if not delivered with the system..



WARNING Used cable must be inserted into the terminal with as little insulation removed as possible, so as to prevent any stranded conductor coming loose and touching any other conductive parts. Tighten terminals securely with torque 1.5-1.8Nm.

Mains input terminal blocks are located on the rear left side of distribution unit. Mains cable size is max. 16mm².

The mains input terminal blocks can be connected to:

- 1-phase 110VAC or 230VAC (Figure 4-15)
- 2-phase 240VAC - N.A./CALA (Figure 4-16)
- 3-phase 208/230/400VAC (Figure 4-17).

single phase 120/230VAC




Figure 4-15 AC Input Terminal Block (1-phase)

2-phase 240VAC (N.A. / CALA)





Figure 4-16 AC Input Terminal Block (2-phase)

3-phase 208/230VAC
(Δ connection)



3-phase 400VAC
(Y connection)




Figure 4-17 AC Input Terminal Block (3-phase)

Recommended mains breaker:

Three pole 3 x 80A C-characteristic

Three pole 3 x 63A D-characteristic

4.13 DC Load Connection

This section details how to connect the loads to the DC load breakers. Use suitably sized cables according to Table 4-1 on page 25.

Check that all the MCB's are in the OFF position.

1. Connect the negative (-) DC supply cable to the appropriate negative DC distribution MCB by inserting the stripped cable in the opening on top of the MCB and tightening the screw. Make sure that the cable has the correct rating for the selected MCB.
2. Connect the positive (+) DC supply cable directly to the positive bus bar by inserting the stripped cable to the hole on top of the screw connector so that the cable is behind the bus bar, and then tightening the screw. Start connecting the loads to the bus bar from the first connector on the left. Make sure, the cable is the correct rating for the load. Check, that all the cables are secured tightly to the connectors.

Use Torque table in the Maintenance and Troubleshooting Chapter for the correct torque.




Figure 4-18 DC Load Connection

4.14 Battery Cable and Connection

If ordered, battery cables are pre-connected to the system battery breakers. If not, use suitably rated cable size (see Table 4-1 on page 25) and follow steps 1 to 4 below.

Battery Connection Points on the PBDU and Battery Distribution are shown in Figure 4-19.

1. Check that all the battery MCBs are in the OFF position.
2. Connect the “+” cable of each battery string to the positive bus bar of the system. Tighten the cable terminal to 3.0Nm.
3. Connect the “-” cable of each battery string to the battery circuit breaker. The copper bar with washer and nut installed on the circuit breaker is used to connect and tighten the battery cable lug.
4. Connect the other ends of the battery cables to the “-” and “+” terminals of the batteries as described in section 4.16.

Use Torque table in the Maintenance and Troubleshooting Chapter for the correct torque.




Figure 4-19 Battery Cable Connection



NOTE Figures 4-18 and 4-19 show a configuration with two battery breakers installed.

4.15 DC Load Connection to 3U PDU (optional)

After opening the front door of the 3U PDU, follow the same steps as described in section 4.13 to make these addition DC load connections.




Figure 4-20 DC Load Connection to 3U PDU

4.16 Battery Installation

The batteries should be handled according to the battery manufacturer's recommendations. When placed into the cabinet, the recommended distance of 5-15mm between the battery blocks should be adhered to to ensure proper ventilation.

1. Attach interblock connections between the battery blocks (Figure 4-21, Detail 1).
2. Connect the negative “-” cable to the negative pole of the battery string (Figure 4-21, Detail 2). Tighten the connection to a torque of 5-6Nm.
3. Connect the positive “+” cable to the positive pole of the battery string (Figure 4-21, Detail 3). Tighten the screw to 5-6Nm.
4. Attach plastic pole protection caps to the battery poles (Figure 4-21, Detail 4).

Repeat steps 1 to 4 to connect the battery cables to the remaining battery strings.



NOTE The battery installation procedure is an example and may vary depending on the battery type.




Figure 4-21 Battery Installation (Example only)

4.17 Alarm and Signal Connections

Alarm connections are positioned on the right side of the PBDU on the Alarm interface board, see Figure 4-22. To connect the alarm cable to the alarm interface board, follow the steps below:

1. Remove the green plug from each connector (Figure 4-22, #1)
2. Determine whether to reference normally closed or normally open with reference to common for each alarm contact.
3. Strip the wires back approximately 10mm. Stranded wire may be soldered or covered with copper ferrule if desired.
4. Insert wire into the openings of green plug and tighten screw to clamp wire (Figure 4-22, #2).
5. Re-insert the green plug with alarm cable into the alarm interface board (Figure 4-22, #3).




Figure 4-22 Alarm Interface

There are two kinds of alarm interface board for selection to meet the user's requirement.

ACX External Connection Board: Select this if the ACX internal communication board is selected and a maximum of 4 alarm relay outputs are required. (Figure 4-23)

ACX Alarm Relay Board: Select this if the ACX internal communication board is selected and 5 - 10 alarm relay outputs are required. (Figure 4-24)

Alarm connections are Form C relays and can be monitored either Normally Closed (NC) or Normally Opened (NO). When the power is OFF, NC is closed and when the power is ON, the NC is open.



NOTE Relays K1 - K6 (Alarm 5 - Alarm 10) on the Alarm Relay Board are set to the alarm position if communication with the controller (due to a malfunction or being pulled out) is lost for more than 7 minutes. (This function is available only for Alarm Relay Board firmware version 1.2 or later.)



NOTE The alarm configuration will be dependent on your system configuration.




Figure 4-23 ACX External Connection Board




Figure 4-24 ACX Alarm Relay Board



NEED MORE INFORMATION? For detailed information regarding Alarm connection see Appendix A, Installation Drawing.

4.18 Symmetry Connection

The ACX controller can supervise 4-block symmetry measurements on 4 battery branches. If the PCC controller is used, only 2 battery branches can be measured on 4 blocks.



NOTE Symmetry cables are pre-connected to the system.



NOTE Multi Purpose inputs which are not used for symmetry measurement can be reconfigured to user defined analog inputs.

1. Insert a suitably sized cable lug into one pole of the inter-block connection plate. Fasten the lugs and plates to individual battery poles.
2. For 2-block battery symmetry measurement fix one wire of the symmetry cable to the cable lug in the mid-point of the battery string, see Figure 4-25.




Figure 4-25 2-block Symmetry Measurement (for illustration only)

For 4-block measurement fix the 3 wires (red, green and blue) of the symmetry cable to individual cable lugs. Color coding of the cables must be followed for proper symmetry measurement, see Figure 4-26.




Figure 4-26 4-Block Symmetry Measurement (for illustration only)



NOTE The interblock Connection Kit is not delivered with the system.

4.19 Temperature Sensor Connection



NOTE The power system is usually delivered with pre-connected temperature sensor cables. If not, use a three-pin plug and connect according to the [Appendix A - Installation Details](#).

Battery Temperature

Temperature sensor 1 measures the temperature of the battery bank while the controller adjusts the float charge voltage according to the temperature compensation factor set in the controller. This factor must be set in the controller according to the battery manufacturer's recommendations.

Fasten the temperature sensor in the middle of the battery bank, Figure 4-27.




Figure 4-27 Temperature Sensor Connection



NOTE The temperature compensation factor can be set only for temperature sensor 1.

Ambient Temperature

Temperature sensor 2 allows a second temperature reading, most commonly the ambient temperature around the system. Place the sensor as required.

The temperature is displayed in the External Measurements menu in the ACX controller or in PowCom™ software.



NOTE Temperature sensor 2 can be activated only in the systems with the ACX controller installed.

4.20 Genset Signal and Control Cable Connection



NOTE This section is only applicable when using the Genset Kit and connecting AC power from a generator.

For correct the operation of the power system, it is important to connect the signal cables for Genset control.

Connect the signal and control cables from the generator to J1, J3 and J6 terminal of Genset Kit. Refer to figures below for details.




Figure 4-28 Genset Kit Overview




Figure 4-29 Genset Kit Connections



NEED MORE INFORMATION? Refer to [Appendix B](#) for more information about the Genset Kit.

4.21 Rectifier/Solar Converter Installation



NOTE Ensure that the rectifier/solar converter handle is in the OPEN position (forms 35-40° angle with rectifier body) before inserting the module into the slot.

The rectifier/solar converter module should be installed starting from the left position in the rectifier/solar converter shelf.

1. Place the rectifier/solar converter module in the desired slot with the handle facing out.
2. Slide the rectifier/solar converter module into the slot until it contacts the interface connection at the rear of the shelf, Figure 4-30 #1.

3. Fully insert the rectifier/solar converter by pushing the handle towards the shelf. The rectifier/solar converter handle will rise up and lock the rectifier/solar converter into the position, Figure 4-30 #2.

Repeat steps 1 to 3 for the remaining rectifier/solar converter modules.




Figure 4-23 Rectifier/solar converter Installation



NOTE When all connections have been completed and checked refit all covers and close and lock access doors/panels.

5.1 Commissioning Overview

This chapter is a step-by-step guide to initial set-up and operation of the Hybrid Power System (Genset + Solar) with HCX Advanced controller.

Some commissioning steps are not applicable with the following applications:

Off-Grid or Unreliable Grid with Battery cycling management:

- Cyclic (Genset only with HCC Lite controller supervision)
- Pure Solar

On-Grid with Battery in Standby mode:

- Solar Enhanced

For details refer to the final Commissioning checklist record.



CAUTION Before starting the system commissioning read the Instruction Manual carefully.



WARNING Only experienced electrician with necessary experience, knowledge and understanding of Hybrid Power Systems may perform the system commissioning. It is important to follow all local and national electrical codes, safety regulations and instructions in this manual.

5.2 Essential Tools and Test Equipment

- Laptop with PowCom™ Hybrid software installed
- Multimeter (3½ Digit, 0–1% DC)
- Screwdrivers (Torx 30, Flat 5.5)



NOTE The PowCom™ Hybrid software installer and manual can be downloaded from the UNIPOWER web site: [PowCom™ Hybrid installer](#) | [PowCom™ Hybrid Manual](#)

5.3 Preparation

Check the installation to ensure the following:

- Grounding: The equipment is correctly grounded. The grounding cable size, color and routing conform to the requirements.
- Power: The incoming mains AC power is available for this site. The site power switch and circuit breakers are clearly labeled. The power cables are correctly terminated.
- The site is clean and safe. Check that the system/cabinet is free of any unwanted objects or insects that may have got in during the installation.

5.4 Commissioning procedure

The checkpoints are to be considered as a minimum for commissioning of the system.



WARNING Do not continue if any faults occur during the commissioning process. In such circumstances contact UNIPOWER for assistance if you cannot locate the problem yourself.

1. Ensure that all system components have been properly connected according to the Installation Guide, section 4, and manufacturers' instructions. Check that all wiring connections have been made properly and that all required parts are properly grounded.
2. Ensure that load, battery, AC Input and PV breakers are in the OFF position and all modules (rectifiers/solar converters) are removed.
3. Switch the Generator (Genset) to Remote Operation and turn the AC Input breaker ON. (Consult Genset manufacturer documentation for details.)
4. Switch ON the Battery breakers. The HCX controller starts up from the batteries (the green LED on the HCX front panel is blinking).
5. The Generator starts operating after the HCX controller closes the Genset control relay. Check if the HCX controller displays the message "Genset ON".
6. Measure the AC voltage on the AC Input terminal block, between phases and neutral. The correct value is approximately 230V. If the value is different, check the AC connection and/or Generator settings (voltage and frequency).
7. Switch ON the breakers in the PV String Combiner (if installed). Measure the DC voltage on input of PV breakers (130-360VDC), the voltage depends on the solar irradiance.
8. Insert all the modules (rectifiers/solar converters) into the correct positions. Switch the PV breakers ON.

The modules will turn ON automatically. It will take a minute to step up the correct voltage value.

9. Switch all Load breakers ON. Measure the DC voltage on the breakers, refer to U2.



NOTE The system is now operating according to the factory configuration settings.

10. Connect the PC with PowCom™ Hybrid software to the system using a USB cable. PowCom™ Hybrid software is a mandatory tool for correct setting of all system parameters.
11. Check if the HCX controller settings correspond with the installed configuration. If different settings are needed follow the steps below to setup the required configuration.

To set the system parameters in the PowCom Hybrid software select:
Utilities → Modify Configuration → Config Wizard-1.




NOTE The following settings are available for PowCom™ Hybrid licence level 30 and higher. Contact UNIPOWER to obtain an appropriate license.

General Settings

Set *Physical Location* (1) and *Time Zone* (2) accurately, Figure 5-1. This is accessible only with the HCX controller and necessary for optimal PV array operation.

Set the *Output Power Limit* (3). This value refers to the maximum input power of all installed rectifiers. At the same time, the limit must be lower than the maximum output power of the GenSet.



The screenshot shows the 'Config Wizard - 1' window with the 'General Settings' tab selected. The 'Physical Location' section (1) includes fields for Latitude (48° 57'), Longitude (18° 11'), and Time Zone (1 h). The 'System' section (3) includes the 'Output Power Limit' set to 8.0 kW. The 'Networking' section shows Network Address (1), Default Password (xxxx), and Baud Rate (38400). The 'General Configurations' section has checkboxes for 'Inverted load fuse alarm' and 'Rectifier On/Off manually allowed'. The 'Device Addressing' section shows a table for Rectifiers, FMD DC/DCs, FPV DC/DCs, and SLI DC/ACs.

	Begin	End
Rectifiers	1	1
FMD DC/DCs	6	64
FPV DC/DCs	0	0
FPW DC/DCs	0	0
SLI DC/ACs	73	90

Figure 5-1 General Settings

When the rectifiers are distributed unevenly per phase (e.g. two rectifiers per phase L1, one per phase L2 and L3), one phase may be overloaded even though the set power limit is below maximum GenSet Power.

Example:

Genset with max. power 11kW has a limit 16A/230V per phase. With 4 rectifiers installed, two rectifiers are fed from phase L1, one from phase L2 and one from phase L3. With the Power limit set to 9kW the set maximum power is below the maximum Genset power (with efficiency considered), yet phase L1 is overloaded (the current of phase L1 is over 21A).



CAUTION It is essential that *Output Power Limit* is set correctly to protect the Generator from overloading and consequent damage.



NOTE For Pure Solar and Solar Enhanced applications (Genset not used), set the *Output Power Limit* to 0kW.

Battery Settings

Select the Battery tab, Figure 5-2.

Make sure the correct *Battery Type* (1) is chosen from the scroll list, otherwise the system will not operate properly.

Set the number of battery *Strings in Parallel* (2).




Figure 5-1 Battery Settings



NOTE If the installed batteries are not listed in the PowCom Battery file, please contact UNIPOWER Customer Support.



WARNING The selected battery type must always exactly match the batteries that are installed.

Genset Setup

Select the *Fuel Tank Form* and insert the correct fuel tank volume dimensions (1).

Set the *Genset Fuel Low Alarm Level* (2)

Set the *Fuel Sensor* values (3):

Offset S0 [m] - minimum height for fuel sensor measurement

Length S1 [m] - the height range for fuel sensor measurement

Minimum Voltage [V] -set the minimum *Fuel Low Alarm Level* voltage value

Maximum Voltage [V] - se the maximum *Fuel Low Alarm Level* voltage value

Set the *Genset Alarm Logic* (4)




Figure 5-3 Genset Setup



NOTE For Pure Solar and Solar Enhanced applications (Genset not used), in *Fuel Tank Form* field set to: **Not Available**.

Also certain Alarms (40-45) are factory disabled for applications without a Genset. If not, please contact UNIPOWER Customer Support.

Load Settings

Fill in the value of *Average Load Current* (1) powered by the system, Figure 5-4. This value is important for optimal battery cycling.




Figure 5-3 Load Settings

12. Read the symmetry measurement and check the values with battery manufacturer recommendations. Check the symmetry alarm by pulling out one symmetry cable from the battery string.
13. Check the battery temperature and ambient temperature (if used).
14. Access the HCX display menu: *Miscellaneous* → *Maintenance Mode*: set Maintenance ON and Genset OFF. It takes some time for the Generator to respond. Check if the Generator is turned OFF.
15. Switch OFF all breakers in the following order:
 - PV breakers
 - Battery breakers
 - Load breakers
 - AC Input breaker
16. Attach all the system covers correctly and clean the site.
17. Fill in the commissioning record.

		Checked (✓) / Result
1	System installation	
2	All breakers OFF	
3	Generator set to Remote Control **/ ***	
4	HCX controller starts up	
5	Generator starts up **/ ***	
6	AC voltage measurement **	L1-N:VAC L2-N:VAC L3-N:VAC
7	PV array voltage measurement *	PV 1:VDC PV 2:VDC PV 3:VDC PV 4:VDC PV 5:VDC
8	Modules ON	
9	DC output voltage measurement	U2:VDC
10	Communication with PC	
11	Controller setup Battery settings Geneset setup ** Load settings	
12	Symmetry measurement	Batt. 1:VDC/VDC Batt. 2:VDC/VDC Batt. 3:VDC/VDC Batt. 4:VDC/VDC Batt. 5:VDC/VDC Batt. 6:VDC/VDC
13	Temperature measurement	
14	Generator OFF **/ ***	
15	All breakers OFF	
16	System covers fitted	

Not applicable for: * Cyclic System, ** Pure Solar System, *** Solar Enhanced System

Table 5-1 Commissioning Record

6.1 Maintenance

6.1.1 Checking Terminal Connection

The connections on the terminal blocks and circuit breakers must be checked according to the Table 6-1 at least once a year.

TYPE OF CONNECTION	MODEL / DESCRIPTION	TORQUE (Nm)	TORQUE (Inch LB)
Terminal block for rail	AKG 16mm ²	2.5	22
Terminal block for rail	AKG 35mm ²	3.5	31
Front terminal for copper cables	FC Cu T2 95mm ²	7.0	62
Terminal block Weidemullers	WDU 4mm	0.6	5
Terminal block Weidemullers	WDU 10mm	2.0	18
Terminal block Weidemullers	WDU 16mm	3.0	27
Miniature circuit breaker	Siemens	2.5	22
Miniature circuit breaker	Merlin G	3.5	31
Miniature circuit breaker	ABB	2.0	18
Miniature circuit breaker	CBI HY-MAG	3.0	27
Molded case circuit breaker	ABB 160A - S2	5.0	45
Molded case circuit breaker	ABB 160A/250A - S3/S4	9.0	80
Molded case circuit breaker	ABB 630A - S6	9.0	80
Molded case circuit breaker	Terasaki - XS125CJ	9.0	80
Connection unit for 2 or 3 pole breaker	Merlin G & Siemens	13.5	120
Terminal Block Phoenix	Phoenix Mini Combicon	0.25	2
Terminal block Phoenix	UK10 / UKLKG10	1.5-1.8	13-16
Terminal block Phoenix	UK16 / USLKG16	1.5-1.8	13-16
Terminal block Phoenix	UK35/UIK35/USKG35/UISKG35	3.2-3.7	28-33
Miniature circuit breaker	Nader	2.5	22

Table 6-1 Connection Torque Setting Check

6.1.2 Other Requirements

At least once a year the output voltage should be verified to be within acceptable limits. The result of the test should be recorded and filed to see any deviations.

In addition, the system requires periodic inspections and routine cleaning. It is very important to keep the all areas and components of the system free from dust or other unwanted objects to ensure free air circulation and safe operation of the system.

6.2 Troubleshooting

This guide is a step-by-step recommendation of what to do if problems occur. If the first step of the recommendation does not solve the problem continue to the next one. If the problem cannot be solved please contact UNIPOWER for assistance.

NOTE For a description of Alarms and Messages generated by the system controller see the Alarms/Messages section of the appropriate controller manual:



HCX Advanced: <https://www.unipowerco.com/pdf/hcx-man.pdf>

By default, alarms are set to be indicated with a red light (higher priority) and messages with a yellow light (lower priority).

Fault	Suggestion/Solution
Low System Voltage	<p>Check the batteries with a voltmeter.</p> <p>Check the <i>low volt alarm</i> limit in the controller or via the PowCom™ Hybrid software.</p> <p>Check that the system is not in battery test mode.</p> <p>Check the rectifier/solar converter modules, input and load conditions compared to rectifier/solar converter capacity.</p>
High System Voltage	<p>Check the batteries with a voltmeter.</p> <p>Check the <i>high volt alarm</i> limit in the controller or via the PowCom™ Hybrid software.</p> <p>Check that the system is not in <i>boost/Charge mode</i>.</p>
Mains Error	<p>Check the mains breakers.</p> <p>Check the mains voltage.</p>
AC Low Voltage	
AC High Voltage	
Module Failure	<p>Localise the failed rectifier/solar converter module.</p> <p>Remove the failed rectifier/solar converter.</p> <p>Wait for 30 sec. and reinstall it.</p>
Urgent Module Failure	See <i>Module failure</i> above.
High Load	<p>Check load in relation to the capacity of the system.</p> <p>Increase the number of rectifier/solar converter modules.</p>

Fault	Suggestion/Solution
Load/Battery Disconnection	<p>Verify that the input supply is present.</p> <p>Check the system DC voltage with voltmeter.</p> <p>Compare the system DC voltage with the disconnected thresholds in the controller or via the PowCom™ Hybrid software.</p> <p>If a breaker trips repeatedly, there is probably either excessive load or a short circuit at the system.</p>
Communication Failure	
Distribution Breaker Failure	<p>Localize the tripped breaker.</p> <p>Check the equipment that is connected to the tripped breaker (there may be a reason for this breaker to blow) and reconnect it.</p>
Battery Failure	<p>Check the batteries.</p> <p>Check the <i>battery test</i> parameters in the controller or via the PowCom™ Hybrid software.</p>
Battery Breaker Failure	<p>Localize the tripped breaker.</p> <p>Check the batteries.</p> <p>Reconnect the breaker.</p>
Symmetry Fault	<p>Reset the alarm.</p> <p>Check the connections according to the number of batteries in the controller or via the PowCom™ Hybrid software.</p> <p>Check the batteries.</p>
Low Battery Temperature	<p>Check the batteries.</p> <p>Check ventilation.</p> <p>Check the temperature reading in the controller or via the PowCom™ Hybrid software.</p>
High Battery Temperature	<p>Check the batteries.</p> <p>Check ventilation.</p> <p>Check the temperature reading in the controller or via the PowCom™ Hybrid software.</p>
Temp. Probe Failure	<p>Check the connections to the temperature probe.</p> <p>Replace the temperature probe.</p>
Alarms Blocked	<p>Check the <i>miscellaneous</i> menu in the controller or via the PowCom™ Hybrid software.</p>

If none of the above solves the problem please contact customer support, see section 1.4.

7.1 Controller Replacement

A faulty Controller can be easily replaced with a new one:

1. Loosen the front screw in the top left corner of the controller front panel using a flat screwdriver.
2. Pull the controller out of the system unit.
3. Reverse the process to insert the new controller into the empty slot and fasten the screw.



CAUTION After controller start-up, verify if the appropriate configuration file is uploaded to the controller. If necessary refer to the [PowCom™ Hybrid Manual](#).

7.2 Rectifier/Solar Converter Replacement



NOTE Rectifier/solar converter modules can be hot-swapped.

This section describes how to replace a faulty rectifier in an active system.

1. Release the module handles and remove the faulty module.
2. Insert the new module into the slot and fasten it with the handles. Refer to section 4.20 of this manual for details.
3. Ignore the module alarm caused by current sharing.
4. After 1 minute the yellow LED starts blinking. Wait for a maximum of 4 minutes for the indicator to stop blinking.

7.3 Battery and Load Breaker Replacement



WARNING Make sure the system is switched OFF.

The system unit is designed front accessible for easy maintenance. Battery and load breakers can be replaced without removing the system unit from the cabinet.

This section describes how to replace faulty breakers.

1. Open the system unit front panel by unscrewing the two knurled nuts to the left side.
2. Unscrew the DC load cable from the faulty breaker.
3. Pull out the faulty breaker(s).
4. Install the replacement breaker(s).
5. Close and lock the system unit front panel.



7.4 Surge Protection Device Replacement

This section describes how to replace a faulty surge protection module.


1. Switch off AC input power.
2. Remove the top cover.
3. Pull out the failed surge protection module.
4. Insert a new surge protection module into the corresponding position.
5. Reinstall the top cover.
6. Switch on AC input power.

This document is believed to be correct at time of publication and UNIPower LLC accepts no responsibility for consequences from printing errors or inaccuracies. Specifications are subject to change without notice.

A.1 System Unit Layout



A.2 System Diagram - ACX External Board (4-relays)



Introduction

The genset interface board is used between the genset and the controller. It provides 5KV surge protection for each input from the genset or oil sensor. It also provides power to the oil sensor and amplifies the sense output voltage to a suitable level for controller.




Figure B-1 Genset Module



NOTE Please refer to following diagram for cabling of the generator alarm and fuel sensor.




Figure B-2 Genset Connections

J1 Fuel Sensor Input

Pin	Function	Note
1	Vsensor+	33VDC, 10mA max.
2	Vsensor_in	fuel sensor signal
3	Vsensor-	0V

Table B-1 Fuel Sensor Input Connections

The fuel sensor should operate at 33VDC with a current consumption of less than 10mA.

Three alternative output voltages are available from the sensor; 5VDC, 10VDC and 15VDC. This is selected by using different jumper settings, see table B-3.

J2 Fuel Sensor Output

Pin	Function	Note
1	Vsystem+	Connected to system
2	Vsystem-	
3	Vsensor_out	Output 0~30VDC

Table B-2 Fuel Sensor Input Connections

There are 3 pin-selectors beside this connector. Set jumpers according to following table based on fuel sensor.

Jumper Setting	Max. Sensor Output
All pins open	5VDC
Pins 2 and 3 shorted	10VDC
Pins 2 and 3 shorted	15VDC

Table B-3 Jumper Settings

J3 Alarm Input Interface

Pin	Function
1	Alarm in 1-1
2	Alarm in 1-2
3	Alarm in 2-1
4	Alarm in 2-2

Table B-4 Alarm Input Connections



NOTE The voltage of alarm signal should not exceed 60VDC. AC voltage is not allowed.

J4 Alarm Output Interface

Pin	Function
1	Alarm out 1-1
2	Alarm out 1-2
3	Alarm out 2-1
4	Alarm out 2-2

Table B-4 Alarm Output Connections



NOTE The alarm output interface matches the input interface. For example, Alarm in 1-1 is connected to Alarm out 1-1.

J5 Genset Control and Battery Monitor Output

Pin	Function	Note
1	Out_Gen-ctrl1	60VDC max. on both terminals
2	Out_Gen-ctrl2	
3	Out_Vbmon+	Battery voltage inside genset, 12VDC or 24VDC
4	Out_Vbmon-	

Table B-5 Genset Control and Battery Monitor Output Connections

Out_Gen-ctrl1 and Out_Gen-ctrl2 are used for remote genset ON/OFF.

The Out_Vbmon+ and Out_Vbmon- are used for detecting the voltage of the battery in the Genset. 24V or 12V is supported.

J6 Genset Control and Battery Monitor Input

Pin	Function	Note
1	In_Gen-ctrl1	60VDC max. on both terminals
2	In_Gen-ctrl2	
3	In_Vbmon+	Battery voltage inside genset, 12VDC or 24VDC
4	In_Vbmon-	

Table B-5 Genset Control and Battery Monitor Input Connections

PE Ground Connection

There is a yellow/green cable connecting to this board. For effective surge protection, this cable must be properly bonded to ground.

Bypass Switch of Generator Interface

There is an additional bypass switch to override commands from the system controller.

The bypass switch has defined two working status:

- Position 1 defines the default status, it means that the generator interface is controlled by the system controller.
- Position 0 means that the generator interface is forced to a continuous running state.




Figure B-6 Genset Bypass



WARNING The switch must be set to the “0” position before removing the system controller, otherwise the generator will shut-down automatically.
