

**HRT RECTIFIERS
SINGLE-PHASE INPUT
PRODUCT MANUAL**

C&D Technologies, Inc.
Integrated Power Systems,
Power Systems Division
65 Industrial Park Road, Dunlap, TN 37327
Customer Service, Voice: (800) 440-3504
Customer Service, Fax: (423) 949-3647
Field Service: (800) 299-3907
Web site – <http://www.cdpowercom.com>

RS-903, ISSUE 4
MAY 2006

**RECEIVING INSTRUCTIONS
&
GENERAL EQUIPMENT INFORMATION**

Please Note: For your protection, the following information and the product manual should be read and thoroughly understood before unpacking, installing, or using the equipment.

C & D Technologies presents all equipment to the delivering carrier securely packed and in perfect condition. Upon acceptance of the package from us, the delivering carrier assumed responsibility for its safe arrival to you. Once you receive the equipment, it is your responsibility to document any damage the carrier may have inflicted, and to file your claim promptly and accurately.

1. PACKAGE INSPECTION

- 1.1** Examine the shipping crate or carton for any visible damage: punctures, dents, and any other signs of possible internal damage.
- 1.2** Describe any damage or shortage on the receiving documents, and have the carrier sign their full name.
- 1.3** If your receiving freight bill notes that a Tip-N-Tell is attached to your freight, locate it. If the Tip-N-Tell arrow has turned even partially blue, this means the freight has been tipped in transport. Make sure the carrier notes this on your receipt before you sign for the freight.

2. EQUIPMENT INSPECTION

- 2.1** Within fifteen days, open the crate and inspect the contents for damages. While unpacking, be careful not to discard any equipment, parts, or manuals. If any damage is detected, call the delivering carrier to determine appropriate action. They may require an inspection.

***SAVE ALL SHIPPING MATERIAL FOR THE INSPECTOR TO SEE!**

- 2.2** After the inspection has been made, call C & D Technologies. We will determine if the equipment should be returned to our plant for repair, or if some other method would be more expeditious. If it is determined that the equipment should be returned to C & D Technologies, ask the delivering carrier to send the packages back to C & D Technologies at the delivering carrier's expense.
- 2.3** If repair is necessary, we will invoice you for the repair so that you may submit the bill to the delivering carrier with your claim form.

- 2.4 It is your responsibility to file a claim with the delivering carrier. Failure to properly file a claim for shipping damages may void warranty service for any physical damages later reported for repair.

3. **HANDLING**

Equipment can be universally heavy or top-heavy. Use adequate manpower or equipment for handling. Until the equipment is securely mounted, be careful to prevent the equipment from being accidentally tipped over.

4. **NAMEPLATE**

Each piece of C & D Technologies equipment is identified by a part number on the nameplate. Please refer to this number in all correspondence with C & D Technologies.

5. **INITIAL SETTINGS**

All equipment is shipped from our production area *fully checked and adjusted*. Do not make any adjustments until you have referred to the technical reference or product manual.

6. **SPARE PARTS**

To minimize downtime during installation or operation, we suggest you purchase spare fuses, circuit boards and other recommended components as listed on the Recommended Spare Parts List in the back of the product manual. If nothing else, we strongly recommend stocking spare fuses for all systems.

ISSUE HISTORY

ISSUE	PAGE(S)	DESCRIPTION	APPRV'D /DATE
1		Original Issue	?
2	ALL	Changed throughout manual & cover to read "C & D Technologies, Inc. Power Solutions" and/or "C & D Technologies, Inc.". Changed cover to include Dunlap Plant address, phone #'s, fax #'s, web-site address, etc. Added updated Receiving Instructions & General Equipment Information sheet –issue 7 Added Issue History sheet & moved associated drawings located throughout manual to the back for better viewing purposes. See ECN 12770	MCM 2/23/00
3	ALL	SEE ECN 14491	MCM 10/27/03
4	ALL	SEE ECN 15560	MCM 5/30/06

DOCUMENT SUMMARY

This document explains the installation, operational, maintenance and troubleshooting methods for the C&D Technologies HRT Single-Phase Rectifier.

Thank you for purchasing the HRT Single-Phase Rectifier. We at C&D Technologies are proud of the quality of our products and welcome any suggestions to further improve our design to fit your needs.

All statements, information and data given herein are believed to be accurate and reliable but are presented without guarantee, warranty or responsibility of any kind, express or implied. Statements or suggestions concerning possible use of the product are made without representation or warranty any such use if free of patent infringement and are not recommendations to infringe any patent. The user should not assume all safety measures are indicated or other measures may not be required.

TABLE OF CONTENTS

CHAPTER ONE: DESCRIPTION AND OPERATING CHARACTERISTICS	1-1
1.1 GENERAL DESCRIPTION	1-1
1.2 SPECIFICATIONS	1-2
CHAPTER TWO: RECEIVING AND INSTALLATION	2-1
2.1 IDENTIFICATION	2-1
2.2 UNPACKING AND HANDLING	2-1
2.3 STORAGE	2-2
2.4 LOCATION AND MOUNTING	2-2
2.5 AC POWER REQUIREMENTS	2-2
2.6 CONNECTIONS	2-2
2.7 VOLTAGE CHANGEOVER	2-3
2.8 GROUNDING	2-3
2.9 FUNCTIONAL TEST	2-4
CHAPTER THREE: OPERATION AND MAINTENANCE	3-1
3.1 TURN-ON PROCEDURE	3-1
3.2 OPERATOR ADJUSTMENTS	3-2
3.2.1 Float voltage, operating	3-2
3.2.2 Equalize voltage, operating:	3-2
3.3 SERVICE ADJUSTMENTS	3-2
3.4 CURRENT LIMIT:	3-3
3.5 HIGH-VOLTAGE ALARM (HVA)	3-3
3.6 HIGH-VOLTAGE SHUTDOWN (HVSD)	3-4
3.7 SECONDARY HIGH-VOLTAGE SHUTDOWN (HVSD)	3-4
3.8 LOW-VOLTAGE ALARM (LVA)	3-5
3.9 NO-CHARGE ALARM (NCA)	3-5
3.10 GROUND FAULT ALARM [\pm GRND] (UTILITY)	3-6
3.11 LOAD SHARING	3-6
3.12 RECTIFIER FAIL (RECT. FAIL)	3-7
3.13 MAINTENANCE	3-7
CHAPTER FOUR: TROUBLESHOOTING	4-1
4.1 PROCEDURE	4-1
4.2 TROUBLESHOOTING CHART	4-1
4.3 CHECKING COMPONENTS	4-4
4.3.1 Diodes	4-4
4.3.2 Capacitors:	4-4
4.3.3 Resistors:	4-4
4.3.4 Resonant Triac:	4-4
4.3.5 Circuit Boards:	4-4
CHAPTER FIVE: OPTIONAL EQUIPMENT	5-1
5.1 OPTION BOARD (TELECOMMUNICATIONS)	5-1
5.2 ALARM CONTACTS (TELECOMMUNICATIONS)	5-1
5.3 REMOTE CONTROL (TELECOMMUNICATIONS)	5-1
5.4 EQUALIZE TIMER (TELECOMMUNICATIONS)	5-2
5.5 LOAD SHARING (TELECOMMUNICATIONS)	5-2
5.6 OPTION BOARD (UTILITY)	5-3

5.7 ALARM CONTACTS (UTILITY).....	5-4
5.8 REMOTE CONTROL (UTILITY).....	5-4
5.9 EQUALIZE TIMER (UTILITY).....	5-4
5.10 LIGHTING ARRESTERS	5-5
5.11 GROUND VOLTMETER SWITCH (UTILITY).....	5-5
5.12 ONE PERCENT METERS (UTILITY).....	5-5
CHAPTER SIX: REPLACEMENT PARTS LISTS	6-1
CHAPTER SEVEN: DRAWINGS	7-1

CHAPTER ONE: DESCRIPTION AND OPERATING CHARACTERISTICS

1.1 GENERAL DESCRIPTION

HRT Series, single-phase power supplies are of the controlled ferroresonant type, designed primarily for telecommunications, switchgear and control and related industries that require premium performance.

The main components of an HRT power supply are shown in Figure 1.1. AC input power is applied through a circuit breaker to the power transformer. In addition to serving as an on-off switch for the power supply, the AC circuit breaker provides overcurrent and fault protection for the unit in case of short circuits or other malfunctions on the input side of the unit.

The ferroresonant transformer has its input coil on the same leg of the core as the resonant winding. The resonant winding, together with the resonant capacitor, maintains the core at a high magnetic flux density, keeping output voltage fairly constant with respect to input voltage. The high reactance of this type of transformer provides protection against overload and short circuit of the output.

To further improve output voltage regulation of the ferroresonant transformer with respect to changes in load and input frequency, HRT power supplies use the C&D controlled-ferro technique, which precisely controls the level of magnetic flux density in the core. This technique shunts the resonant circuit with a triac in series with an inductor.

Located on the unit control board, an electronic voltage/current control senses the start of the resonant capacitor charge cycle. It also monitors output voltage and compares it to a reference voltage. The resulting error signal determines when the triac turns on to interrupt the capacitor charge cycle to maintain core flux at the desired level.

Circuitry to limit output current is also located on the control board. When output current exceeds a preset level a proportional signal, developed the ammeter shunt, overrides the voltage regulator to maintain output current at the preset level. If a fault occurs, causing extremely high output voltage, it is sensed by a high voltage shutdown circuit, which trips the ac breaker, turning the power supply off. If HVS does not operate, a redundant mode forces the triac on to shut the charger down.

A power rectifier, consisting of silicon diodes arranged in a full-wave circuit, converts ac voltage from the transformer to dc voltage. The output of this rectifier is filtered and supplied to the battery and load through a dc circuit breaker.




FIGURE 1.1 Block Diagram

1.2 SPECIFICATIONS

The following specifications are the HRT Series line of controlled ferroresonant power supplies. Individual units are supplied with their own particular specifications.

INPUT

Voltage:	120/208/240 V, single-phase, field-changeable.
Frequency:	57 to 63 Hz; 60 Hz nominal
Input Noise:	Within requirements NEMA PE-7, for telecommunications and NEMA PA-5 for utility.
Audible Noise:	Less than 65 dB, A-weighted and measured at five feet from a vertical surface in a nonreflective environment.

OUTPUT

Rated Voltage:	2.15 volts/cell times the number of series-connected lead-acid cells for which unit was designed plus one volt. Float and equalize voltages are continuously adjustable (no taps) over the nominal voltage range of 2.00 to 2.35 volts per cell at reduced output.
Voltage Regulation:	$\pm 0.5\%$ for float operations and $\pm 1.0\%$ for equalize operation for all variations of line and load; $\pm 0.5\%$ for temperature change with constant line and load conditions.
Noise:	22 dBrc maximum when connected to a battery of Ah capacity equal to four times rated output current; 30 mV RMS maximum in a frequency band of 10Hz to 4 MHz; 200 mV or one percent of output voltage, peak-to-peak, maximum.
Current Limit:	105% rated current (102% for the HRT 48AC50E), maximum.

CHAPTER TWO: RECEIVING AND INSTALLATION

2.1 IDENTIFICATION

The model number of an HRT power supply describes its basic operating characteristics. Knowing these characteristics is essential to proper operation and maintenance and to expected service life and coverage under warranty. Read the following codes, explanation and examples carefully. When requesting information or ordering spare parts, please specify the model, serial and specification number, as shown on the equipment nameplate.

HRT 48AC 100 E
HRT – Model line designation
48 – Nominal dc output voltage
AC – 120/208/240 Vac input
100 – Rated dc current
E – Telecommunications battery eliminator
<i>or</i>
U – Utility battery eliminator

2.2 UNPACKING AND HANDLING

HRT models in the 12-¼ inch cabinet are shipped in a carton, with the back panel of the unit on the bottom of the carton. All other models are shipped upright, bolted to a pallet with a carton dropped over the unit and banded to the pallet. All units may be handled with a hand truck or forklift truck. It is recommended that units be moved to their locations before removing the packing materials.

To remove the 12-¼ inch units from the carton, cut the tape that seals the carton, remove the protective inserts, and lift the unit out of the carton. To unpack all other units, cut the bands holding the carton to the pallet and lift the carton off the unit. Remove packing materials from around the cabinet. Remove the bolts holding the power supply to the pallet. **CAUTION: When cutting bands, hold the banding to prevent it from whipping out towards you.** Remove the unit from the pallet and move it to its mounting location, using a suitable lifting device. Move the unit by the lifting eyes at the top of the unit or from the bottom of the unit.

IMPORTANT: Check packing materials for packing slip and other information.

Carefully inspect the power supply for loosened connections or mountings, dislodged circuit boards, and other disruptions that might have occurred during shipping. Report problems as soon as possible to your C&D representative.

2.3 STORAGE

If you are not going to use the power supply immediately, store it (fully packed, if possible) in a clean, dry place, protected from physical damage, airborne contaminants and moisture. HRT power supplies may be stored safely for up to one year at temperatures of -40 F (-40 C) to +185 F (85 C) and a relative humidity of five percent to 95 percent, noncondensing.

2.4 LOCATION AND MOUNTING

Install power supplies in a cool clean, dry place, protected from overhead drip. Avoid locations that would subject the equipment to extreme vibration, which could cause malfunctions. Also provide adequate ventilation to remove heat. Environmental operating limits for the HRT power supply are as follows:

Ambient temperature:	32 F (0 C) to 122F (50 C)
Relative humidity:	zero to 95 percent, noncondensing
Altitude:	Maximum rating to 3,300 ft (1,000 M); derating above. Maximum operating altitude 10,000 ft (3000 M)

HRT power supplies may be mounted on relay racks, walls and, in some cases, floors. To mount a unit to a wall, remove brackets from middle of cabinet and reinstall them at the rear. Brackets are available from C&D for floor mounting.

2.5 AC POWER REQUIREMENTS

Nominal voltage of the ac source must match that of the HRT power supply. Check the card supplied to see that the primary transformer is connected for the incoming ac line voltage. If it is not, refer to the wiring diagram associated with your rectifier.

For the power supply to function properly, ac supply voltage must be within the following ANSI Standard ranges:

VOLTAGE, ALTERNATING CURRENT		
NOMINAL	MINIMUM	MAXIMUM
120	106	127
208	184	220
240	212	254

If sustained voltage fluctuations are beyond these ranges, contact the C&D Field Service Department at 1-800-299-3907.

2.6 CONNECTIONS

CAUTION: Be sure the dc breaker is “OFF” and that positive-to-positive and negative-to-negative polarity are observed when connecting battery to power supply. In all installations using a battery, connect the load to the battery terminals, not to the power supply.

IMPORTANT: This equipment must be installed by competent personnel who are familiar with both local and national electrical codes.

All connection terminals are within the power supply cabinet and may be reached by removing the door panel and opening the hinged instrument panel at the front of the unit. The location of input and put out power connections are shown in Figure 2.2. Conduit holes for power cables are provided in the tip panel. Knockouts or covered access holes are provided in the sides.

The HRT power supply should be connected either to a fused ac disconnect switch or to an ac circuit breaker. Before selecting the rating of the protective device and the size of ac and dc cables, check the equipment nameplate or "Specifications" in Section 1 for rated currents.

In sizing cables and protective devices, follow the National Electrical Code (NEC) or other acceptable standard. In all cases, cable ampacities and protective device ratings must be equal to or greater than the ratings of the power supply circuit breaker.




FIGURE 2.2 – Connection Diagram

2.7 VOLTAGE CHANGEOVER

HRT Power supplies without preset ac input voltage connections may be connected to 120, 208, or 240 Vac by using jumpers as shown on appropriate drawings in Chapter 7.

CAUTION: When making a voltage changeover, DO NOT reposition any wires except the jumper wires on the voltage changeover terminal block. (See Wiring Diagrams located in back of manual)

2.8 GROUNDING

This power supply must be securely grounded to protect operating and service personnel. The ground system must be designed to eliminate ground divergence from occurring and meet the requirements of the National Electric Code (NEC). For installation convenience a ground terminal (labeled "GND") is provided.

2.9 FUNCTIONAL TEST

If possible, before permanently mounting the power supply and placing it in service, conduct the following tests to see if the unit is operating correctly.

PROCEDURE

1. Ground the unit and connect it to an ac source and dc load, as described above. For acceptance testing, dc load can be smaller than specified operating load. Open the ac and dc breaker.
2. Close the ac breaker.
3. Referring to drawings in back of manual, set the float/equalize rocker switch so the float LED indicator is lit and unit is in float mode. Set the remote/local slide switch to "LOCAL" position.. If the unit is operating properly, the following LED indicators will be lit:
 - "AC ON"
 - "RECT FAIL"
 - "NCA"

The ammeter will read zero and the voltmeter will display the float voltage specified on the equipment order, or if a voltage is not specified, the voltage reading will be 2.20 times the number of lead-acid cells for which the unit was designed.

4. Set the float/equalize switch so equalize LED indicator is lit and unit is in equalize mode. The voltmeter will display the equalize voltage specified on the equipment order, or if a voltage is not specified, the voltage reading will be 2.33 times the number of lead-acid cells for which the unit was designed.

NOTE: If the unit has an option board, the unit may go into equalize for the period set on the timer.

5. Set the float/equalize switch so the float LED indicator is lit and unit is back in float mode. Close the dc breaker. Adjust the dc load to about 10 percent of the power supply rating. If the unit is operating properly, the "NCA" LED indicator will go out; the voltage will be the desired float voltage and the ammeter should display the dc output current.
6. Open ac and dc breakers. The acceptance test is finished.

CAUTION: DC output cans may still be charged after breakers are opened.

If you did not obtain the results described above, repeat the entire test in sequence. If the unit still does not respond contact you local C&D representative for assistance.

CHAPTER THREE: OPERATION AND MAINTENANCE

3.1 TURN-ON PROCEDURE

After making all connections to the power supply and checking them for tightness use the following procedure to energize the equipment:

1. Place the float/equalize rocker switch in the float position and set the local/remote switch to local.
2. Close the ac circuit breaker. Wait several seconds for the dc voltage to reach its set point.
3. Close the dc circuit breaker. If inrush of current trips the dc breaker, reset it and proceed. Refer to drawings in back of manual for location of switches.

NOTE: Float and equalize voltage levels are factory-set and are shown on a red card attached to the inside of the front panel. If you wish to change these settings for your application, please refer to section 3.3, "Service adjustments".

The following are *typical* float and equalize voltages, on a per-cell basis for different types of batteries. Refer to the battery manual for cell voltage recommendations.

Table 1

TYPICAL FLOAT/EQUALIZE VOLTAGES		
BATTERY TYPE	CELL VOLTAGE FLOAT EQUALIZE	
LEAD-ANTIMONY (1.210 Specific gravity)	2.15-2.17	2.33
LEAD-CALCIUM (1.210 Specific gravity)	2.17-2.22	2.33*
NICKEL-CADMIUM	1.43	1.55
NICKEL-IRON	1.50-1.55	1.60-1.65
LEAD-ACID VALVE- REGULATED (SEALED)		
(1.300 Specific gravity)	2.25-2.30	*
(1.290 Specific gravity)	2.25-2.30	*
(1.245 Specific gravity)	2.17-2.22	*
*Additional equalize charging is not normally recommended after initial charge. Consult battery manufacturer or your battery manual for further recommendations.		

3.2 OPERATOR ADJUSTMENTS

The following two adjustments do not require the special knowledge and skills of a technician. They can be made externally, without access to the inside of the equipment.

3.2.1 Float voltage, operating

The setting of the float potentiometer FL on the front panel determines the float voltage level, provided the float/equalize rocker switch is in the float position. Turning the potentiometer clockwise increases float voltage. Turning it counterclockwise decreases float voltage.

To adjust float voltage correctly, the battery should be fully charged with some load connected. Adjust the float potentiometer only while the power supply is operating. Be sure the actual output current is less than the rated output current.

3.2.2 Equalize voltage, operating:

The setting of the equalized potentiometer EQ on the front panel determines the equalize voltage level, provided the float/equalize rocker switch is in the equalize position. With the power supply operating, turn the potentiometer to adjust equalize voltage. Increases by turning clockwise; decrease by turning counterclockwise. The equalize setting depends on the kind of battery connected (as shown in Table 1 and on the maximum limiting voltage of the connected load equipment.

NOTE: If lead-calcium batteries are connected, equalize and float voltages typically have the same setting, since lead-calcium cells normally require no equalize charging. Consult your battery manufacturer for more information.

3.3 SERVICE ADJUSTMENTS

CAUTION: Operating an HRT power supply at more than it's rated current is not recommended. The current limit setting should not be greater than 105 percent for all models, except the HRT 48AC50E. The HRT48AC50E current limit should not be set greater than 102 percent.

IMPORTANT: All of the adjustments described below require access to the interior of the power supply enclosure. They must be performed by a qualified technician who is familiar with the HRT power supply and with electrical safety procedures.

CAUTION: Lethal voltages are present within this equipment. Please DO NOT perform tests or adjustments that can not be done safely.

NOTE: If either float or equalize coarse adjustments are made, the current limit must also be checked and adjusted as required.

If the voltage on a replacement board will not adjust, the current limit adjustment may be turned fully counterclockwise. If so turn the current limit clockwise several turns, then adjust the voltage. Be sure to reset the current limit as part of servicing the unit.

3.4 CURRENT LIMIT:

The current limit is factory preset to 105 percent of the rated current, except for the HRT48AC50E that is set to 102 percent of the rated current. If a lower limit is desired, it may be set within a range of 50 percent to 105 percent of the dc rated output, except the HRT48AC50E which is with a range of 60 percent to 102 percent of the rated dc output, using potentiometer R49 on the control board.

Potentiometer R49 is labeled “CL” and is located on the bottom edge of the control board. Clockwise turning increases the current; counterclockwise turning decreases it. To adjust the current limit, follow one of the procedures below.

If dummy load is available, then:

1. Increase load until it exceeds the desired set point.
2. Turn “CL” slowly counterclockwise until you reach the desired setting. For example, to set a 90 percent current limit on a power supply rated at 30 amps, stop turning when you reach 27 amps.
3. Remove dummy load.

If dummy load is not available but some system load is, then:

1. Open the ac circuit breaker.
2. Allow battery voltage to drop to about 90 percent of float voltage. This will discharge the battery enough to make the power supply operate in the current limit mode when it is turned on again.
3. Close the ac breaker.
4. Turn “CL” slowly until the desired setting is reached.

NOTE: Current limit on replacement boards may be fully counterclockwise. This is not a sign of a defective board.

3.5 HIGH-VOLTAGE ALARM (HVA)

CAUTION: Do not exceed maximum system bus voltage when setting or checking this function.
--

Description: The high-voltage alarm monitors dc output voltage and activates local and remote alarms when voltage raises beyond a preset level. The HVA remains activated as long as a high-voltage condition exists.

Preferred method of adjustment: Set the high-voltage alarm by turning potentiometer R41 (labeled “HVA” on control board) clockwise to increase the alarm trip level voltage, counterclockwise to decrease it. To adjust the HVA, connect a high-impedance voltmeter between TP1 and J3-12. Set the power supply to the equalize mode and adjust equalize voltage to the desired HVA trip limit. Turn R41 counterclockwise until the voltage reading is zero. Then, turn it slowly clockwise until voltage increases to about 15 volts. The alarm voltage level is now set.

Alternate method of adjustment: Set the power supply to the equalize mode and adjust equalize voltage to the desired alarm trip level voltage. Turn R41 clockwise until the HVA LED indicator turns off. Then, turn it very slowly counterclockwise until the HVA LED lights up again.

NOTE: The HVA LED indicator on the front panel will not light at the same time as the 15-volt level is reached because of a time delay in alarm operation.

To check the HVA trip level setting to the power supply to equalize, and while monitoring the output voltage, very slowly increase the output voltage until the alarm is activated.

IMPORTANT: Reset the equalize potentiometer after adjusting the HVA.

3.6 HIGH-VOLTAGE SHUTDOWN (HVSD)

CAUTION: Do not exceed maximum system bus voltage when setting or checking this function.
--

Description: The high-voltage shutdown monitors the dc output voltage and turns the power supply off if the voltage exceeds a preset level, protecting both load and power supply. The HVSD works by energizing a trip coil on the ac input circuit breaker. After it has been activated and as long as voltage is present on the output, the HVSD lights a blinking LED indicator on the front panel. This shows the reason for the power supply shutdown. The function is reset by opening the dc breaker, until the LED stops flashing. The power supply may now be restarted by closing the ac breaker, followed by the dc breaker 15 seconds later.

NOTE: If the HVSD continues to shut down the power supply, refer to “Adjustment” below or to the “Troubleshooting” section of this manual. The HVSD cannot operate when the no-charge alarm (NCA) is energized.

Preferred method of adjustment: Set the HVSD by turning potentiometer R52 (labeled HVS on control board) clockwise to increase trip level voltage, counterclockwise to decrease it. To adjust, connect a high-impedance voltmeter from TP9 to J3-12. Set the power supply to the equalize mode and adjust the equalize voltage to the desired HVSD trip level. Adjust the HVSD by turning R52 clockwise until the voltage rating is zero. Then, turn it counterclockwise until the voltage increases to about 15 volts. This sets the trip level. **NOTE:** By performing the above adjustment at zero output current, the HVSD trip level may be set without the power supply tripping off.

If the HVSD LED indicator does not flash and the ac circuit breaker trips consult the troubleshooting section.

IMPORTANT: RESET THE EQUALIZE POTENTIOMETER AFTER ADJUSTING THE HVSD.

NOTE: For valve-regulated (sealed) batteries, the HVS should be set for 2.40 volts per cell.

3.7 SECONDARY HIGH-VOLTAGE SHUTDOWN (HVSD)

Description: The secondary high-voltage shutdown (HVSD) monitors the dc output voltage and turns off the power supply if the voltage exceeds a factory-set limit for approximately three seconds. The secondary shutdown works by energizing the trip coil in the ac circuit breaker and by turning the triac on. When active, the LED on the circuit board is illuminated. The NCA does not affect the operation of this protection circuit board, which is mounted either to a bracket on the bottom or top of the power supply or to the left wall of the cabinet.

To reset the protective circuit, the ac circuit breaker and the dc circuit breaker must be opened and the output filter capacitors totally discharged (0 volts dc output).

Adjustment: The protective circuit is factory set at 30.7 volts for a 12-cell unit or 61.2 volts for a 24-cell unit, ± 0.2 volts. The level is not field-adjustable.

3.8 LOW-VOLTAGE ALARM (LVA)

Description: The low-voltage alarm monitors dc voltage and activates an LED indicator when voltage falls below a preset limit. The LVA will operate as long as a battery or other voltage source is present – even if the power supply is shut down or the ac source has failed.

Preferred method of adjustment: To set the LVA, turn potentiometer R42 (labeled “LVA” on control board) clockwise to increase or counterclockwise to decrease the trip voltage level. To adjust, connect a high-impedance voltmeter between TP-8 and J3-12. Set the power supply to the equalize mode and adjust equalize voltage to the desired alarm voltage. Turn R42 clockwise until the voltage drops to zero. Then, turn it slowly counterclockwise until the meter reads 15 volts. The LVA level is now set.

NOTE: The front panel LVA LED indicator will not light at the same time the 15-volt level is reached because of a time delay in alarm operation.

Alternate method of adjustment: Set the power supply to equalize and adjust the equalize voltage to the desired level. Turn R42 clockwise until the LVA LED indicator goes off. Then, turn it very slowly counterclockwise until the LED lights again. The alarm level is now set.

To check the LVA setting, slowly adjust the equalize voltage from above to below the desired alarm voltage. Or, set the power supply to “Float”, close the ac breaker, and partially discharge the connected battery. Monitor the output voltage until the desired alarm voltage is reached.

IMPORTANT: RESET THE EQUALIZE POTENTIOMETER AFTER ADJUSTING THE LVA.

3.9 NO-CHARGE ALARM (NCA)

Description: The no-charge alarm is a low-current alarm. It monitors power supply output current and activates local and remote alarms when this current drops below a preset level. NCA operation prevents operation of the HVSD. It also disconnects load-sharing circuitry from power supplies, which are connected in parallel. Do not set the NCA to less than two percent of the rated output of the power supply.

Preferred method of adjustment: To set the NCA turn potentiometer R47 (labeled NCA on the control board) counterclockwise to increase the current level. Clockwise to decrease it. With the power supply operating, load the power supply to obtain the desired current for the alarm to operate. For currents above the desired current, the alarm is inactive. For currents below the desired current, the alarm is active. Turn R47 counterclockwise until the NCA LED indicator goes off. Then turn it slowly clockwise until the LED lights again. The NCA is now set.

Alternate method of adjustment: With batteries and load connected, adjust the power supply voltage until the output current is the desired operating current for the alarm. Currents above the desired operating current leave the alarm inactive. Currents below the desired current activate the alarm. Turn R47 counterclockwise until the NCA LED indicator goes off. Then, turn it slowly clockwise until the LED lights again. You may need to readjust power supply voltage during this procedure as the load discharges the batteries.

To check the NCA setting, adjust either the load or the output voltage so power supply current drops below the alarm set point. Note current at which alarm operates.

IMPORTANT: RESET OUTPUT VOLTAGE LEVELS AFTER ADJUSTING THE NCA.

NOTE: Setting the NCA too low may result in HVSD operation.

3.10 GROUND FAULT ALARM [\pm GRND] (UTILITY)

Description: The ground fault alarm indicates if a substantial current path is present from an output lead to the ground. The presence of a current path will activate the appropriate LED.

Adjustment: The sensitivity level of the alarm is selectable between either 1 mA or 5mA by J7 and J8. For 1 mA sensitivity, place the shorting jumpers of pins 2 and 3 of J7 and pins 2 and 3 of J8. For 5 mA sensitivity, place the short jumpers on pins 1 and 2 of J7 and pins 1 and 2 of J8. Removing the jumpers and not replacing them on the appropriate pins will result in a 1mA sensitivity.

3.11 LOAD SHARING

Description: Load sharing allows two or more HRT power supplies connected in parallel to share a load in proportion to their ratings, HRT power supplies will share a load within five percent of the rating of the largest unit between 10 percent and 100 percent of their ratings.

Connection: Connect all load sharing power supplies to the system bus, using equal lengths of properly sized cable from the output of each unit. Connect a #18 AWG insulated wire from TB1-1 on the HRT control board to the appropriate terminal in the other unit.

Adjustment: For each power supply, remove connections to TB1-1 and energize only that unit. Set output voltage in both float and equalize mode to the desired levels. Use a digital dc voltmeter for this adjustment. Connect the dc voltmeter between TB1-1 and J3-12.

With no load on the power supply, adjust the load share control (R43) to obtain 5.00 volts on the TB1-1 terminal. Individually adjust all other HRT power supplies in the same manner.

For two power supplies: reconnect the #18 AWG wire between the two units. Energize both units. Add some load to the system and adjust R43 on the unit with the lower output current until the load share control matches the output current of the other unit. For best results, the load should be between 50 percent and 100 percent of the combined rating of the two power supplies.

For more than two power supplies: Energize two units and adjust them as described above.

NOTE: Only the units operating should have any connections to the TB1-1 terminals. For each additional unit set the unit as described in the paragraph "Adjustment," above. Then add additional units, one at a time, connecting the #18 AWG wire to TB1-1 from the units already load sharing and adjustment R43 (load share control) on each added unit until all units are balanced and sharing the load. For best results, the system load should be between 50 percent and 100 percent of the combined rating of the operating power supplies.

Operational notes – load sharing:

1. Load sharing is not intended to be effective below 10 percent of the sum of the rectifier-rated output. Operation below 10 percent load may cause unequal outputs or loss of output current from one of the paralleled units. Where paralleled units are used to load a battery before the system load is installed. We recommend only one power supply be operated.
2. Occasional minor changes in the power supply output current may occur when paralleled units are operated at light loads. This indicates the transfer of small currents between units and does not affect the load.

3. If output voltages are misadjusted, oscillation or “hunting” may occur. To remedy this, energize only one unit at a time and adjust its output voltage to the desired level using a digital voltmeter.

3.12 RECTIFIER FAIL (RECT. FAIL)

The rectifier fail is not user adjustable. It is activated by the individual alarms: the high-voltage shutdown, no-charge alarm, and loss of ac power. The summary alarm relay is operated with the rectifier fail. The summary alarm relay is de-energized by an alarm condition. Alarm contact connections are made via the screw terminals a TB3 on the control board.

3.13 MAINTENANCE

CAUTION: Before performing any maintenance, shut off ac input power and disconnect the battery from the power supply. Also discharge filter and resonant capacitors if required.

The HRT power supply is designed to provide years of trouble-free service. To obtain optimum performance, we recommend you perform the following preventive maintenance and inspections periodically:

- Good ventilation is essential to power supply operation. Check the area around the unit to assure nothing interferes with the free movement of cooling air around internal components.
- Clean equipment operates cooler and performs better. Blow out the power supply periodically with dry, low-pressure air to remove built-up dust.
- Check all connections at least twice a year for tightness. Clean and retighten as necessary.
- Check ac and dc capacitors for leakage, case or seal rupture, and screw tightness. DC capacitors more than five years old or showing signs of degradation should be removed and checked for excessive leakage current and replaced if necessary. (Refer to Chapter 4: Troubleshooting)
- Float and equalize voltages should be checked and adjusted as described at the beginning of this section.
- Excessive overloads may damage the power supply. Check the current limit periodically as described in “Current limit” above.
- Check panel meters periodically against portable standards.

CHAPTER FOUR: TROUBLESHOOTING

4.1 PROCEDURE

The chart below is designed to help a qualified technician diagnose the causes of power malfunctions and remedy them in a logical and efficient manner. Use it with the component location drawings and wiring and schematic diagrams that follow in Chapter 7. A section on “Checking components,” also in this section, will help you diagnose a repair malfunctions in specific components.

SERVICE NOTE: To check power circuit:

1. Disconnect control board.
2. Open the dc circuit breaker.
3. Close the ac circuit breaker.

If power circuit is functioning properly, the unit will deliver dc voltage. If this does not occur, follow the appropriate procedure in the troubleshooting chart below.

WARNING: Lethal voltages are present within an HRT power supply. For your own safety, before attempting any of the following procedures, disconnect both the ac power source and the battery, and discharge the filter and the resonant capacitors if required. If a particular check requires ac or dc power, or both follow carefully the specific procedures for that test.

4.2 TROUBLESHOOTING CHART

TROUBLESHOOTING CHART

Problem	Possible Causes	Solutions
AC breaker trips	1. Short in ac power circuit	a. Inspect primary wiring for shorts or ground connections
	2. Input connected for wrong voltage	a. Check position of jumpers on voltage changeover diagram, Fig. 2.6
	3. High-voltage shutdown is operating	a. Remove load and check for high voltage
	4. Secondary high-voltage shutdown is operating	a. Check for high voltage b. Defective shutdown board
	5. Input voltage is outside ANSI range	a. Measure input voltage
	6. AC frequency is less than 57 Hz	a. Check input frequency
	7. Short in power transformer winding	a. Inspect transformer primary for signs of overheating

TROUBLESHOOTING CHART (continued)

Problem	Possible Causes	Solutions
No dc output (current or voltage) <i>Note:</i> <i>Panel voltmeter maybe defective --- Check voltage at output terminals using portable meter.</i>	1. AC power outage	a. Check ac voltage on both sides of breaker
	2. DC breaker open	a. Check dc breaker b. With unit operating, load connected and breaker closed, voltage across breaker should be zero.
	3. Short in dc power circuit	a. Check secondary power wiring and terminals for shorts or grounded connections b. Check power rectifier diodes c. Check for shorted dc filter capacitors
Low dc output voltage <i>Note:</i> <i>Panel voltmeter may be defective --- check voltage at output Terminals using portable meter.</i>	1. Short in resonant circuit	a. Check triac b. Check resonant capacitor c. Check resonant circuit wiring
	2. Open sensing lead	a. Check wiring for continuity
	3. Unit in current limit	a. Adjust current limit potentiometer
	4. Component failure in control board	a. Replace control board
	5. Voltage misadjustment	a. Adjust float potentiometer b. Adjust coarse voltage setting on control board. (Telecommunications only.)
	6. Secondary shutdown is activated	a. Remove load and check for high voltage b. Defective shutdown board
High dc output voltage	1. Open triac in resonant circuit	a. Check triac
	2. Open sensing leads	a. Check for dc voltage between J3-9 and J3-12 on control board. (2.55V nominal)
	3. Control board failure	a. Replace control board
DC breaker trips	1. Battery connection reversed	a. Check polarity of battery connections
	2. Short in dc power circuit	a. Check secondary power wiring and terminals for shorts or grounded connections b. Check power rectifier diodes c. Check dc filter capacitors
Excessive output current	1. No current limit	a. Current limit improperly set b. Check shunt/control board connections c. Failed component in control board; replace control board

TROUBLESHOOTING CHART (continued)

Problem	Possible Causes	Solutions
Excessive ripple or electrical noise	1. Loose filter connections	a. Check unit wiring and bus bars for loose or corroded connections
	2. Defective filter capacitor	a. Check filter capacitors
	3. Open power diode	a. Check power diodes
	4. DC cable routing (excessive noise)	a. Check for broken cable
	5. Improperly-sized battery	a. Check battery rating
No output current	2. Load sharing misadjustment	a. Adjust load sharing b. Readjust input voltage and load sharing c. Insufficient load for load sharing
	3. Paralleled charger supplying all load current	a. Readjust output voltage and load sharing b. Insufficient load for load sharing
	4. Dc ammeter or shunt defective	a. Check and replace, if necessary
Oscillations or poor regulation	1. Loose connection	a. Check circuit boards, connectors, and wiring for poor contacts
	2. Defective triac	a. Replace triac
	3. Component failure in control board	a. replace control board
	4. Open power diode	a. Check power diodes; replace as required
	5. Resonant capacitor not Grounded	a. Check ac capacitor case to ground with ohmmeter
Low output current	1. Loose connections	a. Check wiring
	2. Open power diode	a. Check power rectifier diodes; replace as required
	3. Unit in current limit	a. Adjust current limit to proper setting
		b. Replace control board
Acoustic noise	1. Loose laminations	a. Check air gap areas of power transformer and control reactor with insulated screwdriver
	2. Cabinet vibration	a. Check welds and bolted joints
Ground lights OFF with ground on battery <i>(Utility models only)</i>	1. DC breaker open	a. Close unit
	2. Control board not grounded	a. Ground unit b. check ground from control board to instrument panel to cabinet
	3. Sensitivity jumpers set wrong	a. Set jumpers on J7 and J8 correctly
	4. Detention level too high	b. Set board for 1 mA
	5. Control board defective	a. Replace control board
	6. Option board installed wrong	a. Check option board installation

4.3 CHECKING COMPONENTS

CAUTION: Before performing the following test, disconnect both the ac power and the battery. Also discharge filter and resonant capacitors if required.

NOTE: Replace defective components with exact duplicates only. Refer to Chapter 6 for part numbers.

4.3.1 Diodes

Isolate diode from circuit by removing one of its connections. Then test with ohmmeter, using either 10X or 100X scale. A good diode will show low resistance in one direction, very high resistance in the other. A short-circuited diode will show no resistance or very low resistance in both directions. An open diode will show very high resistance in both directions.

4.3.2 Capacitors:

Isolate capacitor from circuit by disconnecting both of its leads. Test with an analog ohmmeter reversing leads for each check. Scale range depends on size of capacitor and type of ohmmeter used. Start with highest range and work downward. A good capacitor will show a deflection toward zero resistance initially, then a steady increase toward infinite resistance. A short-circuited capacitor will show zero resistance. An open capacitor will show infinite resistance.

4.3.3 Resistors:

Isolate resistor by disconnecting both of its leads. Test with ohmmeter, starting with lowest scale and increasing upward. A good resistor will show a specified resistance. A short-circuited resistor will show zero resistance. An open resistor will show infinite resistance.

4.3.4 Resonant Triac:

To check for short circuit, remove one connection and test with ohmmeter, using either 10X or 100X scale. A short-circuited triac will show no resistance or very low resistance in both directions. However, a high resistance in both directions does not necessarily mean that a triac is open.

To check for turn-on, remove one connection. Connect the positive lead of an analog ohmmeter to the triac anode and the negative lead to the cathode. The triac should read open or high resistance. Connect the gate to the anode with a jumper. A low resistance indicates that the triac is turning on.

4.3.5 Circuit Boards:

None of the components on a circuit board were designed for field repair. Defective circuit boards should be replaced. See Chapter 6.

CHAPTER FIVE: OPTIONAL EQUIPMENT

5.1 OPTION BOARD (TELECOMMUNICATIONS)

The option board provides an equalize timer, alarm contacts and load sharing interfacing on one circuit board. The load sharing interfacing allows the HRT Series units to be connected with units, such as ART Series, which have the load sharing output referenced to the positive output lead. To install an option board, refer to the table below:

Model	Drawing
HRT24AC25E	MBC-5544
HRT24AC50E	MBC-5544
HRT24AC100E	MBC-5332
HRT24AC200E	MBC-5471
HRT24AC15E	MBC-5544
HRT48AC30E	MBC-5544
HRT48AC50E	MBC-5332
HRT48AC100E	MBC-5333

5.2 ALARM CONTACTS (TELECOMMUNICATIONS)

The alarm contacts are accessible through the terminals on the right side of the circuit board. The terminals are spring loaded. By pushing the orange tab to the left (total travel is approximately 0.09 inches), the terminal will open to release or receive a stripped wire. The wire size range is 26-14 AWG. Normally open and normally closed contacts are provided for no-charge alarm (TB2, NCA), low-voltage alarm (TB6, LVA), high-voltage alarm (TB7, HVA), and ac on (TB8, PWR).

The alarm contact position for alarm conditions are:

Alarm	Relay Operations
AC power	De-energized by alarm conditions
HVA	Energized by alarm conditions
LVA	De-energized by alarm conditions
NCA	De-energized by alarm conditions

5.3 REMOTE CONTROL (TELECOMMUNICATIONS)

Remote control of the float or equalize mode is available through TB5, remote equalize. The contact should be rated for 1 mA, 5-volt operation. To use this feature, remove the jumper from TB5 and connect the remote control contacts to these terminals.

For remote control of the output mode the local/remote selector switch must be in remote position. With the switch in this position, the output mode is controlled by the option board and contact status presented to TB5. C closed contact selects float mode for the rectifier, and an open contact selects equalize mode. If the remote control contact is not used a jumper must be place between the TB5 terminals as originally provided. If the option board equalize timer (described on Page 19) is in equalize mode, the remote contact status is ignored. To assure proper operation, a jumper or the remote control contacts must be connected to TB5.

5.4 EQUALIZE TIMER (TELECOMMUNICATIONS)

The equalize timer function is activated by changing the local/remote selector switch from local to remote. This action initiates only one timer cycle. If the HRT is already set to remote, rock the switch from remote to local to remote. When activated, the unit operates in equalize mode for the number of hours selected via S2 and S3, plus an additional six minutes. Operation of the remote control contacts connected to RB5 will not initiate a timer cycle.

The switches S3 and S2 select the desired number of hours for the equalize timer cycle. Setting the switches should only be done by qualified service personnel. Any period from 00 to 99 hours may be set. For periods less than 10 hours, S3 is set to "0" and S2 is set to the desired number of hours.

External events can affect the equalize timer function. Without a battery connected to the unit, an ac power failure will terminate the equalize timer cycle. With a battery connected to the unit, an ac power outage will stop the timer for the duration of the outage. When ac power is restored, the timer will resume operation. Changing the local/remote switch from remote to local puts the rectifier in the mode selected via the float/equalize switch. Returning the switch to remote activates the timer as described above. If the TB5 terminals (described above) are connected to open contacts or are otherwise not shorted together, the HRT will remain in equalize mode after the timer cycle is finished. To assure proper operation, a jumper or remote control contacts must be connected to TB5.

5.5 LOAD SHARING (TELECOMMUNICATIONS)

CAUTION: All units connected in load sharing via the option board MUST have their load sharing output referenced to the positive output leads of the units.

WARNING: Improper connection of the load sharing can damage the rectifiers and may result in personal injury.

The load sharing circuitry on the option board is intended for use with C&D rectifiers, which are not HRT Series or HF Series. All load sharing connection between HRT Series or HF Series units should be made on the control board on TB1 or TB1-1a. All load-sharing connections to all other types of C&D power supplies must be made on TB1 of the option board.

Upon installation, J4 should be set to the nominal output voltage of the rectifier. The jumper J3 should be set to either the "C&D POWER SUPPLIES" position on the "±" position.

Adjustment: Set the LS voltage on control boards. With ac and dc circuit breaker off, disconnect ribbon cable from J1 on the option board. Disconnect any wires connected to TB1-1 or TB1 -1a on the control board and energize only that unit. Set the output voltage in both float and equalize mode to the desired level. Use a digital voltmeter for the adjustment. Connect a dc voltmeter between LS (TB1-1 or TB1-1a) on the control board and negative voltmeter jack. With no load on the HRT, adjust the load share control (R43) on the control board to obtain 5.00 volts on the dc voltmeter. De-energize the power supply and reconnect the ribbon cable to J1 on the option board. Connect a voltmeter between LS (TB1) on the option board (positive lead) and the positive meter jack (negative meter lead).

For units with J3 set to "C&D CHARGERS": Close ac breaker and leave the dc breaker open. On the option board turn the potentiometer R13 fully counterclockwise. (R13 is a 25-turn potentiometer. Several turns may be necessary to go fully counter clockwise.) Once fully counter clockwise, turn R13 clockwise for 2 ½ turns.

Adjust potentiometer R14 on the option board for -5.0 volts on voltmeter. Close dc breaker and place rated load on charger. The voltmeter should read -4.5 volts. If necessary, adjust R13 by one-quarter turn then readjust R14 to obtain the required levels. Please note R13 and R14 adjustments interact.

For units with J3 set to “ \pm ”:

CAUTION: For this calibration the user must know the desired output voltage for the load share connection of no load and at rated load. Without this information, the board cannot be calibrated. The calibration process requires loading the units to rated current and may be very time consuming. A factory-calibrated board should not be readjusted unless it is absolutely necessary.

For “positive” (+) load sharing (-10V at 0% load, -2.0V at 100% load), open the ac breaker. Turn the potentiometer R12 (gain) on the option board fully counterclockwise. Once fully counter clockwise, turn R12 clockwise 7½ turns. Adjust potentiometer R14 (zero) on the option board for -10.0V. Close dc breaker and load the HRT to its rated output current. Verify the voltage is -2.0V. If necessary, readjust R12 and R14 to obtain -10.0 volts at no load and -2.0 volts at rated load. Note that the R12 and R14 adjustments interact.

For “negative” (-) load sharing 0V at 0% load, 8V at 100% load), open the ac breaker. Turn the potentiometer R12 (gain) on the option board fully counterclockwise. Once fully counterclockwise, turn R12 clockwise 9 turns. Adjust potentiometer R14 (zero) on the option board for 0.0 volts on the meter. Close the dc breaker and current. Verify the voltmeter reads 8 volts. If necessary, readjust R12 and 8 volts at rated load. Note that R12 and R14 adjustments interact.

5.6 OPTION BOARD (UTILITY)

The option board provides an equalize timer and alarm contacts on one circuit board. The option board is installed as indicated on the drawings listed below:

Model	Drawing
HRT24AC25U	MBC-5544
HRT24AC50U	MBC-5544
HRT24AC100U	MBC-5542
HRT48AC15U	MBC-5544
HRT48AC30U	MBC-5544
HRT48AC50U	MBC-5542
HRT48AC100U	MBC-5533

When installing or adjusting an option board be sure the internal wires do not rest against the option board. Refer to the appropriate installation drawing for more information.

5.7 ALARM CONTACTS (UTILITY)

The alarm contacts are accessible through the terminals on the right side of the circuit board. The terminals are spring-loaded. By pushing the orange tab to the left, the terminal will open to release or receive a tripped wire. The wire size range is 26-14 AWG. Normally, open and closed contacts are provided for no-charge alarm (TB2, NCA), negative lead ground faults (TB3-GND), positive lead ground faults (TB4+GND), low-voltage alarm (TB6, LVA), high-voltage alarm (TB7, HVA), and ac on (TB8, PWR). The operation is described in the following table:

Alarm	Relay Operation
AC PWR	De-energized by alarm conditions
HVA	Energized by alarm conditions
LVA	De-energized by alarm conditions
+GND	Energized by alarm conditions
-GND	Energized by alarm conditions
NCA	De-energized by alarm conditions

5.8 REMOTE CONTROL (UTILITY)

Remote control of the float or equalize mode is available through TB5, remote equalize. The contact should be rated for 1 mA, 5 volt operation. To use this feature, remove the jumper from TB5 and connect the remote control contacts to these terminals.

For remote control of the output mode, the local/remote selector switch must be in remote position. With the switch in this position, the output mode is controlled by the option board and contact status preset to TB5. A closed contact selects float mode for the rectifier and an open contact selects equalize mode. If the remote control contact is not used, a jumper must be placed between the TB5 terminals as originally provided. If the option board equalizer timer (described below) is selecting equalize mode, the remote contact status is ignored. To assure proper operation, a jumper or remote control contacts must be connected to TB5.

5.9 EQUALIZE TIMER (UTILITY)

The equalize timer function is activated by changing the local/remote selector switch from local to remote. This action initiates only one timer cycle. If the HRT is already set to remote, rock the switch from remote to local to remote.

When activated, the unit operates in equalize mode for the number of hours selected via S2 and S3, plus an additional six minutes. Operation of the remote control connected to the TB5 will not initiate a timer cycle.

The switches S3 and S2 select the desired number of hours for the equalize timer cycle. Setting the switches should only be done by qualified service personnel. Any period from 00 to 99 hours may be set. For periods less than 10 hours, S3 is set to zero and S2 is set to the desired number of hours.

External events can affect the equalize timer function, an ac power failure will terminate the equalize timer cycle. Changing the local/remote switch from remote to local puts the rectifier in the mode selected via the float/equalize switch. Returning the switch to remote activates the timer as described above. If the TB% terminals (described above) are connected to open contacts or are otherwise not shorted together, the HRT will remain in equalize mode after the timer cycle is finished. For proper operation, a jumper or remote control contacts must be connected to TB5.

5.10 LIGHTING ARRESTERS

Optional lightning arrestors for the dc input are available for all HRT models.

Model:	Drawing
HRT24AC25E	MBC-5488
HRT24AC50E	MBC-5488
HRT48AC15E	MBC-5488
HRT48AC30E	MBC-5488
HRT24AC25U	MBC-5488
HRT24AC50U	MBC-5488
HRT48AC15U	MBC-5488
HRT48AC30U	MBC-5488
HRT24AC100E	KBC-5295
HRT48AC50U	KBC-5295
HRT24AC100U	KBC-5295
HRT48AC50U	KBC-5295
HRT24AC200E	KBC-5296
HRT48AC100E	KBC-5296
HRT48AC100U	KBC-5296

5.11 GROUND VOLTMETER SWITCH (UTILITY)

The ground voltmeter switch allows the internal analog voltmeter and/or an external voltmeter connected to the pin jacks to measure the potential from either output lead to ground. Normal readings are approximately six volts from ground to the negative output lead. The positive lead to ground will be approximately 40 volts and 20 volts for nominal 48 and 24-volt units, respectively. The dissymmetry in voltage measurements is due to the ground detection scheme for the ground lights. The ground voltmeter switch does not provide correct information to the digital meter but does provide correct voltages to the pin jacks.

5.12 ONE PERCENT METERS (UTILITY)

One percent analog voltmeters and ammeters are available on the utility models. The meters are identical in size and appearance to the standard meters but are more accurate.

CHAPTER SIX: REPLACEMENT PARTS LISTS

MODEL	RATED AC CURRENT①	RATED DC VOLTAGE②	INTERNAL CIRCUIT BREAKER RATINGS (AMPS)		CIRCUIT BREAKER INTERRUPTING RATING (AMPS)	
			AC⑤	DC	AC③	DC
HRT24AC25E	7.6/4.4/3.8	26.8	16/8/8	35	5000 @ 250 Vac	5000 @ 125 Vdc
HRT24AC50E	15/8.7/7.5	26.8	30/15/15	70	5000 @ 250 Vac	5000 @ 125 Vdc
HRT24AC100E	32/19/16	26.8	80/40/40 or 60/30/30④	125	5000 @ 250 Vac	10,000 @ 125 Vdc 25,000 @ 65 Vdc
HRT24AC200E	58/33/29	26.8	100/50/50	250	5000 @ 250 Vac	10,000 @ 125 Vdc 25,000 @ 65 Vdc
HRT48AC15E	8.6/5/4.3	52.6	20/10/10	20	5000 @ 250 Vac	5000 @ 125 Vdc
HRT48AC30E	18/10.3/9	52.6	40/20/20	40	5000 @ 250 Vac	5000 @ 125 Vdc
HRT48AC50E	28/16/14	52.6	60/30/30	70	5000 @ 250 Vac	5000 @ 125 Vdc
HRT48AC100E	58/33/29	52.6	100/50/50	125	5000 @ 250 Vac	10,000 @ 125 Vdc 25,000 @ 65 Vdc
HRT24AC25U	7.6/4.4/3.8	26.8	16/8/8	35	5000 @ 250 Vac	5000 @ 125 Vdc
HRT24AC50U	15/8.7/7.5	26.8	30/15/15	70	5000 @ 250 Vac	5000 @ 125 Vdc
HRT24AC100U	32/19/16	26.8	60/30/30	125	5000 @ 250 Vac	5000 @ 125 Vdc
HRT48AC15U	8.6/5/4.3	52.6	20/10/10	20	5000 @ 250 Vac	5000 @ 125 Vdc
HRT48AC30U	18/10.3/9	52.6	40/20/20	40	5000 @ 250 Vac	5000 @ 125 Vdc
HRT48AC50U	28/16/14	52.6	60/30/30	70	5000 @ 250 Vac	5000 @ 125 Vdc
HRT48AC100U	58/33/29	52.6	100/50/50	125	5000 @ 250 Vac	5000 @ 125 Vdc

①Rated currents are presented in the form 120V/208V/240V connected inputs.

②Rated voltage is calculated per NEMA PE7 – 1985. In practice, voltage should be adjusted to the battery manufacturer's recommendations. (NEMA PE7 = 2.15 X number of cells + 1 volt)

③Breaker fusing of four times rating is required. Otherwise the rating is 1000A @ 250 Vac.

④Early models shipped with either 80/40/40 or 60/30/30 breakers. Recommended replacement is 60/30/30.

⑤AC breaker ratings are 120V/208V/240V connected inputs. Poles are paralleled for 120V.

OBSOLETE - FOR RECORD ONLY

HRT RECTIFIER SINGLE-PHASE INPUT MANUAL

REPLACEMENT PARTS FOR HRT 24 AC 25E AND HRT 24 AC 25U

ITEM	SCHEMATIC LEGEND	C & D PART NUMBER	QUANTITY	DESCRIPTION
-	-	-	-	Cabinet outline
41	-	JN-38A	1	Name plate
-	AM	JM-242	1	Ammeter, 50A, 50mV, YEW
-	VM	JM-239	1	Voltmeter, 50V YEW
4	ACB	JR-751	1	AC circuit breaker, 2-pole, 8A, 250 Vac
5*	DCB	JR-755	1	DC circuit breaker, 1-pole, 35A, 125Vdc
-	DCB	JR-798	1	DC circuit breaker, 2-pole, 35A, 125Vdc
-	CBA	NBC-2155	1	Analog meter control board, telecommunications
-	CBA	NBC-2157	1	Analog meter control board, utility
-	CBA	NBC-2158	1	Digital meter control board, utility
19	RR	T-1900	1	Resonant reactor
-	TS1	JL-918	1	AC input terminal strip
-	TS2	JL-898	1	DC output terminal strip
55	GND	JH-1315	1	Ground lug
21	PFX	T-1898	1	Power transformer
11	C1	JC-135	1	Filter capacitor, 48,000 μ F, 40 Vdc
11	C2	JC-186	1	Filter capacitor, 145,000 μ F, 40 Vdc
18**	RA	JS-882	1	Triac/rectifier assembly
12	RC	JC-32	1	Resonant capacitor
23	R1, R2	JE-630	1	Resonant resistor, 1.5 ohm, 110W
19	FC	T-1902	1	Filter choke
-	AS	JM-248	1	Ammeter shunt, 50A, 50mV
**	TRIAC	JS-826	1	Triac, 35A, 600V
-	-	JS-883	1	Diode module, 30A, 400V
17	AXF	JT-276	1	Transformer, 36V C.T., 30VA
-	-	JA-2031-150V	1	Surge protector
-	HVSD	NBC-2341-24	1	Secondary high-voltage shutdown board

**Indicates recommended spare part. Item numbers refer to drawings in Chapter 7.

REPLACEMENT PARTS FOR HRT 24 AC 50E AND HRT 24 AC 50U

ITEM	SCHEMATIC LEGEND	C & D PART NUMBER	QUANTITY	DESCRIPTION
-	-	-	-	Cabinet outline
41	-	JN-38A	1	Name plate
-	AM	JM-243	1	Ammeter, 75A, 50mV, YEW
-	VM	JM-239	1	Voltmeter, 50V YEW
4	ACB	JR-753	1	AC circuit breaker, 2-pole, 15A, 250 Vac
5*	DCB	JR-709	1	DC circuit breaker, 1-pole, 70A, 125Vdc
-	DCB	JR-800	1	DC circuit breaker, 2-pole, 70A, 125Vdc
-	CBA	NBC-2155	1	Analog meter control board, telecommunications
-	CBA	NBC-2157	1	Analog meter control board, utility
-	CBA	NBC-2158	1	Digital meter control board, utility
19	RR	T-1901	1	Resonant reactor
-	TS1	JL-918	1	AC input terminal strip
-	TS2	JL-898	1	DC output terminal strip
55	GND	JH-1315	1	Ground lug
21	PFX	T-1897	1	Power transformer
11	C1	JC-186	2	Filter capacitor, 145,000 μ F, 40 Vdc
11	C2	JC-186	1	Filter capacitor, 145,000 μ F, 40 Vdc
10**	RA	JS-881	1	Triac/rectifier assembly
18	RC	JC-61	1	Resonant capacitor, 18 μ F, 660 Vdc
12	R1, R2	JE-630	1	Resonant resistor, 1.5 ohm, 110W
19	FC	T-1903	1	Filter choke
-	AS	JM-249	1	Ammeter shunt, 75A, 50mV
**	TRIAC	JS-826	1	Triac, 35A, 600V
-	-	JS-878	1	Diode module, 60A, 400V
17	AXF	JT-276	1	Transformer, 36V C.T., 30VA
-	-	JA-2031-150V	1	Surge protector
-	HVSD	NBC-2341-24	1	Secondary high-voltage shutdown board

* "E" suffix models use a single-pole breaker. "U" suffix models use a double-pole breaker.

**Indicates recommended spare part. Item numbers refer to drawings in Chapter 7.

OBSOLETE - FOR RECORD ONLY

HRT RECTIFIER SINGLE-PHASE INPUT MANUAL

REPLACEMENT PARTS FOR HRT 48 AC 15E AND HRT 48 AC 15U

ITEM	SCHEMATIC LEGEND	C & D PART NUMBER	QUANTITY	DESCRIPTION
-	-	-	-	Cabinet outline
41	-	JN-38A	1	Name plate
-	AM	JM-241	1	Ammeter, 20A, 50mV, YEW
-	VM	JM-240	1	Voltmeter, 80V YEW
4	ACB	JR-752	1	AC circuit breaker, 2-pole, 10A, 250 Vac
5*	DCB	JR-754	1	DC circuit breaker, 1-pole, 20A, 125Vdc
5*	DCB	JR-797	1	DC circuit breaker, 2-pole, 20A, 125Vdc
.*	CBA	NBC-2155	1	Analog meter control board, telecommunications
.*	CBA	NBC-2157	1	Analog meter control board, utility
-	CBA	NBC-2158	1	Digital meter control board, utility
19	RR	T-1912	1	Resonant reactor
-	TS1	JL-918	1	AC input terminal strip
-	TS2	JL-898	1	DC output terminal strip
55	GND	JH-1315	1	Ground lug
21	PFX	T-1896	1	Power transformer
11	C1	JC-184	1	Filter capacitor, 64,000 μ F, 75 Vdc
11	C2	JC-184	1	Filter capacitor, 64,000 μ F, 75 Vdc
10	RA	JS-882	1	Triac/rectifier assembly
18**	RC	JC-32	1	Resonant capacitor, 12 μ F, 660 Vdc
12	R1, R2	JE-630	1	Resonant resistor, 1.5 ohm, 110W
19	FC	T-1902	1	Filter choke
-	AS	JM-247	1	Ammeter shunt, 20A, 50mV
.*	TRIAC	JS-826	1	Triac, 35A, 600V
-	-	JS-883	1	Diode module, 30A, 400V
17	AXF	JT-276	1	Transformer, 36V C.T., 30VA
-	-	JA-2031-150V	1	Surge protector
-	HVSD	NBC-2341-24	1	Secondary high-voltage shutdown board

**Indicates recommended spare part. Item numbers refer to drawings in Chapter 7.

REPLACEMENT PARTS FOR HRT 48 AC 30E AND HRT 48 AC 30U

ITEM	SCHEMATIC LEGEND	C & D PART NUMBER	QUANTITY	DESCRIPTION
-	-	-	-	Cabinet outline
41	-	JN-38A	1	Name plate
-	AM	JM-242	1	Ammeter, 50A, 50mV, YEW
-	VM	JM-240	1	Voltmeter, 80V YEW
4	ACB	JR-749	1	AC circuit breaker, 2-pole, 20A, 250 Vac
5*	DCB	JR-750	1	DC circuit breaker, 1-pole, 40A, 125Vdc
5*	DCB	JR-799	1	DC circuit breaker, 2-pole, 40A, 125Vdc
-	CBA	NBC-2155	1	Analog meter control board, telecommunications
-	CBA	NBC-2157	1	Analog meter control board, utility
-	CBA	NBC-2158	1	Digital meter control board, utility
19	RR	T-1899	1	Resonant reactor
-	TS1	JL-918	1	AC input terminal strip
-	TS2	JL-898	1	DC output terminal strip
55	GND	JH-1315	1	Ground lug
21	PFX	T-1895	1	Power transformer
11	C1	JC-184	2	Filter capacitor, 64,000 μ FD, 75 Vdc
11	C2	JC-184	1	Filter capacitor, 64,000 μ FD, 75 Vdc
10**	RA	JS-882	1	Triac/rectifier assembly
18	RC	JC-118	1	Resonant capacitor, 25 μ FD, 660 Vdc
12	R1, R2	JE-637	2	Resonant resistor, 2.25 ohm, 155W
19	FC	T-1902	1	Filter choke
-	AS	JM-248	1	Ammeter shunt, 50A, 50mV
.*	TRIAC	JS-826	1	Triac, 35A, 600V
-	-	JS-883	1	Diode module, 30A, 400V
17	AXF	JT-276	1	Transformer, 36V C.T., 30VA
-	-	JA-2031-150V	1	Surge protector
-	HVSD	NBC-2341-24	1	Secondary high-voltage shutdown board

* "E" suffix models use a single-pole breaker. "U" suffix models use a double-pole breaker.

**Indicates recommended spare part. Item numbers refer to drawings in Chapter 7.

OBSOLETE - FOR RECORD ONLY

HRT RECTIFIER SINGLE-PHASE INPUT MANUAL

REPLACEMENT PARTS FOR HRT 48 AC 50E AND HRT 48 AC 50U

ITEM	SCHEMATIC LEGEND	C & D PART NUMBER	QUANTITY	DESCRIPTION
-	-	-	-	Cabinet outline NBC-2140 Sheet 1
41	-	JN-38A	1	Name plate
-	AM	JM-243	1	Ammeter
-	VM	JM-240	1	Voltmeter
71	ACB	JR-721	1	AC circuit breaker, 2-pole, 30A
70*	DCB	JR-709	1	DC circuit breaker, 1-pole, 70A
-	DCB	JR-800	1	DC circuit breaker, 2-pole, 70A
-	CBA	NBC-2155	1	Analog meter control board, telecommunications
-	CBA	NBC-2157	1	Analog meter control board, utility
-	CBA	NBC-2158	1	Digital meter control board, utility
17	RR	T-1870	1	Resonant reactor
27	TS1	JL-918	1	AC input terminal strip
33	TS2	JL-898	1	DC output terminal strip
-	GND	JH-1278	1	Ground lug
15	PFX	T-1850	1	Power transformer
14	C1	JC-184	5	Filter capacitor, 64,000 μ F, 75 Vdc
18**	RA	JC-852	1	Rectifier Assembly
19	RC	JS-117	1	Resonant capacitor
20	RC	JC-32	1	Resonant capacitor
23	R1, R2	JE-51	2	Resonant resistor
16	FC	T-1870	1	Filter choke
-	AS	JM-249	1	Ammeter shunt
31**	TRIAC	JS-826	1	Triac
18A	-	JS-548	2	Diode
17	AXF	JT-276	1	Transformer, 36V C.T., 30VA
18B	-	JA-2031-150V	1	Surge protector
-	-	NBC-2341-24	1	Secondary high-voltage shutdown board

**Indicates recommended spare part. Item numbers refer to drawings in Chapter 7.

REPLACEMENT PARTS FOR HRT 24 AC 100E AND HRT 24 AC 100U

ITEM	SCHEMATIC LEGEND	C & D PART NUMBER	QUANTITY	DESCRIPTION
-	-	-	-	Cabinet outline, NBC-2140 Sheet 1
41	-	JN-38A	1	Name plate
-	AM	JM-244	1	Ammeter
-	VM	JM-239	1	Voltmeter
71	ACB	JR-721	1	AC circuit breaker, 2-pole, 30A
70*	DCB	JR-706	1	DC circuit breaker, 1-pole, 125A
-	DCB	JR-801	1	DC circuit breaker, 2-pole, 125A
-	CBA	NBC-2155	1	Analog meter control board, telecommunications
-	CBA	NBC-2157	1	Analog meter control board, utility
-	CBA	NBC-2158	1	Digital meter control board, utility
17	RR	T-1842	1	Resonant reactor
27	TS1	JL-918	1	AC input terminal strip
33	TS2	JL-898	1	DC output terminal strip
51	GND	JH-1315	1	Ground lug
15	PFX	T-1841	1	Power transformer
14	C1	JC-135	4	Filter capacitor, 48,000 μ F, 40 Vdc
14	C2	JC-186	1	Filter capacitor, 145,000 μ F, 40 Vdc
18**	RA	JS-852	1	Rectifier Assembly
19	RC	JC-117	1	Resonant capacitor, 30 μ F, 660 Vdc
20	RC	JC-32	1	Resonant capacitor, 12 μ F, 660 Vdc
23	R1, R2	JE-51	2	Resonant resistor, 1.5 ohm, 225W
16	FC	T-1845	1	Filter choke
-	AS	JM-250	1	Ammeter shunt, 150A, 50mV
31**	TRIAC	JS-826	1	Triac, 35A, 600V
18A	-	JS-548	2	Diode 125A, 300V
26	AXF	JT-276	1	Transformer, 36V C.T., 30VA
18B	-	JA-2031-150V	1	Surge protector
-	HVSD	NBC-2341-24	1	Secondary high-voltage shutdown board

* "E" suffix models use a single-pole breaker. "U" suffix models use a double-pole breaker.

**Indicates recommended spare part. Item numbers refer to drawings in Chapter 7.

OBSOLETE - FOR RECORD ONLY

HRT RECTIFIER SINGLE-PHASE INPUT MANUAL

REPLACEMENT PARTS FOR HRT 24 AC 200E

ITEM	SCHEMATIC LEGEND	C & D PART NUMBER	QUANTITY	DESCRIPTION
-	-	-	-	Cabinet outline NBC-2258 Sheet 1
41	-	JN-38A	1	Name plate
-	AM	JM-245	1	Ammeter
-	VM	JM-239	1	Voltmeter
-	ACB	JR-556	1	AC circuit breaker, 2-pole, 50A
-	DCB	JR-707	1	DC circuit breaker, 1-pole, 250A
_*	CBA	NBC-2155	1	Analog meter control board, telecommunications
10	RR	T-1893	1	Resonant reactor
-	TS1	JL-704	1	AC input terminal strip
-	TS2	JL-607	1	DC output terminal strip
-	GND	JH-1315	1	Ground lug
2	PFX	T-1894	1	Power transformer
6	C1	JC-135	10	Filter capacitor, 48,000 μ F, 40 Vdc
6	C2	JC-186	2	Filter capacitor, 145,000 μ F, 40 Vdc
4*	RA	JS-869	1	Rectifier Assembly
-	RC	JC-117	2	Resonant capacitor, 30 μ F, 600 V
8	R1, R2	JE-51	2	Resonant resistor
3	FC	T-1892	1	Filter choke
-	AS	JM-251	1	Ammeter shunt
_*	TRIAC	JS-826	1	Triac
4A	-	JS-654	2	Diode module, 300A, 300V
26	AXF	JT-276	1	Transformer, 36V C.T., 30VA
4B	-	JA-2031-150V	1	Surge protector
-	HVSD	NBC-2341-24	1	Secondary high-voltage shutdown board

**Indicates recommended spare part. Item numbers refer to drawings in Chapter 7.

REPLACEMENT PARTS FOR HRT 48 AC 100E AND HRT 48 AC 100U

ITEM	SCHEMATIC LEGEND	C & D PART NUMBER	QUANTITY	DESCRIPTION
-	-	-	-	Cabinet outline, NBC-3000 Sheet 1
41	-	JN-38A	1	Name plate
-	AM	JM-244	1	Ammeter
-	VM	JM-240	1	Voltmeter
-	ACB	JR-556	1	AC circuit breaker, 2-pole, 50A
_*	DCB	JR-706	1	DC circuit breaker, 1-pole, 125A
_*	DCB	JR-801	1	DC circuit breaker, 2-pole
-	CBA	NBC-2155	1	Analog meter control board, telecommunications
-	CBA	NBC-2157	1	Analog meter control board, utility
-	CBA	NBC-2158	1	Digital meter control board, utility
-	RR	T-1817	1	Resonant reactor
-	TS1	JL-704	1	AC input terminal strip
-	TS2	JL-898	1	DC output terminal strip
-	GND	JH-1278	1	Ground lug
2	PFX	T-1816	1	Power transformer
-	C1, C2	JC-184	8	Capacitors
4**	RA	JS-828	1	Rectifier Assembly
_*	RC	RT-87	1	Resonant capacitor, 2 μ F, 660 Vdc
_*	RC	JC-118	1	Resonant capacitor, 25 μ F, 660 Vdc
_*	RC	JC-117	1	Resonant resistor, 30 μ F, 660 Vdc
8	R1, R2	JE-51	2	Resonant resistor
3	FC	T-1818	1	Filter choke
23	AS	JM-250	1	Ammeter shunt
_*	TRIAC	JS-826	1	Triac
18A	-	JS-548	2	Diode 125A, 300Vdc
-	AXF	JT-276	1	Transformer, 36V C.T., 30VA
18B	-	JA-2031-150V	1	Surge protector
-	HVSD	NBC-2341-24	1	Secondary high-voltage shutdown board

* "E" suffix models use a single-pole breaker. "U" suffix models use a double-pole breaker.

**Indicates recommended spare part. Item numbers refer to drawings in Chapter 7.




CHAPTER SEVEN: DRAWINGS

NBC-2418
NBC-2413
NBC-2420
NBC-2419
NBC-2470
NBC-2465
MBC-5524
MBC-5490
NBC-2417
NBC-2416
NBC-2324
NBC-2327
NBC-2414
NBC-2406
NBC-2379
NBC-2380
NBC-2415
NBC-2381
NBC-2325
NBC-2391
NBC-2378
NBC-2326
MBC-5488
KBC-5295
KBC-5296
MBC-5466
MBC-5542
MBC-5471
MBC-5543
MBC-5333
MBC-5545
NBC-2486
NBC-2486SD
NBC-2169
NBC-2170

OBSOLETE - FOR RECORD ONLY



OBSOLETE - FOR RECORD ONLY

OBSOLETE - FOR RECORD ONLY



SECTION A-A
SCALE 1:1

- NOTES:
- ITEM 47 TIED TO ITEM 16.
 - ITEM 49 TIED TO THE WIRING OF ITEM 4.



62	SCREW	36	BRACKET
61	WASHER	35	SNAP BUSHING
60	STANDOFF	34	CAP PLUG
59	CIRCUIT BOARD	33	WASHER
58	MOV ASSEMBLY	32	RECEPTACLE
57	MOV ASSEMBLY	31	WASHER, CUP AND RETAINER
56	MOV ASSEMBLY	30	SPRING
55	GROUND LUG	29	FASTENER
54	LABEL, GROUND	28	SCREW
53	TAG, GROUND ONLY	27	SCREW
52	LABEL, CAUTION	26	SCREW
51	LABEL, EMERGENCY SERVICE	25	NUT
50	LABEL, HIGH VOLTAGE	24	NUT
49	VOLTAGE CARD	23	NUT
48	TAG, INSTRUCTION & INSTALLATION	22	NUT
47	TAG, VOLTAGE SETTING	21	TRANSFORMER, POWER
46	LABEL (GRD)	20	CLAMP
45	LABEL (NEG)	19	REACTOR/CHOKE ASSEMBLY
44	LABEL (POS)	18	CAPACITOR
43	LABEL (TB3)	17	TRANSFORMER, CONTROL
42	LABEL (TB2)	16	PANEL, INSTRUMENT
41	LABEL (TB1)	15	BRACKET, BREAKER
40	HOLE PLUG	14	NAMEPLATE
39	HARNESS	13	SCREW
38	CAPACITOR ASSEMBLY	12	RESISTOR
37	WASHER	11	CAPACITOR ASSEMBLY
36	BRACKET	10	HEATSINK ASSEMBLY
35	SNAP BUSHING	9	BUMPER, SNAP-IN
34	CAP PLUG	8	GROUND WIRE ASSEMBLY
33	WASHER	7	ANGLE, RACK/WALL MOUNTING
32	RECEPTACLE	6	PANEL, TOP
31	WASHER, CUP AND RETAINER	5	DC BREAKER
30	SPRING	4	AC BREAKER
29	FASTENER	3	BACK PANEL
28	SCREW	2	FRONT DOOR ASSEMBLY
27	SCREW	1	CABINET, WELDMENT
26	SCREW	1	DESCRIPTION

ISSUE #	DESCRIPTION	ISS. BY ISS. DATE	APP. BY APP. DATE
1	SEE ECN 10059 (ADOBE PROCESSED 4/4/02; OLD FILE NAME=Nbc2418)	KEL	MCM 03/24/94
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON:			
HOLES		+0.004 -0.002	APPROVALS DRAWN G. D. HAWKINS
FRACTIONS		±1/32	CHECKED D. B. WILSON
DECIMALS (XX)		±0.020	APPROVED D. H. MUHLRAD
DECIMALS (XXX)		±0.010	APPROVED
ANGLES		±1/2°	DATE 06/10/91
SQUARE CORNERS AND ANGLES ARE 90° UNLESS OTHERWISE SPECIFIED.			
MATERIAL:			
FINISH:			
PROPRIETARY INFORMATION NOT TO BE COPIED, USED OR DISCLOSED WITHOUT PRIOR WRITTEN PERMISSION FROM C&D TECHNOLOGIES, INC.			
C&D TECHNOLOGIES Power Solutions			
GENERAL ARRANGEMENT HRT CABINET 12-1/4H			
SIZE B	DOC TYPE / NUMBER NBC-2418		ISSUE 1
SCALE: N/A	SHEET: 1 OF 1	FILE NAME: NBC2418_SH1_ISS1	



OBSOLETE - FOR RECORD ONLY

OBSOLETE - FOR RECORD ONLY

OBSOLETE - FOR RECORD ONLY

OBSOLETE - FOR RECORD ONLY

REV	DESCRIPTION	DATE	APPROVED
1	SEE ECN 9413	12-4-91	DELL
2	SEE ECN 9975	12/13/93	DELL
3	SEE ECN 10352	KEL 12/28/94	DELL



CABINET FEATURES

REMOVABLE FRONT PANEL	FOR ACCESS TO INSTRUMENT PANEL TO MAKE MINOR ADJUSTMENTS AND TESTING.
REMOVABLE TOP & BACK PANELS	FOR ACCESS TO CABINET FOR PREVENTATIVE MAINTENANCE AND SERVICEABLY.
REMOVABLE CAPACITOR TRAY ASSY.	FOR PERIODIC REPLACEMENT OF CANISTERS.



NOTES:

1. RELAY RACK MOUNTING BRACKETS AND LIFTING EYE MAY VARY FROM THIS ILLUSTRATION, SEE WORK SHEET FOR PART NUMBER.
2. THE APPEARANCE OF ITEM 70 MAY VARY FROM THIS ILLUSTRATION.

ISSUE	DATE	BY
1	5-25-91	4
2	7-25-91	4
3	7-25-91	4

CD TECHNOLOGIES, INC. Power Solutions	
GENERAL ARRANGEMENT HRT SERIES 17-1/2 INCH CABINET.	
NBC-2413	
SHEET 1 OF 2	

OBSOLETE - FOR RECORD ONLY



- CABINET FEATURES**
- REMOVABLE FRONT PANEL FOR ACCESS TO CONTROL PANEL TO MAKE MINOR ADJUSTMENTS AND TESTING.
 - REMOVABLE FRONT HALF FOR PREVENTATIVE MAINTENANCE AND SERVICEABILITY

DRYER
CHECKED
DATE 7-29-81
BY J. J. Miller
10/12/81

MATERIAL


APPROVED

CD TECHNOLOGIES, INC.
Power Solutions

GENERAL ARRANGEMENT
HRT04A0200E

NBC-2420

SCALE 1/2" = 1" REV. NO. 1 SHEET 1 OF 2



56	COVER PLATE	
55	BUSHING, SNAP-IN	(TIED TO UNIT)
54	CAP LUG	
53	COVER PLATE	
52	MOV ASSEMBLY	
51	MOV ASSEMBLY	
50	LOCK WASHER	
49	SCREW	
48	STANDOFF	
47	CIRCUIT BOARD	

RESONANT REACTOR LEADS ARE TO BE DRESSED AWAY FROM THE RESONANT RESISTOR ITEM 8.

- 46 MOV ASSEMBLY
- 45 DECAL, GROUND
- 44 BUSBAR (BRAIDED)
- 43 TAG, WIRE FOR GND ONLY
- 42 TAG, BMSR SERVICE
- 41 NAMEPLATE, CAUTION
- 40 DECAL, HIGH VOLTAGE
- 39 VOLTAGE CARDS
- 38 TAG, INST. SERVICE INSTALLATION
- 37 TAG, VOLTAGE SETTING
- 36 NAMEPLATE
- 35 NUT, SELF RETAINING
- 34 NUT
- 33 NUT
- 32 NUT
- 31 SCREW
- 30 SCREW
- 29 LUG
- 28 SCREW
- 27 SCREW
- 26 SCREW
- 25 WASHER
- 24 SCREW
- 23 TERMINAL PANEL
- 22 EYEBOLT
- 21 BUMPER, SNAP-IN
- 20 CAPLUG
- 19 BUSHING, SNAP-IN (TIED TO UNIT)
- 18 SHUNT
- 17 RETAINING CLIP
- 16 FRONT DOOR
- 15 RACK MTO, ANGLE
- 14 FRONT HALF CAP. WELDMENT
- 13 TOP PANEL
- 12 HARNESS ASSY.
- 11 INSTRUMENT PANEL
- 10 REACTOR
- 9 ACCESSORY PANEL
- 8 RESISTOR ASSY.
- 7 RESONANT CAP. ASSY.
- 6 FILTER ASSY.
- 5 LOCK PANEL ASSY.
- 4 RECTIFIER ASSY.
- 3 CHOKE



NOTE: SEE WIRING DIAGRAM FOR INSTALLATION OF ITEMS 48, 51, AND 52

ISSUE	DATE	QTY
CASH ON HAND	11-2-71	✓
PURCHASE	11-2-71	✓

ITEM	DESCRIPTION
2	TRANSFORMER
1	BACK HALF CAB. WELDMENT
1	NBC-24

ORD ONLY

OBSOLETE RECORD ONLY



CABINET FEATURES


- REMOVABLE FRONT PANEL FOR ACCESS TO CONTROL PANEL TO MAKE MINOR ADJUSTMENTS AND TESTING.
- REMOVABLE FRONT HALF FOR PREVENTATIVE MAINTENANCE AND SERVICEABILITY.

OBSOLETE RECORD ONLY

ISSUED		DATE	BY
REVISION		DATE	BY
MATERIAL		DATE	BY
APPROVED		DATE	BY
SCALE		1/2	
REV. NO.		2	
SHEET		1	OF 2



CD TECHNOLOGIES, INC.
Power Solutions
GENERAL ARRANGEMENT
HMT48AC100E, POS GND
NBC-2419

NBC-2419



SEC. 6, 9, 10 MAY BE SET ASIDE

[illegible]



- CABINET FEATURES
- REMOVABLE FRONT PANEL FOR ACCESS TO CONTROL PANEL TO MAKE MINOR ADJUSTMENTS AND TESTING.
 - REMOVABLE FRONT HALF FOR PREVENTATIVE MAINTENANCE AND SERVICEABLY.

OPTIONAL PANEL SUPPORTS FOR BEST RECORD KEEPING

Scale: 1/2" = 1"

DATE: 11-25-91

DESIGNED BY: [Signature]

CHECKED BY: [Signature]


APPROVED BY: [Signature]

CD TECHNOLOGIES, INC.
Power Solutions

GENERAL ARRANGEMENT
MT48AC100E, NEG GND

NBC-2470

SCALE 1/2" REV. NO. SHEET 1 of 2




14-00000 (Rev. 10-20-76) PREPARED BY: <u>W. J. B. G. G. G.</u> CHECKED BY: <u>W. J. B. G. G.</u> DATE: <u>10-20-76</u>	DESIGNED BY: <u>W. J. B. G. G.</u> CHECKED BY: <u>W. J. B. G. G.</u> DATE: <u>10-20-76</u>	DRAWN BY: <u>W. J. B. G. G.</u> CHECKED BY: <u>W. J. B. G. G.</u> DATE: <u>10-20-76</u>	TITLE: <u>GENERAL ARRANGEMENT</u> <u>AT 84C100E, NEG GND</u>
APPROVED BY: <u>W. J. B. G. G.</u> DATE: <u>10-20-76</u>			SCALE: <u>1/2</u> REV. <u>2</u> OF <u>2</u>

OBSOLETE FOR RECORD ONLY OR ONE RECORD ONLY

NOTES: THIS PRINT AND THE INFORMATION THEREON IS THE PROPERTY OF C.D. TECHNOLOGIES, INC. IT IS TO BE USED FOR THE PURPOSES SPECIFIED HEREIN ONLY. IT IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF C.D. TECHNOLOGIES, INC.

REV.	DATE	BY	CHKD.	APPROVED
1	12/13/95	EEB/CLV	94	5
2	10/5/95	SEE EBN	10555	



CABINET FEATURES

- REMOVABLE FRONT PANEL FOR ACCESS TO CONTROL PANEL TO MAKE MINOR ADJUSTMENTS AND TESTING.
- REMOVABLE FRONT HALF FOR PREVENTATIVE MAINTENANCE AND SERVICEABILITY.

GENERAL ARRANGEMENT

CD TECHNOLOGIES, INC.


HRT48AG100J

NBC-2465

SCALE 1/2 IN. = 1 FT. SHEET 1 OF 2

OBSOLETE FOR RECORD ONLY

REMARK: THIS PRINT AND THE INFORMATION HEREON IS THE PROPERTY OF C & I TECHNOLOGIES, INC. AND IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF C & I TECHNOLOGIES, INC.



REVISIONS			
NO.	DESCRIPTION	DATE	APPROVED
1	ECN 10 35	2/13/91	CHW
2	ECN 10 35	en	2/14/91

64	COVER PLATE
63	COVER PLATE
62	BUSHING, SNAP-IN
61	PLUG
59	MOV ASSEMBLY
58	MOV ASSEMBLY
57	LUG
56	LOCKWASHER
55	STANDOFF
54	MOV ASSEMBLY
53	DECAL NEG
52	DECAL POS
51	DECAL TB2
50	DECAL TB1
49	NUT, SELF RETAINER
48	LABEL-CAUTION
47	LABEL-EMER SERVICE
46	LABEL-HIGH VOLTAGE
45	TAG-GRID ONLY
44	TAG-VOLTAGE CONNECTED FOR
43	TAG-INSTRUCTION & INSTALLATION
42	TAG-VOLTAGE SETTING
41	NAME PLATE
40	WASHER
39	NUT
38	NUT
37	NUT
36	SCREW
35	SCREW
34	SCREW
33	SCREW
32	SCREW
31	SCREW
30	SCREW
29	SCREW
28	SCREW
27	EYE BOLT
26	BUMPER, SNAP-IN
25	CAPPLUG
24	BUSHING, SNAP IN
23	SHUNT
22	FRONT PNL RETAINING CLIP
21	REMOVABLE FRONT DOOR
20	RACK MTG ANGLE
19	FRONT HALF CAB WELDMENT
18	PERFORATED TOP
17	HARNASS ASSEM
16	INSTRUMENT PANEL
15	INSTRUMENT PANEL
14	INSTRUMENT PANEL
13	CIRCUIT BOARD
12	SIDE RAIL RM
11	ACCESSORY PANEL
10	BOLT, MICA/CTRG WASHERS
9	RESISTOR BRACKET MTG.
8	RESISTOR
7	RESN CAP ASSY
6	FILTER ASSY
5	BACK PANEL ASSY.
4	RECTIFIER ASSY
3	CHOKO
2	TRANSFORMER
1	BACK HALF CAB WELDMENT


NOTE: SEE WIRING DIAGRAM DRAWING FOR ITEMS 54, 55 & 59.
SEC. 6, 9, 10 MAY BE IN AN ASSEMBLY.

DESIGNED BY	DATE	2/13/91
DRAWN BY	DATE	2/13/91
CHECKED BY	DATE	2/13/91
APPROVED BY	DATE	2/13/91
SCALE	1/2	
SHEET	2 OF 2	


GENERAL ARRANGEMENT
HRT48AC100U
NBC-2465

OBSOLETE

REVISION LEVEL	DESCRIPTION	REV. BY REV. DATE	APPROVED BY APPROVED DATE
1	SEE ECN 12520	KEL 09/01/99	MM 9/28/99



REVISIONS			
REVISION LEVEL	DESCRIPTION	REV. BY REV. DATE	APPROVED BY APPROVED DATE
1	SEE ECN 12520	KEL 09/01/99	<i>mm</i> 9/28/99



NOTES:

- THE JUMPER FROM CBA-J3-2 IS CONNECTED TO ONE OF THESE TERMINALS ACCORDING TO THE NOMINAL OUTPUT VOLTAGE OF THE UNIT.
- C3 MAY NOT BE PRESENT IN ALL MODELS.
- J3 ON CBA IS MARKED OPPOSITE OF CONNECTOR MARKINGS. EXAMPLE: CBA-J3-2 IS CONNECTOR 21 AND CBA-J3-20 IS CONNECTOR 3.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON:			
FRACTIONS	DECIMALS	ANGLES	
± 1/32	0.020 0.010	± 1°	
MATERIAL:			
BLANK SIZE:			

DISTRIBUTION CODE:	
APPROVALS	DATE
DRAWN G. D. HAWKINS	05/09/91
CHECKED D. B. WILSON	07/30/91
APPROVED D. H. HUMPHREY	07/30/91
APPROVED	

GED TECHNOLOGIES, INC. Power Solutions			
SCHEMATIC DIAGRAM, HRT UTILITY 2P DC BREAKER WITH ANALOG METERS			
SIZE	DATING	DOC. TYPE / NUMBER	REVISION
B	STANDARD	NEO 4490	1
SCALE: NONE	SHEET: 1 OF 1	FILE NAME: MBC5490_SHT_1_ISS_1	

OBSOLETE - FOR RECORD ONLY


OBSOLETE - FOR RECORD ONLY

OBSOLETE - FOR RECORD ONLY

NOTICE: THIS PRINT AND THE INFORMATION SHOWN THEREON IS THE PROPERTY OF C&D TECHNOLOGIES, INC. AND IS BEING FURNISHED AS A CONFIDENTIAL DISCLOSURE. IT MAY NOT BE DELIVERED TO OTHERS NOR REPRODUCED FOR GENERAL CIRCULATION WITHOUT THE WRITTEN APPROVAL OF C&D TECHNOLOGIES, INC.



NOTES:

1. ALL WIRES ARE BLACK UNLESS OTHERWISE SPECIFIED.
2. ALL WIRES ARE #18 AWG STRANDED OR SELF LEADS UNLESS OTHERWISE SPECIFIED.
3. AC BREAKER TERMINAL LOCATIONS MAY BE DIFFERENT THAN SHOWN. TERMINAL IDENTIFIERS (A, B, C, D, 1, 2) WILL BE CORRECT.
4. ALL WIRES SPECIFIED WITH "*" ARE SELF LEADS.
5. TB1-2 IS LINE 1. TB1-3 IS LINE 2 FOR 208V & 240V. TB1-3 IS NEUTRAL FOR 120V.
6. CIRCUIT BREAKERS ARE SHOWN FROM FRONT OF CABINET.
7. FOR HRT24AC50E, USE #8 AWG WIRE.
8. WIRE NUMBERS USED:
POWER: 1 THROUGH 25
CONTROL: 50 THROUGH 64, 67 THROUGH 87, 105, 106
LIGHTNING ARRESTER: 100, 101, 102
9. SP4 IS PART OF RECTIFIER (RA) ASSEMBLY.
10. J3 ON CBA IS MARKED OPPOSITE OF CONNECTOR MARKINGS. EXAMPLE: CBA-J3-2 IS CONNECTOR 21 AND CBA-J3-20 IS CONNECTOR 3.



48 VDC OUTPUT CONNECTION SHOWN.
FOR 24 VDC OUTPUT, CONNECT CBA-
TO CBA-J3-7.

REVISIONS			
REVISION LEVEL	DESCRIPTION	REV. BY REV. DATE	APPROVED BY APPROVED DATE
1	SEE ECN 12520	KEL 09/10/99	MM 9/28/99
2	SEE ECN 13430	JPR 4/23/01	MM 05/03/01
3	SEE ECN 15204 Added BusBar to TB2-1	KEL 08/01/05	MCM 10/4/05



DISTRIBUTION CODE:		<div>ESDTECHNOLOGIES, INC.</div> <div>Power Solutions</div>									
APPROVALS		DATE		WIRING DIAGRAM HRT CABINET 12-1/4H POSITIVE GROUND WITH ANALOG METER							
DRAWN G. D. HAWKINS		06/04/91									
CHECKED D. B. WILSON		11/11/91									
APPROVED D. H. MUHLRAD		11/11/91									
APPROVED											
		SIZE B	RATING STANDARD	DOC TYPE / NUMBER NBC-2417	REVISION 3						
		SCALE: NONE		SHEET: 1 OF 1	FILE NAME: NBC2417_SHT_1_ISS_3						
BLANK SIZE:		UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES ± TOLERANCES ON: <table><tr><td>FRACTIONS</td><td>DECIMALS</td><td>ANGLES</td></tr><tr><td>±1/32</td><td>0.020</td><td>±1°</td></tr></table>				FRACTIONS	DECIMALS	ANGLES	±1/32	0.020	±1°
FRACTIONS	DECIMALS	ANGLES									
±1/32	0.020	±1°									

OBSOLETE¹ - FOR RECORD ONLY


OBSELETE - FOR RECORD ONLY

OBSOLETE - FOR RECORD ONLY

NOTICE: THIS PRINT AND THE INFORMATION THEREON IS THE PROPERTY OF C&D TECHNOLOGIES, INC. AND IS BEING FURNISHED AS A CONFIDENTIAL DISCLOSURE. IT MAY NOT BE DELIVERED TO OTHERS NOR REPRODUCED FOR GENERAL CIRCULATION WITHOUT THE WRITTEN APPROVAL OF C&D TECHNOLOGIES, INC.

REVISIONS


REVISION LEVEL	DESCRIPTION	REV. BY	REV. DATE	APPROVED DATE
1	SEE ECN 10352	KEL	02/27/95	MCM 02/27/95
2	SEE ECN 12520	KEL	09/10/99	MM 9/28/99



NOTICE: THIS PRINT AND THE INFORMATION SHOWN THEREON IS THE PROPERTY OF C&D TECHNOLOGIES, INC. AND IS BEING FURNISHED AS A CONFIDENTIAL DISCLOSURE. IT MAY NOT BE DELIVERED TO OTHERS NOR REPRODUCED FOR GENERAL CIRCULATION WITHOUT THE WRITTEN APPROVAL OF C&D TECHNOLOGIES, INC.

REVISIONS


REVISION LEVEL	DESCRIPTION	REV. BY	REV. DATE	APPROVED BY
1	SEE ECN 10352	KEL	02/27/95	MCM 02/27/95
2	SEE ECN 12520	KEL	09/10/99	MJM 9/28/99



NOTICE: THIS PRINT AND THE INFORMATION SHOWN THEREON IS THE PROPERTY OF C&D TECHNOLOGIES, INC. AND IS BEING FURNISHED AS A CONFIDENTIAL DISCLOSURE. IT MAY NOT BE DELIVERED TO OTHERS NOR REPRODUCED FOR GENERAL CIRCULATION WITHOUT THE WRITTEN APPROVAL OF C&D TECHNOLOGIES, INC.


REVISIONS

REVISION LEVEL	DESCRIPTION	REV. BY	REV. DATE	APPROVED BY	APPROVED DATE
1	SEE ECN 10054	KEL	03/24/94	MCM	03/24/94
2	SEE ECN 10352	KEL	02/27/95	MCM	02/27/95
3	SEE ECN 12520	KEL	09/16/99	MCM	9/24/99



NOTICE: THIS PRINT AND THE INFORMATION SHOWN THEREON IS THE PROPERTY OF C&D TECHNOLOGIES, INC. AND IS BEING FURNISHED AS A CONFIDENTIAL DISCLOSURE. IT MAY NOT BE DELIVERED TO OTHERS NOR REPRODUCED FOR GENERAL CIRCULATION WITHOUT THE WRITTEN APPROVAL OF C&D TECHNOLOGIES, INC.


REVISIONS			
REVISION LEVEL	DESCRIPTION	REV. BY REV. DATE	APPROVED BY APPROVED DATE
2	SEE ECN 13433	JPR 04/23/01	MM 05/03/01



NOTICE: THIS PRINT AND THE INFORMATION SHOWN THEREON IS THE PROPERTY OF C&D TECHNOLOGIES, INC. AND IS BEING FURNISHED AS A CONFIDENTIAL DISCLOSURE. IT MAY NOT BE DELIVERED TO OTHERS NOR REPRODUCED FOR GENERAL CIRCULATION WITHOUT THE WRITTEN APPROVAL OF C&D TECHNOLOGIES, INC.

REVISIONS



REVISION LEVEL	DESCRIPTION	REV. BY REV. DATE	APPROVED BY APPROVED DATE
1	SEE ECN 12520	KEL 09/13/99	mm 9/28/97



NOTICE: THIS PRINT AND THE INFORMATION SHOWN THEREON IS THE PROPERTY OF C&D TECHNOLOGIES, INC. AND IS BEING FURNISHED AS A CONFIDENTIAL DISCLOSURE. IT MAY NOT BE DELIVERED TO OTHERS NOR REPRODUCED FOR GENERAL CIRCULATION WITHOUT THE WRITTEN APPROVAL OF C&D TECHNOLOGIES, INC.

REVISIONS

REVISION LEVEL	DESCRIPTION	REV. BY REV. DATE	APPROVED BY APPROVED DATE
1	SEE ECN 9465		DBW 05/12/92
2	SEE ECN 10352	KEL 02/27/95	MCM 02/27/95
3	SEE ECN 12520	KEL 09/16/99	MCM 09/18/99
4	SEE ECN 13442	KEL 04/26/01	MM 04/26/01



AC VOLTAGE CONNECTION VARIATIONS
(ALL JUMPER WIRES #10 AWG)

LEGEND

- A1, A2 ANODES, RECTIFIER ASSEMBLY
ACB AC CIRCUIT BREAKER
AM AMMETER
AS AMMETER SHUNT
AXF AUXILIARY TRANSFORMER
BB1 BUS BAR
C1 DC FILTER CAPACITOR-INPUT
C2 DC FILTER CAPACITOR-OUTPUT
C3 CAPACITOR
CBA CONTROL BOARD
DCB DC CIRCUIT BREAKER
FC DC FILTER CHOKE
GND GROUND
HVSD HIGH VOLTAGE SHUTDOWN BOARD
LA LIGHTNING ARRESTER
PRI PRIMARY WINDING
PXF POWER TRANSFORMER
R1, R2 RESONANT RESISTOR
R4, R5 RESISTOR
RA SILICON RECTIFIER ASSEMBLY
RC RESONANT CAPACITOR
RES RESONANT WINDING
RR RESONANT REACTOR
SEC SECONDARY WINDING
SC SNUBBER CAPACITOR
SP1-3, 5, 6 SURGE PROTECTOR
SR SNUBBER RESISTOR
TB1 TERMINAL BLOCK-PXF TERMINATION
TB2 TERMINAL BLOCK-DC OUTPUT
TB3 TERMINAL BLOCK
TP1 POSITIVE OUTPUT TEST JACK
TP2 NEGATIVE OUTPUT TEST JACK
TRIAC RESONANT CONTROL THYRISTOR
VM DC VOLT-METER
SPLICE

NOTES:

1. ALL WIRES ARE BLACK UNLESS OTHERWISE SPECIFIED.
2. ALL WIRES ARE #18 AWG STRANDED OR SELF LEADS UNLESS OTHERWISE SPECIFIED.
3. AC BREAKER TERMINAL LOCATIONS MAY BE DIFFERENT THAN SHOWN. TERMINAL IDENTIFIERS (A, B, C, D, 1, 2) WILL BE CORRECT.
4. ALL WIRES SPECIFIED WITH "*" ARE SELF LEADS.
5. TB1-2 IS LINE 1, TB1-3 IS LINE 2 FOR 208V & 240V. TB1-3 IS NEUTRAL FOR 120V.
6. CIRCUIT BREAKERS ARE SHOWN FROM FRONT OF CABINET.
7. WIRE NUMBERS USED:
POWER: 1 THROUGH 22
CONTROL: 50 THROUGH 64, 67 THROUGH 87, 105, 106
LIGHTNING ARRESTER: 100, 101, 102
8. SP4 IS PART OF RECTIFIER (RA) ASSEMBLY.
9. J3 ON CBA IS MARKED OPPOSITE OF CONNECTOR MARKINGS. EXAMPLE: CBA-J3-2 IS CONNECTOR 21 AND CBA-J3-20 IS CONNECTOR 3.

PARALLEL DC POWER CABLE
AS SHOWN, TIE WRAP TOGETHER
FROM ONE END TO THE OTHER.

DISTRIBUTION CODE:

C&D TECHNOLOGIES, INC.
Power Solutions

WIRING DIAGRAM
HRT48AC50E POSITIVE GROUND
WITH ANALOG METERS

APPROVALS	DATE
DRAWN G. D. HAWKINS	06/04/91
CHECKED D. B. WILSON	12/05/91
APPROVED P. S. ALEXANDER	12/05/91
APPROVED	

SIZE	RATING	DOC TYPE / NUMBER	REVISION
B	STANDARD	NBC-2415	4


BLANK SIZE:

UNLESS OTHERWISE
SPECIFIED DIMENSIONS
ARE IN INCHES
± TOLERANCES ON:

FRACTIONS	DECIMALS	ANGLES
±1/32	0.020 0.010	±1°

NOTICE: THIS PRINT AND THE INFORMATION SHOWN THEREON IS THE PROPERTY OF C&D TECHNOLOGIES, INC. AND IS BEING FURNISHED AS A CONFIDENTIAL DISCLOSURE. IT MAY NOT BE DELIVERED TO OTHERS NOR REPRODUCED FOR GENERAL CIRCULATION WITHOUT THE WRITTEN APPROVAL OF C&D TECHNOLOGIES, INC.


REVISIONS			
REVISION LEVEL	DESCRIPTION	REV. BY REV. DATE	APPROVED BY APPROVED DATE
1	SEE ECN 10352	KEL 02/27/95	MCM 02/27/95
2	SEE ECN 12520	KEL 09/10/99	MCM 09/28/99




NOTICE: THIS PRINT AND THE INFORMATION SHOWN THEREON IS THE PROPERTY OF C&D TECHNOLOGIES, INC. AND IS BEING FURNISHED AS A CONFIDENTIAL DISCLOSURE. IT MAY NOT BE DELIVERED TO OTHERS NOR REPRODUCED FOR GENERAL CIRCULATION WITHOUT THE WRITTEN APPROVAL OF C&D TECHNOLOGIES, INC.

REVISIONS


REVISION LEVEL	DESCRIPTION	REV. BY REV. DATE	APPROVED BY APPROVED DATE
1	SEE ECN 10352	KEL 02/27/95	MCM 02/27/95
2	SEE ECN 12520	KEL 09/10/99	MCM 9/28/99





NOTICE: THIS PRINT AND THE INFORMATION SHOWN THEREON IS THE PROPERTY OF C&D TECHNOLOGIES, INC. AND IS BEING FURNISHED AS A CONFIDENTIAL DISCLOSURE. IT MAY NOT BE DELIVERED TO OTHERS NOR REPRODUCED FOR GENERAL CIRCULATION WITHOUT THE WRITTEN APPROVAL OF C&D TECHNOLOGIES, INC.


REVISIONS			
REVISION LEVEL	DESCRIPTION	REV. BY REV. DATE	APPROVED BY APPROVED DATE
1	SEE ECN 12520	KEL 09/13/99	<i>7/11</i> 9/18/99





NOTICE: THIS PRINT AND THE INFORMATION SHOWN THEREON IS THE PROPERTY OF C&D TECHNOLOGIES, INC. AND IS BEING FURNISHED AS A CONFIDENTIAL DISCLOSURE. IT MAY NOT BE DELIVERED TO OTHERS NOR REPRODUCED FOR GENERAL CIRCULATION WITHOUT THE WRITTEN APPROVAL OF C&D TECHNOLOGIES, INC.

REVISIONS


REVISION LEVEL	DESCRIPTION	REV. BY REV. DATE	APPROVED BY APPROVED DATE
1	SEE ECN 12520	KEL 09/16/99	M/M 9/28/99








TOP (PERFORATED) FRONT OF CABINET



MOUNTING DETAIL



CONNECTION DIAGRAM



6	#8 LUG	#14 WIRE
5	1/4" LUG	#14 WIRE
4	5/16 NUT	
3	5/16X3/4 BOLT	
2	LIGHTNING ARRESTOR	
1	MOUNTING PLATE	
ITEM	DESCRIPTION	

ISSUE	DATE	QTY
CONSTRUCTION		4
DRAWING		
PURCHASE		

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON:		DRAWN E. GREISS	DATE 6/14/89
* DECIMALS ANGLES		CHECKED P. A. CONNOR	6/15/89
X XX XXX		APPROVED <i>D. H. H.</i>	6/16/89
MATERIAL:		APPROVED	
		ISSUED	

C & D TECHNOLOGIES, INC. Power Solutions		
LIGHTNING ARRESTOR INSTALLATION HRT 24/100, HRT 48/50		
SIZE B	CODE IDENT. NO.	KBC-5295
SCALE <i>1/2"</i>	REV. LEVEL 1	SHEET 1 OF 1

REVISIONS		DATE	APPROVED
ZONE	REVISION		
1	SEE ECN 8725	6/4/90	15mm



5	#10 LUG	#14 WIRE
4	1/4 LUG	#14 WIRE
3	5/16 NUT	
2	5/16X1 BOLT	
1	LIGHTNING ARRESTOR	
ITEM	DESCRIPTION	


UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON:		DRAWN E. GREISS	DATE 6/14/89
* DECIMALS	ANGLES	CHECKED P.A. O'CONNOR	6/15/89
X	XX	APPROVED D.B. WILSON	6/16/89
XXX	1/2	APPROVED	
MATERIAL:		ISSUED	

ISSUE	DATE	QTY
CONSTRUCTION		4
OVERLAP		
PURCHASING		

C & D TECHNOLOGIES, INC. Power Solutions		
LIGHTNING ARRESTOR INSTALLATION HRT 48/100		
SIZE B	CODE IDENT. NO.	KBC-5296
SCALE	REV. LEVEL	SHEET
1	1	1 OF 1

CONNECTION DIAGRAM

-
- CONTROL BOARD
- INSTRUMENT PANEL
- (2)
- (1)
- A




3	HARNES, RIBBON
2	STANDOFF
1	OPTION BOARD
ITEM	DESCRIPTION

ISSUE	DATE	QTY
CONSHOCKEN		4
PLP H. S. 1		

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCH TOLERANCES ONE		DRAWN P.A.C. CONNOR		DATE 10/28/90
±		CHECKED <i>[Signature]</i>		10/26/90
DECIMALS .XX .XXX .XXX		APPROVED <i>[Signature]</i>		10/26/90
FRACTIONS 1/8 1/4 3/8 1/2 5/8 3/4 7/8		APPROVED		
MATERIAL:		ISSUED		

FOR OFFICIAL USE ONLY

 CD TECHNOLOGIES, INC. Power Solutions			
INSTALLATION HRT OPTION BOARD, 12-1/4 CABINET			
SIZE DC	DATE 01/11/91	DWT. NO. RED	MBC-5466
SCALE 1/2	REV. LEVEL	SHEET 1	OF 1



1. MOUNT BOARD AS SHOWN WITH SPECIFIED HARDWARE.
2. CONNECT RIBBON CABLE ASSEMBLY (ITEM 3) TO J1 ON THE OPTION BOARD. THE IDENTIFIER MARK SHOULD BE TOWARD PIN 1.
3. CONNECT THE OTHER END OF THE RIBBON CABLE ASSEMBLY TO J1 ON THE CONTROL BOARD. THE IDENTIFIER MARK SHOULD BE TOWARD PIN 1.
4. VERIFY THE HRT'S INTERNAL WIRING DOES NOT REST AGAINST THE OPTION BOARD. IF NECESSARY, CAREFULLY BEND ANY WIRES AWAY FROM THE BOARD'S LOCATION.
5. THREADED STUD IS PART OF CHASSIS SIDE.
6. MATING NUT IS PART OF ITEM 2.

CD TECHNOLOGIES, INC.
Power Solutions

INSTALLATION
HRT UTILITY OPTION BOARD, 17.5" CABINET



SIZE	CODE	IDENT. NO.	ONLY	MBC-5542
------	------	------------	------	----------

SCALE 1:2	REV. LEVEL	SHEET	1 OF 1
-----------	------------	-------	--------

ISSUE	DATE	QTY
CONSHOHOCKEN		4
DUPLICATE		4
TRUCKING		

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: * DIMENSIONS IN PARENTHESES ARE DECIMALS IN INCHES	DRAWN G. D. HAWKINS CHECKED J. B. C. Canner APPROVED J. B. C. Canner	DATE 5-12-90 5/24/90 5/24/90
.03 .010 1/2	MATERIAL:	APPROVED ISSUED

OBsolete FOR RECORD ONLY



SEE NOTE 6

NOTES:

1. MOUNT BOARD AS SHOWN WITH SPECIFIED HARDWARE.
2. SELECT NOMINAL SYSTEM VOLTAGE, 24 OR 48 VOLTS, BY MOVING THE JUMPER ON J4 TO THE APPROPRIATE LOCATION AS MARKED ON THE BOARD.
3. CONNECT RIBBON CABLE ASSEMBLY (ITEM 4) TO J1 ON THE BOARD. THE IDENTIFIER MARK IS TO BE TOWARD PIN 1.
4. CONNECT THE OTHER END OF THE RIBBON CABLE ASSEMBLY TO J1 ON THE CONTROL BOARD. THE IDENTIFIER MARK IS TO BE TOWARD PIN 1.
5. VERIFY THE HRT'S INTERNAL WIRING DOES NOT REST AGAINST THE OPTION BOARD. IF NECESSARY CAREFULLY BEND ANY WIRES AWAY FROM THE BOARD'S LOCATION.
6. AFFIX ITEM 9 VERTICALLY ON THE SIDE OF THE DC CIRCUIT BREAKER. PLACE THE RIBBON CABLE IN ITEM 9.
7. EARLY PRODUCTION MODELS MAY NOT HAVE PROVISIONS FOR ATTACHING BRACKET #2. IF NO HOLE IS PROVIDED, ASSOCIATED HARDWARE MAY BE DISCARDED.
8. EARLY PRODUCTION MODELS MAY HAVE A BUSBAR FROM THE CAPACITOR ASSEMBLY TOUCHING THE BACK OF THE OPTION BOARD. THIS CONDITION IS ACCEPTABLE PROVIDED THAT: A) THE BUSBAR HAS AT LEAST 1/8 INCH CLEARANCE BETWEEN THE CIRCUIT BOARD TRACES, AND B) THE BUSBAR DOES NOT PLACE EXCESSIVE PRESSURE ON THE BOARD.

ITEM	DESCRIPTION
9	WIRE SUPPORT
8	NUT, #6
7	SCREW, #6
6	NUT, #8
5	SCREW, #8
4	HARNESS
3	BRACKET
2	BRACKET, SLOTTED
1	BOARD

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----


UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON:	DRAWN: R.B. WEBER	DATE: 5-23-00
DECIMALS	CHECKED: [Signature]	5/25/00
ANGLES	APPROVED: [Signature]	5/25/00
MATERIAL:	ISSUED:	

C&D TECHNOLOGIES, INC. Power Solutions	
INSTALLATION HRT OPTION BOARD 24" CABINET - 24 VOLT	
SIZE: C	CODE IDENT. NO: MBC-5471
SCALE: 1" = 1"	REV. LEVEL: 1
SHEET 1 OF 1	

OBsolete FOR RECORD ONLY

OBSOLETE FOR RECORD ONLY

ZONE	REV.	DATE	APPROVED
1	1	10/22/91	SEE EON 9281



NOTES:

1. MOUNT BOARD AS SHOWN WITH SPECIFIED HARDWARE.
2. CONNECT RIBBON CABLE ASSEMBLY (ITEM 4) TO J1 ON THE OPTION BOARD. THE IDENTIFIER MARK SHOULD BE TOWARD PIN 1.
3. CONNECT THE OTHER END OF THE RIBBON CABLE ASSEMBLY TO J1 ON THE CONTROL BOARD. THE IDENTIFIER MARK SHOULD BE TOWARD PIN 1.
4. VERIFY THE HRT'S INTERNAL WIRING DOES NOT REST AGAINST THE OPTION BOARD. IF NECESSARY, CAREFULLY BEND ANY WIRES AWAY FROM THE BOARD'S LOCATION.
5. AFFIX ITEM 9 VERTICALLY ON THE SIDE OF THE DC CIRCUIT BREAKER. PLACE THE RIBBON CABLE IN ITEM 9.
6. THREADED STUD IS PART OF CHASSIS SIDE.

ITEM	DESCRIPTION
9	WIRE SUPPORT
8	NUT
7	SCREW
6	NUT
5	SCREW
4	HARNESS
3	BRACKET
2	BRACKET, SLOTTED
1	P.C. BOARD


UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN INCHES, FRACTIONS AND DECIMALS.	DRAWN: G. D. HAWKINS	DATE: 5-18-91
CHECKED: R. D. CONNER	APPROVED: R. D. CONNER	DATE: 5/24/91
ISSUE: .03	DATE: 10/10	QTY: 1/2
MATERIAL:		

CAD TECHNOLOGIES, INC. Power Solutions	
INSTALLATION HRT UTILITY OPTION BOARD, 24" CABINET	
SCALE: 1:2	REV. LEVEL: 1
SHEET: 1 OF 1	

OBSOLETE FOR RECORD ONLY


OBsolete FOR RECORD ONLY

REV.	DESCRIPTION	DATE	APPROVED
1	SEE ECN-8445	10/10/88	DBU/L
2	SEE ECN 8674	3-4-90	DBU/L



NOTES:

1. MOUNT BOARD AS SHOWN WITH SPECIFIED HARDWARE.
2. SELECT NOMINAL SYSTEM VOLTAGE, 24 OR 48 VOLTS, BY MOVING THE JUMPER ON J4 TO THE APPROPRIATE LOCATION AS MARKED ON THE BOARD.
3. CONNECT RIBBON CABLE ASSEMBLY (ITEM 4) TO J1 ON THE BOARD. THE IDENTIFIER MARK IS TO BE TOWARD PIN 1.
4. CONNECT THE OTHER END OF THE RIBBON CABLE ASSEMBLY TO J1 ON THE CONTROL BOARD. THE IDENTIFIER MARK IS TO BE TOWARD PIN 1.
5. VERIFY THE HRT'S INTERNAL WIRING DOES NOT REST AGAINST THE OPTION BOARD. IF NECESSARY CAREFULLY BEND ANY WIRES AWAY FROM THE BOARD'S LOCATION.
6. AFFIX ITEM 9 VERTICALLY ON THE SIDE OF THE DC CIRCUIT BREAKER. PLACE THE RIBBON CABLE IN ITEM 9.



ITEM	DESCRIPTION
9	WIRE SUPPORT
8	NUT, #6
7	SCREW, #6
6	NUT, #8
5	SCREW, #8
4	HARNESS
3	BRACKET
2	BRACKET, SLOTTED
1	BOARD


UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON		DRAWN RATCLIFFE	DATE 10-4-88
1	DECIMALS	CHECKED 10/10/88	
2	FRACTIONS	APPROVED 10/10/88	
3	ANGLES	ISSUED	
MATERIAL:		APPROVED	


C & D TECHNOLOGIES, INC. Power Solutions	
INSTALLATION HRT OPTION BOARD 24" CABINET - 48 VOLT	
SIZE 10-4-88	CODE MBC-5333
SCALE	REV. LEVEL 2 SHEET 1 OF 1

OBsolete FOR RECORD ONLY



- FIGURE 3



4	LUG
3	WIRE
2	LABEL
1	SWITCH
ITEM	DESCRIPTION
DATE 4/28/91	 CD TECHNOLOGIES, INC. <i>Power Solutions</i>
5/9/91	
5/9/91	
INSTALLATION AND CONNECTION GROUND SWITCH ON VOLTMETER HRT SERIES	
SIZE	CODE IDENT. NO.
ORD ONLY	
SCALE	REV. LEVEL
SHEET	1 OF 1

ISSUE	DATE	QTY
CONSHOHOCKEN		4
DUNLAP		4
PURCHASE		

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON			DRAWN R. B. WEBER	DATE 4/26/81
±	DECIMALS	FRACTIONS	CHECKED <i>[Signature]</i>	5/1/81
X .XX	XXX		APPROVED <i>[Signature]</i>	5/4/81
			APPROVED	
			ISSUED	

FOR RECORD

OBSOLETE - FOR DISCLOSURE OR RECORD ONLY


REV. NO.		DATE	APPROVED
1	REV. 02H 1028A	10/11/78	MGM
2	REV. 02H 1030A	10/20/78	MGM

NOTES:

- NUMBERS INSIDE OR ADJACENT TO COMPONENTS INDICATE ITEM NUMBER.
- MARK PART NUMBER AND REVISION LEVEL IN AREA SHOWN. DATA CODE. USE NON-CONDUCTIVE INK/LABEL.
- ALL DIM. ARE FOR REFERENCE ONLY.
- THIS ASSEMBLY CONTAINS STATIC SENSITIVE "MOS" COMPONENTS. THEY MUST BE INSERTED BY A GROUNDED OPERATOR AT A GROUNDED ANTI-STATIC WORKSTATION. AFTER INSTALLATION OF "MOS" COMPONENTS, ASSEMBLY MUST BE PUT IN AN ANTI-STATIC CONTAINER FOR TRANSPORT BETWEEN OPERATIONS OR FOR FINAL SHIPMENT.
- ADDITIONAL JUMPER POSITIONS (IF JUMPERS ARE PRESENT):
J4- REMOVE FOR 200A UNITS
J5- MOVE TO PINS 2&3 FOR 200A UNITS
J6- MOVE TO PINS 2&3 FOR 24V APPLICATIONS
J7- MOVE TO PINS 2&3 FOR REMOTE SENSING

COMPONENTS (USED ON ALL BOARDS)
ITEM NUMBER DESCRIPTION

001	DRILLING	061	TB2
002	BR1	062	U2-4
003	C1	063	U5
004	C3	064	U6
005	C5	065	U7, 10
006	C37, 39, 40	066	U8
007	C8-11	067	U9
008	C12	068	VR1
009	C13	069	VR2,3
010	C14	084	C32
011	C15	085	R43, 55, 56
012	C17-21, 28	086	R58, R59
013	C27, 38	087	R12, 62, 66,
014	C29, 30		77, 78
015	D1-7, 18-20, 27-29, 31, 34, 36, 37, 41, 42, 47-49, 54, 60 D11-13, 16, 17, 21-26, 38-40, 44-46, 53, 59	088	R70
016		089	R51
018	D43	090	R72
019	DS1, 2, 8	091	R71
020	DS3	093	J6, 9
021	DS4, 6, 7	099	TB3
022	DS5	100	K2,4
023	J1	101	D50, 51
024	J3A	102	DS2, 55-57
025	K1	105	
026	K3	106	R47, 49
027	Q1	107	C24-26
028	R41, 42, 52	109	R16, 82
029	R39, 40	110	R81
030	R45	111	R85
031	R1, 2	113	TB2
032	R24	117	C7, 22, 23, 41
033	R4-7, 20, 60, 63, 67	118	R11
034	R64	119	SP1
035	R3, 9, 19, 33, 35, 36, 53	120	R92
037	R13	121	C4
039	R15		
041	R17		
042	R21		
043	R22		
044	R23		
045	R8, 26, 57, 61, 84		
046	R27		
047	R28		
048	R14, 29, 30, 65, 91		
049	R31, 80		
050	R10, 34, 44, 46, 73		
051	R16		
052	R74, 79		
053	R86-90		
054	R54, 83		
055	RN1, 2, 5		
056	RN3		
057	RN4		
058	RN7, 8		
059	S1, 2		
060	TB1		




NBC-2486

DESIGN	D.B. WILSON	DATE	7/29/77
DRAWN	D.B. WILSON	DATE	7/29/77
APPROVED	D.S. ALEXANDER	DATE	7/29/77
ASSEMBLY			
HRT CONTROL/ALARM BOARD ASSEMBLY			
SIZE	BLANK SIZE	NBC-2486	
SCALE	1.5=1	REV. LEVEL	2
SHEET	1	OF	2

OBSOLETE - FOR DISCLOSURE OR RECORD ONLY

OBSOLETE - FOR RECORD ONLY OR OBSOLETE - FOR RECORD ONLY



NBC-2487

ADDITIONAL COMPONENTS ARE:

- ITEM 10 - C33, C34
- ITEM 59 - J5
- ITEM 73 - R37
- ITEM 74 - R38
- ITEM 75 - J2
- ITEM 94 - XJ4, J5
- ITEM 122 - R68, 69
- ITEM 92 - J4
- ITEM 93 - J5

NBC-2488

ADDITIONAL COMPONENTS ARE:

- ITEM 12 - C3
- ITEM 21 - C6, 10, 14, 15
- ITEM 29 - C59, 10
- ITEM 69 - C59
- ITEM 89 - C59
- ITEM 94 - XJ7, 8
- ITEM 102 - C52
- ITEM 103 - R78
- ITEM 104 - R75
- ITEM 93 - J7, J8


NBC-2489

CONSIST OF THE COMPONENTS FOR BOTH NBC-2487 & NBC-2488

NBC-2487 , NBC-2488 OR NBC-2489

OBSOLETE - FOR RECORD ONLY OR OBSOLETE - FOR RECORD ONLY

OBSOLETE - FOR RECORD ONLY




REVISIONS				
REV.	DATE	BY	APPROVED	REASON
1	11-14-84	KEL	DSW	REV. 1
2	3-18-85	RMH	DSW	REV. 2

- NOTES
- UNLESS OTHERWISE SPECIFIED
ALL RESISTOR VALUES ARE IN OHMS
ALL CAPACITOR VALUES ARE IN MICROFARADS
ALL RESISTORS ARE 1/4W 5%
ALL CAPACITORS ARE 50V, 10%
ALL DIODE ARE 1N4004
- LAST REFERENCE DESIGNATION USED
- BR1, C41, D60, DS10, JS, K4, Q2, R92, S3,
SP1, TB3, U10, VR3
- REFERENCE DESIGNATION NOT USED
- D30, D32, D33, D35
U1
VR4
- REFERENCE DRAWINGS
LAND PATTERN: NBC-2486LP
DRILLING: NBC-2486D
SOLDER MASK: NBC-2486SM
SILKSCREEN: NBC-2486SS
ASSEMBLIES: NBC-2486 BASIC BOARD
NBC-2487 DIGITAL METER
NBC-2488 COMBINATION DIGITAL METER
NBC-2489 COMBINATION DIGITAL METER AND GROUND DETECTION
3. INDICATES COMPONENTS REQUIRED FOR DIGITAL METER OPTION.
4. INDICATES COMPONENTS REQUIRED FOR GROUND DETECTION OPTION.
- FOR COMBINATION DIGITAL METER AND GROUND DETECTION OPTION COMPONENTS IN BOTH 3 & 4 ARE REQUIRED.


TO OPTION BOARD

DESIGNED S.B.	DATE 3/17/82	S & S TECHNOLOGIES, INC. Power Solutions
APPROVED DSW	DATE 6-30-84	
SCHEMATIC CONTROL/ALARM 2486 HRT BOARD		SCALE 1=1 REV. LEVEL 2 SHEET 1 OF 2
ANALYZE NBC-2486SD		

OBSOLETE - FOR RECORD ONLY



OBSOLETE - FOR DISPOSITION OR RECORD ONLY




OBSOLETE - FOR DISPOSITION OR RECORD ONLY

D

C

B

A



CD TECHNOLOGIES, INC. Power Solutions	
SCHEMATIC DIAGRAM HRT OPTION BOARD	
REV. NO. 1.0 SHEET 2 OF 2	

DESIGNED BY: J. WEBER	DATE: 1-12-88
CHECKED BY: J. WEBER	DATE: 1-12-88
APPROVED BY: J. WEBER	DATE: 1-12-88
MATERIAL	
APPROVED	

