



**SETUP GUIDE
SNMP ALARM ADAPTOR
COMPATIBLE WITH
SIGMA, RADIANT, TPCMQ & BLUEstreak
POWER SHELVES**

Document Number: SNMP-MAN Rev. 4

**© 2019 UNIPOWER LLC
All Rights Reserved**

UNIPOWER, LLC
65 Industrial Park Rd
Dunlap, TN 37327
Phone: +1-954-346-2442
Toll Free: 1-800-440-3504
Web site: www.unipowerco.com

Product Support

Product support can be obtained using the following addresses and telephone numbers.

Corporate office:	Manufacturing facility:	Manufacturing facility:
UNIPOWER, LLC	UNIPOWER, LLC	UNIPOWER Slovakia SRO
210 N University Dr	65 Industrial Park Rd	ZLATOVSKA 1279
Coral Springs, FL 33071	Dunlap, TN 37327	Business Center 22
United States	United States	91105 Trencin, Slovakia

Phone: +1-954-346-2442

Toll Free: 1-800-440-3504

Web site – www.unipowerco.com

When contacting UNIPOWER, please be prepared to provide:

1. The product model number, spec number, S build number, and serial number
- see the equipment nameplate on the front panel
2. Your company's name and address
3. Your name and title
4. The reason for the contact
5. If there is a problem with product operation:
 - Is the problem intermittent or continuous?
 - What revision is the firmware?
 - What actions were being performed prior to the appearance of the problem?
 - What actions have been taken since the problem occurred?

REV	DESCRIPTION	CHK'd & APPR'd / DATE
4	PCO# 45400	MM / 07-31-19

Contents

1.0	INTRODUCTION	4
2.0	STANDARD FEATURES	5
3.0	WARRANTY (summary)	5
4.0	UNPACKING AND INSPECTION	5
5.0	MODULE SPECIFICATIONS	6
6.0	DESCRIPTION	6
7.0	INSTALLATION	7
8.0	INITIAL SETUP	8
9.0	WEB PAGES	9

FIGURES

Figure 1	SNMP Alarm Module	4
Figure 2	Rear View	6
Figure 3	Initial Log On Page	9
Figure 4	Home Page	10
Figure 5	Configuration - Network - IP Settings	11
Figure 6	Configuration - Network - Network Services Settings	12
Figure 7	Configuration - Network - Advanced Network Settings	13
Figure 7	Configuration - Alarm Configuration (1)	14
Figure 8	Configuration - Alarm Configuration (2)	15
Figure 9	System - System Configuration (1)	16
Figure 10	System - System Configuration (2)	17
Figure 11	Configuration - Users	18
Figure 12	Management - Connections	19
Figure 13	Administration - Update Firmware	20
Figure 14	Administration - Factory Default Settings	21
Figure 15	Administration – System Information - General	22
Figure 16	Administration – System Information – GPIO	23
Figure 17	Administration – System Information – Serial	24
Figure 18	Administration – System Information – Network	25
Figure 19	Administration – Reboot	26
Figure 20	Log out	27

SETUP GUIDE

SNMP ALARM ADAPTOR

1.0 INTRODUCTION

These alarm adaptor modules plug directly into the 25 way D-Type signal connector at the rear of a Sigma, Radian or BLUEstreak Series power shelf and monitors the DC Good signal provided by each power module.

When an alarm condition occurs or clears the built-in processor sends an SNMP alarm trap to the monitoring host and optionally can send an email message.

The module also provides connections via spring clamp terminals to allow daisy-chaining of the share bus between multiple parallel connected shelves as well as remote sense connections.

The Ethernet connection is made via a standard RJ45 socket.

This setup guide details installation and the available functions of the Unipower SNMP alarm adaptor. The primary purpose of this module is to provide SNMP traps when an alarm condition occurs so that a remote monitoring station can be alerted. The adaptor may also be set up to provide alert e-mails. SNMP monitoring is best achieved by using third party management software such as HP Open view.

Setting up such software is beyond the scope of this Guide.




Figure 1 - SNMP Alarm Module

2.0 STANDARD FEATURES

- ◆ SNMP Alarm Traps
- ◆ Indicates DC Output Status for each Module
- ◆ Optional Email Alarms
- ◆ Daisy-chains Share Bus
- ◆ Provides Connections For Remote Sense
- ◆ Spring Clamp Connections (no tools)

3.0 WARRANTY (summary)

These adaptors are warranted for two (2) years from date of shipment against defects in material and workmanship. This warranty does not extend to products which have been opened, altered or repaired by persons other than persons authorized by the manufacturer or to products which become defective due to acts of God, negligence or the failure of customer to fully follow instructions with respect to installation, application or maintenance.

For a complete text of UNIPOWER's warranty conditions please request a copy from your local Sales Office.

4.0 UNPACKING AND INSPECTION

- 4.1** This unit was carefully tested, inspected and packaged for shipment from our factory. Upon receipt the unit should be carefully unpacked and inspected for any damage in shipment.
- 4.2** If there is evidence of damage, do not attempt to install the unit. The freight carrier should be notified immediately and a claim for the cost of the unit should be filed with the carrier for direct reimbursement. Be sure to include the model and serial number of the damaged unit in all correspondence with the freight carrier. Also save the shipping carton and packing material as evidence of damage for the freight carrier's inspection.
- 4.3** UNIPOWER LLC will cooperate fully in case of any shipping damage investigation.
- 4.4** Always save the packing materials for later use in shipping the unit. Never ship this unit without proper packing.

5.0 MODULE SPECIFICATIONS

The following specifications are typical at 25°C unless otherwise noted.

NETWORK INTERFACE

Standard.....	IEEE802.3
Physical Layer.....	10/100 Base-T
Data Rate.....	10/100Mbps (auto-sensing)
Mode.....	Half/Full Duplex Support (auto-sensing)
Connector.....	RJ45, standard Ethernet connections
SNMP.....	Version 1

ENVIRONMENTAL

Operating Temp. Range.....	-40°C to +70°C
Humidity.....	0% to 95%, Non-Condensing
ESD.....	Bellcore GR-1089-Core and EN61000-4-2
MTBF, 35°C (Bellcore).....	1.6M Hours

PHYSICAL

Case Material.....	Steel
Dimensions, Inches (mm).....	1.14 H x 2.99 W x 2.24 D (29 x 76 x 57)
Weight.....	0.22 lbs. (0.1 kg.)

6.0 DESCRIPTION




Figure 2 - Rear View

6.1 Indicators

The two indicators together indicate the status of the power module.

The left hand yellow LED indicates the link status and should normally be on.

The right hand green LED indicates Network activity and should normally be flickering.

6.2 Spring Clamp Terminals

Two sets of connections for remote sense and share are provided to allow for multiple power shelves connected in parallel.

6.3 Ethernet

An RJ45 connector with standard pinout provides the connection to an Ethernet network.

7.0 INSTALLATION

The adaptor is plugged directly into the 25 way D-type connector on the rear of the front-end / rectifier power shelf. The two knurled screws must be properly tightened to ensure mechanical stability.

When the remote sense facility is being used with multiple shelves it is recommended that the sense terminals are linked between individual shelves and only one pair of remote leads connected to the remote sense point.

In the case of dual bus shelves where there are two separate D-type connectors two separate adaptors are required to monitor the complete power system.

In such cases it is essential that the remote sense and share connections are made to the loads and the same bus on additional shelves.

The maximum wire size that can be accepted by the spring clamp terminals is 22AWG.

IMPORTANT NOTE: WHEN USING THESE ADAPTORS WITH THE OR BLUEstreak POWER SHELVES THE POSITION OF THE D-TYPE CONNECTORS ON THE REAR IS SUCH THAT THE ADAPTOR WILL PROTRUDE SLIGHTLY ABOVE THE TOP OF THE SHELF WHEN INSTALLED. THE POWER SHELF SHOULD THEREFORE BE INSTALLED IN THE RACK SUCH THAT ANY UNIT IN THE POSITION IMMEDIATELY ABOVE HAS A DEPTH LESS THAN OR EQUAL TO THAT OF THE POWER SHELF OTHERWISE THE ADAPTOR WILL NOT FIT.

8.0 INITIAL SETUP

The module is intended to be connected to a local area network using ethernet. The module provides an RJ-45 socket for this purpose.

To assist in setting up the module initially, it is suggested that a crossover cable is used to connect directly between the module and a computer.

The module is initially set with the following network settings:

IP address:	192.168.0.200
Subnet mask:	255.255.255.0
Gateway:	0.0.0.0

A computer initially connected to the module must have it's IP address set in the range 192.168.0.x where x is 1 to 255 (not 200 though). The computers subnet mask must be set to 255.255.255.0.

It should then be possible to log in to the module using internet explorer or another web browser.

The rectifier shelf system should be powered up with the SNMP module connected to the 25-way connector on the rear of the shelf. You should see the yellow and green lights on the SNMP module flash a few times as it boots up.

To connect to the module, simply type the following into the browsers address bar:

`http://192.168.0.200`

The log in web page should appear. If it does not, please recheck your computer network settings and ensure that a crossover cable is used for direct connection.

9.0 WEB PAGES

9.1 Initial Log On




Figure 3 - Initial Log On Page

Type the following into the boxes as shown in figure 1 to log on:

Username: admin

Password: 1234

Press the **Login** button.

9.2 Home Page




Figure 4 - Home Page

After successfully logging in, the module home page will be displayed. A menu is provided down the left hand side which allows access to various module set up features.

The home page displays some basic information about the adaptor including a description, contact details and location.

The tutorial link should not be used as it contains details of features not available in this module configuration.

9.3 Configuration – Network – IP Settings




Figure 5 - Configuration - Network - IP Settings

The network configuration screen allows adjustment of basic network parameters (IP address, subnet mask and gateway). It will also allow the module to be configured to use DHCP.

A reboot will be necessary after changing any of these parameters.

Remember to redirect your browser to the new address and reconfigure the connecting computer if necessary.

9.4 Configuration – Network – Network Services Settings




Figure 6 - Configuration - Network - Network Services Settings

The network service settings allow some of the network features to be enabled or disabled. It is recommended to only enable the following since other features are not supported by this module:

- ADDP Device discovery
- Network management protocol (SNMP)
- Telnet server
- Web server (HTTP)

9.5 Configuration – Network – Advanced Network Settings





Figure 7 - Configuration - Network - Advanced Network Settings

The advanced network settings allow more precise adjustment of network parameters.

It is recommended that only advanced users adjust these parameters.

9.6 Configuration - Alarms Configuration



Changes have been saved successfully.

Alarms Configuration

Alarm Notification Settings

☒ Enable alarm notifications

Mail Server Address (SMTP):

From E-Mail Address:

Alarm Conditions

Enable	Alarm	Type	Trigger	SNMP Trap	Send To	Email Subject
<input checked="" type="checkbox"/>	Alarm 1	gpio	1 x x x x	enabled	somebody@somewhere.com	Module 1 DC Fault Activated
<input checked="" type="checkbox"/>	Alarm 2	gpio	x 1 x x x	enabled	somebody@somewhere.com	Module 2 DC Fault Activated
<input checked="" type="checkbox"/>	Alarm 3	gpio	x x 1 x x	enabled	somebody@somewhere.com	Module 3 DC Fault Activated
<input type="checkbox"/>	Alarm 4	gpio	x x x 1 x	enabled	someone@somewhere.com	Module 4 DC Fault Activated
<input checked="" type="checkbox"/>	Alarm 5	gpio	0 x x x x	enabled	someone@somewhere.com	Module 1 DC Fault Cleared
<input checked="" type="checkbox"/>	Alarm 6	gpio	x 0 x x x	enabled	someone@somewhere.com	Module 2 DC Fault Cleared
<input checked="" type="checkbox"/>	Alarm 7	gpio	x x 0 x x	enabled	someone@somewhere.com	Module 3 DC Fault Cleared
<input type="checkbox"/>	Alarm 8	gpio	x x x 0 x	enabled	someone@somewhere.com	Module 4 DC Fault Cleared
<input type="checkbox"/>	Alarm 9	gpio	x x x x x	disabled		
<input type="checkbox"/>	Alarm 10	gpio	x x x x x	disabled		

Figure 7 - Configuration - Alarm Configuration (1)

The alarms configuration page shows some preset alarm conditions so that any failing power supply module will provide an alarm output. Alarm outputs will also be generated when faults are cleared. The check box at the top must always be checked as otherwise no alarm outputs will be generated from either SNMP or e-mail.

For the e-mail service, the mail server IP address must be entered into the relevant box. This box will only accept an IP address in numerical format.

Most mail servers will require a 'from' e-mail address before they will accept outgoing mail. This address must be entered in the box. This address must be valid on the mail server. Don't forget to press **Apply** after making changes.

To alter the e-mail address that alarms are sent to and to setup other parameters, click on the blue text in the second column of the alarm table. For each alarm a screen similar to that shown in figure 8 will appear.




Figure 8 - Configuration - Alarm Configuration (2)

The GPIO pin state combo boxes should not be altered as this will affect how the module creates alarms. If reminders at regular intervals are required for a continuing alarm condition, then this can be enabled using the check box. The repeat time in seconds can then be entered into the box.

If an e-mail is required to be sent for this condition, then the check box must be checked next to 'Send E-mail to the following recipients when alarm occurs'.


The text boxes can then be filled in with the relevant details.

Note that the e-mail subject is also used when SNMP traps are sent.

To enable an SNMP trap to be sent, make sure the check box is checked for that option.

Please press **Apply** when all changes are complete.

9.7 Configuration – System - System Configuration



Ethernet Module Configuration and Management

Home

Configuration

- Network
- Alarms
- System**
- Users

Management

- Connections

Administration

- Update Firmware
- Factory Default Settings
- System Information
- Reboot

Logout

System Configuration

▼ **Device Identity Settings**

Description:

Contact:

Location:

► Simple Network Management Protocol (SNMP) Settings

Copyright © 2008 Unipower Telecom. All rights reserved. s/w 103-1407-0010r4
www.unipowertelecom.com

Figure 9 - System - System Configuration (1)

This web page allows the user to enter some information about the site.

This information is present on the home page and can also be accessed when using SNMP.




Figure 10 - System - System Configuration (2)

This web page allows the user to set up the SNMP. The community strings and trap destination can be set.

Additional traps can be configured to be sent if desired by checking the relevant boxes.

Please press **Apply** when changes have been completed.

9.8 Configuration – Users




Figure 11 - Configuration - Users

This page displays the possible user log in names.

The root user **MUST NOT** be removed as it may be required for factory configuration.

It is not recommended to change any admin user settings as access to some of the menus may become impossible.

9.9 Management – Connections




Figure 12 - Management - Connections

This page shows any active connections. No changes are possible on this screen.

9.10 Administration – Update Firmware




Figure 13 - Administration - Update Firmware

This page allows the updating of the core module firmware.

It is not recommended to do this unless it has been advised by UNIPOWER. If so then the necessary files will be provided.

9.11 Administration – Factory Default Settings




Figure 14 - Administration - Factory Default Settings

This page allows the user to revert to the default settings of the module as supplied by UNIPOWER.

9.12 Administration – System Information - General




Figure 15 - Administration – System Information - General

This web page shows basic information about the module system.

9.13 Administration – System Information – GPIO




Figure 16 - Administration – System Information – GPIO

The GPIO page shows the state of the monitored inputs. Each pin corresponds to a DCOK signal from a power supply module. In TPCP/TPCM and similar products where three power modules are monitored, then the first three pins will be used for modules 1 to 3 as viewed from the front of the shelf. When a module is working correctly, the pin will show as De-asserted. For modules that are faulty or are not present, the pin will show as Asserted.

9.14 Administration – System Information – Serial




Figure 17 - Administration – System Information – Serial

This page shows the status of the serial port within the module.

This port is not available for external use and no changes should be made.

9.15 Administration – System Information – Network




Figure 18 - Administration – System Information – Network

This web page shows statistics about the network connection to the module.

This data is also available through the SNMP.

9.16 Administration – Reboot




Figure 19 - Administration – Reboot

This page is used to reboot the module.

This can be done if some changes have been made that require it.

9.17 Log out




Figure 20 - Log out

The page shown in figure 20 will be displayed when the user has successfully logged out.

9.18 Further SNMP information

The SNMP adaptor supports SNMP version 1.

The following MIBs should be used with the SNMP adaptor:

RFC1213, MIB-II	Network Statistics
RFCs 1316, 1317	Port Statistics
DIGI-SMI	Enterprise MIB
DIGI-DEVICE-INFO-MIB	Enterprise MIB
DIGI-SERIAL-ALARM-TRAPS-MIB	Enterprise MIB

For more information on the statistics available through the standard RFCs listed above, refer to the RFCs available on the IETF web site (www.ietf.org). For enterprise MIBs, refer to the description fields in the MIB text.

This document is believed to be correct at time of publication and UNIPower LLC accepts no responsibility for consequences from printing errors or inaccuracies. Specifications are subject to change without notice.